K&F Concept KF13.107

K&F CONCEPT KF13.107 32L Waterproof 2-in-1 Camera Backpack and Shoulder Bag Instruction Manual

Brand: K&F Concept | **Model:** KF13.107

1. Introduction

Thank you for choosing the K&F CONCEPT KF13.107 32L Camera Backpack. This versatile 2-in-1 camera bag is designed for photographers requiring robust protection and flexible storage for their gear. Featuring a waterproof EVA material construction, a large 32L capacity, and a detachable shoulder bag, it is ideal for outdoor activities, travel, commuting, and professional photography. This manual provides detailed instructions for optimal use and maintenance of your camera bag.



Figure 1: The K&F CONCEPT KF13.107 32L Camera Backpack with its detachable shoulder bag.

2. Product Overview

The KF13.107 camera backpack is engineered for durability and functionality. It features a robust exterior, customizable interior, and ergonomic design for comfortable carrying. The bag includes a main backpack unit and a separate camera shoulder bag, offering flexible usage options.

2.1 Key Features

- **2-in-1 Design:** Combines a 32L backpack with a detachable camera shoulder bag.
- **Waterproof & Durable:** Constructed from superior EVA material, offering waterproof, shockproof, tear-proof, scratch-resistant, and easy-to-clean properties.
- **Customizable Storage:** EVA Velcro-type partition plates allow for flexible interior configuration to fit various equipment sizes.
- **Laptop Compartment:** Dedicated rear compartment accommodates laptops up to 15.6 inches.
- **Ergonomic Comfort:** Features highly cushioned back shoulder harnesses, adjustable chest straps, and a hollow honeycomb material pad for breathability and reduced burden.
- **Rain Cover:** Includes a rainproof cover for enhanced protection in heavy rain.

Video 1: An overview of the K&F Concept Camera Bag's features and design.

3. Setup and Configuration

3.1 Customizing Internal Dividers

The main compartment of the backpack features removable EVA Velcro-type partition plates. These can be freely rearranged to create custom compartments that securely fit your camera bodies, lenses, and other accessories. Experiment with different layouts to find the most efficient and protective configuration for your specific gear.



Figure 2: Illustration of the customizable internal dividers in the top and bottom compartments.

3.2 Attaching the Detachable Shoulder Bag

The included camera shoulder bag (27x12.5x17cm) can be used independently or stored within the main backpack's bottom compartment. To use it as a standalone bag, attach the provided shoulder strap. To integrate it with the backpack, ensure it is securely placed within the designated bottom section.



Figure 3: The detachable shoulder bag, illustrating its capacity for a camera, lenses, and clothing.

3.3 Tripod Attachment

The backpack features a concealed tripod support at the bottom and adjustable straps on the side to securely carry a tripod. Extend the bottom support and use the side straps to fasten your tripod firmly to the backpack, ensuring even weight distribution.



Figure 4: Instructions for attaching a tripod using the concealed support and side straps.

4. Usage

4.1 Packing Your Gear

Utilize the customizable compartments to organize your camera, multiple lenses, flashes, and other accessories. The 32L capacity allows for substantial gear. The separate laptop compartment on the back can hold up to a 15.6-inch laptop, providing quick and secure access.



Figure 5: An example of organized camera gear within the backpack, highlighting the laptop and mesh pockets.

4.2 Wearing the Backpack

Adjust the highly cushioned back shoulder harnesses and chest straps to ensure a snug and comfortable fit. The hollow honeycomb material pad on the back promotes breathability, making it comfortable for extended periods of wear. Proper adjustment helps distribute weight evenly and prevents shaking during movement.

Video 2: Demonstrates the K&F Concept Large Camera Backpack in use, highlighting its capacity and wearability.

4.3 Using the Rain Cover

In adverse weather conditions, deploy the included rainproof cover over the entire backpack. This provides an additional layer of protection against water, safeguarding your valuable camera and accessories from moisture.



Figure 6: The backpack with its rain cover, illustrating enhanced weather protection.

5. Maintenance

To ensure the longevity and performance of your K&F CONCEPT camera bag, follow these maintenance guidelines:

- **Cleaning:** The exterior EVA material is easy to clean. Wipe with a damp cloth and mild soap if necessary. For the interior, remove all gear and use a soft brush or vacuum to remove dust and debris.
- **Drying:** If the bag gets wet, especially after using the rain cover, ensure it is thoroughly air-dried in a well-ventilated area before storing. Do not use direct heat sources.
- **Storage:** Store the bag in a cool, dry place away from direct sunlight when not in use. Avoid placing heavy objects on top of the bag to maintain its shape and protective properties.
- **Zipper Care:** Periodically clean zippers with a small brush to remove dirt. Lubricate with a zipper lubricant if they become stiff.

6. Specifications

Feature	Detail
Model Number	KF13.107
Product Dimensions	8.66 x 13.39 x 21.26 inches (34 x 22 x 54 cm)
Item Weight	6.38 pounds (2.9 kg)
Capacity Total	32 Liters
Material	EVA (Waterproof, Shockproof, Tear-resistant)
Laptop Compatibility	Up to 15.6 inches
Included Accessories	Detachable Camera Shoulder Bag (27x12.5x17cm), Rain Cover

7. Troubleshooting

This section addresses common concerns you might encounter with your camera bag:

- **Bag feels too heavy when full:** Ensure shoulder and chest straps are properly adjusted to distribute weight evenly across your back and hips. Utilize the waist strap for additional support.
- **Gear not fitting properly:** Reconfigure the EVA Velcro dividers. They are designed to be flexible; experiment with different arrangements to optimize space for your specific equipment.
- **Water leakage during rain:** While the bag is made of waterproof material, always use the included rain cover in heavy rain for maximum protection. Ensure all zippers are fully closed.
- **Zippers are stiff:** Clean any debris from the zipper teeth and apply a small amount of zipper lubricant or wax to improve

smoothness.

8. Warranty and Support

For warranty information, product support, or any inquiries regarding your K&F CONCEPT KF13.107 Camera Backpack, please refer to the official K&F Concept website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.