

## Roxel RSB-380

# Roxel RSB380 All-in-One Soundbar User Manual

Model: RSB-380

## 1. INTRODUCTION

The Roxel RSB380 is an all-in-one 2.0 channel soundbar designed to significantly enhance your television's audio experience. Featuring built-in high-range speakers and multiple connectivity options, it delivers clear and powerful sound for movies, music, and games.

## 2. SAFETY INFORMATION

- Read all instructions carefully before use.
- Do not expose the soundbar to rain or moisture.
- Do not block any ventilation openings.
- Ensure the power cable is not pinched or walked on.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel.

## 3. PACKAGE CONTENTS

Please check that all items are present in the box:

- Roxel RSB380 Soundbar
- User Manual
- Wall Mount Guide
- Wall mounting screws and brackets
- Power cable
- Remote control
- Optical cable (if included in your specific package)

## 4. PRODUCT OVERVIEW

## 4.1 Key Features

- Compact All-in-One 2.0 System
- Multi-Connection Options (AUX, USB, Optical, Wireless Bluetooth)
- Simplified Setup
- Roxel Remote Control Included
- Elegant and Stylish Design with Wall Mounting Capability

## 4.2 Soundbar Dimensions



Figure 1: Roxel RSB380 Soundbar with indicated dimensions. The soundbar measures approximately 27.5 inches (69 cm) in length and 3.5 inches (10 cm) in height and depth.

## 4.3 Internal Speaker Configuration



## 2.0 Home Theatre System

Figure 2: An exploded view illustrating the internal speaker components of the RSB380, demonstrating its 2.0 channel home theatre system design.

## 5. SETUP

### 5.1 Placement Options

The Roxel RSB380 Soundbar offers versatile placement options:

- **Tabletop Placement:** Place the soundbar on a flat, stable surface directly in front of your TV.
- **Wall Mounting:** The soundbar can be mounted on a wall using the provided brackets and screws. Refer to the included Wall Mount Guide for detailed instructions.

# Mountable Design



28Inch,Great for 28" or above TVs, Place on cabinet or mount under your tv

Figure 3: The soundbar features a mountable design with a wall mount kit provided. Examples show the soundbar wall-mounted and placed on a cabinet, suitable for TVs 28 inches or larger.

## 5.2 Connecting to Your TV or Device

The RSB380 offers multiple connection methods:

### 1. Optical Connection (Recommended for best audio quality):

Connect one end of the optical cable to the OPTICAL OUT port on your TV and the other end to the OPTICAL IN port on the soundbar. Select 'Optical' input on the soundbar.

### 2. AUX Connection:

Connect a 3.5mm audio cable from the AUX OUT port on your TV or device to the AUX IN port on the soundbar. Select 'AUX' input on the soundbar.

### 3. USB Connection:

Insert a USB drive containing audio files into the USB port on the soundbar. The soundbar will automatically switch to USB mode and begin playback.

### 4. Bluetooth Connection:

Refer to Section 6.3 for detailed Bluetooth pairing instructions.

## 5.3 Power Connection

Connect the provided power cable to the DC IN port on the soundbar and then plug it into a wall outlet. The

soundbar will enter standby mode.

## 6. OPERATING THE SOUNDBAR

---

### 6.1 Power On/Off

Press the **POWER** button on the soundbar or the remote control to turn the unit on or off.

### 6.2 Input Selection

Press the **MODE** button on the soundbar or the remote control repeatedly to cycle through the available input sources: Optical, AUX, USB, and Bluetooth.

### 6.3 Bluetooth Pairing

1. Turn on the soundbar.
2. Press the **MODE** button until 'BT' (Bluetooth) is displayed or indicated by an LED. The soundbar will enter pairing mode.
3. On your Bluetooth-enabled device (e.g., smartphone, tablet), search for available Bluetooth devices.
4. Select 'Roxel RSB380' from the list.
5. Once paired, the soundbar will emit a confirmation tone, and the 'BT' indicator will stop flashing.
6. You can now play audio from your device through the soundbar.

### 6.4 Volume Control

Use the **VOL+** and **VOL-** buttons on the soundbar or the remote control to adjust the volume. Press the **MUTE** button on the remote to temporarily silence the audio.



Figure 4: Operating the soundbar with the included remote control for convenient audio adjustments.



Figure 5: The Roxel RSB380 Soundbar seamlessly integrates into a home entertainment setup, providing enhanced audio for various content.

## 7. MAINTENANCE

---

To ensure the longevity and optimal performance of your Roxel RSB380 Soundbar:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the soundbar. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure that the ventilation openings are not obstructed to prevent overheating.
- **Storage:** If storing the soundbar for an extended period, disconnect it from power and store it in a cool, dry place.

## 8. TROUBLESHOOTING

---

If you encounter issues with your soundbar, refer to the following common problems and solutions:

- **No Power:**

*Solution:* Check if the power cable is securely connected to both the soundbar and the wall outlet. Try

a different power outlet.

- **No Sound:**

*Solution:* Ensure the soundbar is powered on and not muted. Verify that the correct input source is selected (Optical, AUX, Bluetooth). Check the volume level on both the soundbar and your connected device/TV. Ensure cables are securely connected.

- **Bluetooth Pairing Issues:**

*Solution:* Ensure the soundbar is in Bluetooth pairing mode. Turn off Bluetooth on other nearby devices to avoid interference. Try unpairing and re-pairing the soundbar from your device's Bluetooth settings.

- **Remote Control Not Working:**

*Solution:* Check the battery in the remote control and replace if necessary. Ensure there are no obstructions between the remote and the soundbar's sensor.

## 9. SPECIFICATIONS

Feature	Specification
Model Number	RSB-380
Brand	Roxel
Speaker Type	Soundbar
Connectivity Technology	AUX, USB, Optical, Wireless (Bluetooth 5.0)
Audio Output Mode	Stereo
Max Speaker Output Power	120 Watt
Surround Sound Configuration	2.0 Channel
Speaker Dimensions	60 Millimeter
Product Dimensions	69 x 10 x 10 cm; 2.32 kg
Power Source	Electric with cord
Control Method	Remote Control
Mounting Type	Wall Mount
Compatible Devices	Android devices, iOS devices, Television, Universal TV
Special Features	Portable
Color	Black

## 10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official Roxel website. Keep your proof of purchase for any warranty claims.

