

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [ciciglow](#) /

> [ciciglow Vintage Corded Telephone User Manual](#)

ciciglow ciciglow4iug85vwtb2305

ciciglow Vintage Corded Telephone User Manual

Model: ciciglow4iug85vwtb2305

1. INTRODUCTION

This manual provides essential instructions for the installation, operation, and maintenance of your ciciglow Vintage Corded Telephone. Designed with a classic retro aesthetic, this telephone features large, clear buttons and high-definition call quality, making it suitable for home, office, or hotel use.

Vintage style

With ringtone, essential tool for home office.



Image: The ciciglow Vintage Corded Telephone, featuring its classic pink design and rotary-style keypad, resting on a wooden surface, highlighting its vintage aesthetic.

The telephone is constructed from durable ABS material, ensuring robustness while maintaining its vintage characteristics. It incorporates a built-in voice smart chip and an anti-jamming system to reduce noise and ensure clear voice transmission during calls.

High-definition call quality

Office phone reduces noise by using a built-in voice smart chip and anti-jamming system, and 100% conveys your voice.



Image: An illustration depicting three individuals engaged in phone conversations using the ciciglow Vintage Corded Telephone, emphasizing its high-definition call quality feature in an office environment.

2. PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all components are present:

- 1 x Telephone Base
- 1 x Telephone Receiver
- 1 x Receiver Connection Cable
- 1 x US Telephone Line Cable
- 1 x UK Telephone Line Cable (random color)
- 1 x User Manual



Image: The ciglow Vintage Corded Telephone base, its receiver, and the two telephone line cables (US and UK) included in the package, laid out for inspection.

3. INSTALLATION

Follow these steps to properly install your ciglow Vintage Corded Telephone:

1. **Connect the Receiver:** Connect the telephone receiver to the telephone base using the coiled receiver connection cable. Ensure one end is inserted into the receiver and the other end into the socket marked for the receiver on the base.
2. **Connect the Telephone Line:** Connect the telephone power supply (line cable) to the socket marked with "TE cable" on the base. The other end of this cable plugs into your wall telephone jack. The product includes both US and UK telephone line cables for compatibility.
3. **Verify Connection:** After plugging the telephone into the wall socket, lift the handset and listen for a dial tone for a few seconds. If a dial tone is heard, the telephone is correctly connected and ready for use.

● Installation

- 1) Please note that Telephone receivers should be connected using a crimped cable with one end inserted into the receiver and the other end inserted into the base. Use the cable with the socket marked with the receiver.
- 2) Connect the telephone power supply (cable) to the socket marked with TE cable on the base and the plug. The other end goes into your phone supply.
- 3) After you plug the phone into the socket, check for proper connection by listening to the dial tones for a few seconds through the handset of your mobile phone. When the dial tones are heard, the telephone can be used.



Image: A visual guide illustrating the three key installation steps for the ciglow Vintage Corded Telephone, including connecting the receiver and the telephone line, and verifying the dial tone.

4. OPERATING INSTRUCTIONS

The ciglow Vintage Corded Telephone is designed for straightforward voice communication.

- **Making a Call:** Lift the receiver and wait for a dial tone. Dial the desired phone number using the large, clear buttons on the keypad.
- **Receiving a Call:** When the telephone rings, lift the receiver to answer the call.
- **Ending a Call:** Place the receiver back onto the telephone base to end the call.
- **Redial Function:** The telephone features a "REDIAL" button for quickly redialing the last number called.
- **Flash Function:** The "FLASH" button can be used for certain network services, such as call waiting or transferring calls, depending on your telephone service provider.



Image: A user engaged in a phone call with the ciglow Vintage Corded Telephone, illustrating the practical application of the device in a typical office or home environment.

5. MAINTENANCE

Proper care will ensure the longevity of your telephone:

- **Cleaning:** Disconnect the telephone from its wall jack before cleaning. Clean the surface with a damp cloth. Do not use liquid cleaners or immerse the telephone in water.
- **Temperature:** Avoid exposing the telephone to extreme temperatures.
- **Water Resistance:** This product is not waterproof. Do not allow it to get wet or immerse it in water.

6. TROUBLESHOOTING

If you encounter issues with your telephone, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No dial tone or unable to make calls.	<ul style="list-style-type: none"> • Telephone line cable not properly connected. • Receiver connection cable loose. • Issue with the telephone service line. 	<ul style="list-style-type: none"> • Ensure both ends of the telephone line cable are securely plugged into the telephone base and the wall jack. • Check that the receiver connection cable is firmly inserted into both the receiver and the base. • Test with another phone if available, or contact your telephone service provider.
Rings but cannot answer/talk.	<ul style="list-style-type: none"> • Receiver connection cable issue. • Internal fault. 	<ul style="list-style-type: none"> • Verify the receiver connection cable is correctly and firmly attached. • If the problem persists after checking connections, the unit may have an internal fault.
Poor call quality or static.	<ul style="list-style-type: none"> • Loose cable connections. • Interference. 	<ul style="list-style-type: none"> • Ensure all cables are securely connected. • Move the telephone away from other electronic devices that might cause interference.

7. SPECIFICATIONS

- **Brand:** ciciglow
- **Model Number:** ciciglow4iug85vwtb2305
- **Type:** Vintage Corded Telephone
- **Main Material:** ABS
- **Main Color:** Pink
- **Number Storage Function:** Yes
- **Caller ID:** No
- **Visual Function:** No
- **Power Source:** Corded Electric
- **Answering System Type:** Digital (refers to keypad dialing, not an answering machine)



Image: A direct front view of the ciciglow Vintage Corded Telephone, showcasing its large, clear dialing buttons, the central redial and flash buttons, and the classic receiver cradle.

8. SAFETY INFORMATION

- Do not expose the telephone to water or high humidity. This product is not waterproof.
- Avoid placing the telephone in direct sunlight or near heat sources.
- Keep the telephone away from strong magnetic fields.
- Use only the provided cables for connection.
- Do not attempt to disassemble or repair the telephone yourself. Contact qualified personnel for service.

9. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available documentation. For any support inquiries, technical assistance, or questions regarding your ciciglow Vintage Corded Telephone, please refer to the retailer or the manufacturer's official support channels.