

[Manuals.plus](#) /

> [SONGMICS](#) /

> SONGMICS Garment Rack HSR060W01 Instruction Manual

## SONGMICS HSR060W01

# SONGMICS Garment Rack HSR060W01 Instruction Manual

Model: HSR060W01

## 1. INTRODUCTION

---

Thank you for choosing the SONGMICS Garment Rack HSR060W01. This manual provides essential information for the safe assembly, operation, and maintenance of your new garment rack. Please read these instructions carefully before assembly and retain them for future reference.



Image 1.1: Fully assembled SONGMICS Garment Rack HSR060W01.

## 2. PRODUCT OVERVIEW AND COMPONENTS

The SONGMICS HSR060W01 is a robust, industrial-style garment rack designed for organizing clothes in bedrooms, laundry rooms, or for display. It features a double-rod design and a lower storage shelf, all supported by a durable steel frame with mobile wheels.

### Key Features:

- **Double Hanging Rods:** Provides ample space for hanging garments.
- **Bottom Storage Shelf:** Ideal for shoes, boxes, or other accessories.
- **Mobile Design:** Equipped with 4 universal wheels for easy movement, two of which are lockable for stability.
- **High Load Capacity:** Supports up to 110 kg (242 lbs) of evenly distributed weight.

- **Durable Construction:** Made from high-quality alloy steel.

### Components:

Please ensure all parts are present before beginning assembly. Refer to the included parts list in your packaging for detailed identification.



Image 2.1: The double hanging rods provide extensive storage for various clothing items.

## 3. ASSEMBLY INSTRUCTIONS

Assembly of the SONGMICS Garment Rack HSR060W01 is designed to be straightforward. Follow the clear instructions and use the marked parts provided in your package.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify that all components listed in the parts list are present.

2. **Assemble Base Frame:** Connect the base pipes according to the diagrams in your instruction leaflet. Ensure all connections are secure.
3. **Attach Wheels:** Insert the four universal wheels into the designated holes on the base frame. Ensure the two lockable wheels are positioned as indicated for easy access.
4. **Install Vertical Supports:** Attach the vertical support pipes to the base frame.
5. **Mount Lower Shelf:** Secure the lower storage shelf onto the vertical supports at the specified height.
6. **Install Double Rods:** Attach the two hanging rods to the upper sections of the vertical supports. Ensure they are level and firmly secured.
7. **Final Check:** Once assembled, gently shake the rack to ensure all connections are stable and secure.



Image 3.1: Detail of the robust pipe connections and a lockable wheel.

## 4. OPERATING INSTRUCTIONS

### Using the Hanging Rods:

Utilize the double hanging rods to organize your clothing. The distance between the bars is approximately 44 cm, allowing for easy access and preventing clothes from touching the lower shelf.



Image 4.1: The 44 cm spacing between rods provides ample room for garments.

### Using the Storage Shelf:

The lower shelf is suitable for storing shoes, folded clothes, storage boxes, or other items. Ensure items are placed evenly to maintain stability.




Image 4.2: The bottom shelf offers convenient storage for various items.

### **Mobility and Stability:**

The garment rack is equipped with four 360-degree swivel wheels for easy movement. Two of these wheels are lockable. To move the rack, unlock the wheels. To secure it in place, engage the locks on the two designated wheels.

## **5. MAINTENANCE**

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners that may damage the finish.
- **Load Capacity:** Do not exceed the maximum static load capacity of 110 kg (242 lbs). Distribute weight evenly across the rods and shelf.
- **Moving the Rack:** When the rack is heavily loaded, it is recommended to move it with the

assistance of another person to prevent damage and prolong its lifespan.

- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight and secure.

## 6. TROUBLESHOOTING

---

- **Rack is unstable:** Ensure all screws and connections are tightened. Verify that the vertical supports are correctly installed. If wheels are locked, unlock them before moving. If moving, ensure wheels are unlocked.
- **Difficulty moving the rack:** Check if the wheel locks are engaged. Ensure the wheels are free from obstructions.
- **Parts missing or damaged:** Contact SONGMICS customer support for assistance.

## 7. SPECIFICATIONS

---

Feature	Detail
Brand	SONGMICS
Model Number	HSR060W01
Color	White
Material	Alloy Steel
Product Dimensions (L x W x H)	100 x 59 x 162 cm (39.4 x 23.2 x 63.8 inches)
Weight	9 kg (19.8 lbs)
Maximum Static Load Capacity	110 kg (242 lbs)
Distance between Hanging Rods	44 cm (17.3 inches)
Installation Method	Freestanding with wheels



Image 7.1: Product dimensions overview.

## 8. SAFETY INFORMATION

- Keep small parts away from children during assembly to prevent choking hazards.
- Do not stand or climb on the garment rack.
- Ensure the rack is placed on a level surface to prevent tipping.
- Do not overload the rack beyond its specified weight capacity.
- Use the wheel locks when the rack is stationary to prevent accidental movement.

## 9. WARRANTY AND SUPPORT

SONGMICS products are designed for quality and durability. For any questions, missing parts, or

issues with your product, please contact SONGMICS customer support. Please have your model number (HSR060W01) and purchase information ready when contacting support.

For more information, visit the official [SONGMICS Brand Store](#).