



[Manuals.plus](#) /

> [Bellemave](#) /

> Bellemave Twin House Bunk Bed: Metal Frame Assembly and User Manual

Bellemave 3080K

Bellemave Twin House Bunk Bed Instruction Manual

Model: 3080K | Brand: Bellemave

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembling and using this product. Keep this manual for future reference.

- Ensure the bed's weight capacity is not exceeded. The upper bed has a maximum weight capacity of **220 lbs.**
- Be cautious of pinch points and sharp edges during assembly and use.
- Follow the provided assembly instructions carefully to prevent instability or collapse.
- Use the secured built-in ladder safely. Always face the ladder when ascending or descending.
- Only one person should occupy the upper bunk at a time.
- Ensure mattresses used are of appropriate size and thickness. Recommended upper mattress thickness: **6 inches**. Recommended lower mattress thickness: **8-10 inches**.
- Periodically check and ensure that all connectors are tight.
- Do not allow children to play under the upper bunk without supervision.

2. PRODUCT OVERVIEW

The Bellemave Twin House Bunk Bed is a metal twin over twin loft bed designed for children's bedrooms. Its unique house shape adds a decorative element, while the metal construction ensures durability and stability. This bed features a low height, making it suitable for rooms with lower ceilings and for younger children.

Key Features:

- **Space-Saving Design:** Twin over twin configuration with a lower overall height.
- **Convertible Functionality:** The bottom bed can be used as a traditional twin bed or removed to create a play/storage area beneath the loft.
- **Durable Construction:** Crafted from strong, solid, powder-coated metal for stability and longevity.
- **Integrated Ladder:** Features a secured built-in ladder that can be positioned on either the left or right

side during assembly.

- **House Shape Design:** Whimsical house roof design adds charm to any child's room.

Product Dimensions:



Image: Detailed dimensions of the Bellemave Twin House Bunk Bed, showing overall length (76.5 inches), width (40.5 inches), and height (71 inches), along with specific measurements for the upper bed, ladder, and floor clearance.

- Overall Product Dimension: 76.5 inches (L) x 40.5 inches (W) x 71 inches (H)
- Bed Dimension (each): 75 inches (L) x 38.5 inches (W)
- Total Height: 71 inches
- Overall Product Weight: 69.5 lbs
- Upper Bed Weight Capacity: 220 lbs
- Recommended Upper Mattress Thickness: 6 inches
- Recommended Lower Mattress Thickness: 8-10 inches

Product Images:



Image: The Bellemave Twin House Bunk Bed in a decorated child's room, showcasing its house-like structure and twin over twin configuration.




Image: A front view of the Bellemave Twin House Bunk Bed, highlighting the metal frame and the house-shaped roof.



Image: An angled view of the Bellemave Twin House Bunk Bed, showing the integrated ladder and the open space for the lower bed.



Image: A side view of the Bellemave Twin House Bunk Bed, emphasizing the metal slat support for the upper bunk.

3. PACKAGE CONTENTS

Please verify that all parts and hardware are present before beginning assembly. Refer to the detailed parts list included in your product packaging for a complete inventory.

If any parts are missing or damaged, please contact Bellemave customer support for assistance.

4. ASSEMBLY INSTRUCTIONS

Assembly of the Bellemave Twin House Bunk Bed requires two adults. Follow the step-by-step instructions provided in the separate assembly manual included with your product. Ensure all connections are secure before use.

General Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts and hardware using the provided parts list.
3. Assemble the base frame for the lower bed (if applicable).
4. Assemble the upper bunk frame, including the side rails and mattress support slats.
5. Attach the house-shaped roof structure.

6. Install the integrated ladder, ensuring it is securely fastened. The ladder can be installed on either the left or right side.
7. Tighten all bolts and screws firmly, but do not overtighten.
8. Place mattresses on the upper and lower bunks.

Note: For detailed, visual assembly guidance, please refer to the specific diagrams and instructions in your packaged manual.

5. OPERATING INSTRUCTIONS

This bunk bed is designed for sleeping and light play. Adhere to the following guidelines for safe operation:

- **Ladder Use:** Always use the integrated ladder to access the upper bunk. Do not climb on the side rails or other parts of the bed.
- **Mattress Placement:** Ensure mattresses are properly seated within the bed frames and do not extend beyond the safety rails.
- **Lower Bed Configuration:** The lower bed can be used with a mattress or the space can be utilized for storage or a play area. If using as a play area, ensure it is clear of hazards.
- **Weight Limits:** Do not exceed the 220 lbs weight limit for the upper bunk.
- **Supervision:** Young children using the upper bunk should be supervised.

6. MAINTENANCE

Regular maintenance will help prolong the life and safety of your Bellemave Twin House Bunk Bed.

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the powder-coated finish.
- **Hardware Check:** Periodically (e.g., monthly) inspect all bolts, screws, and connections to ensure they are tight. Retighten if necessary.
- **Structural Integrity:** Check for any signs of wear, damage, or loose parts. Do not use the bed if any structural components are compromised.
- **Ladder Inspection:** Ensure the ladder rungs and attachments are secure and free from damage.

7. TROUBLESHOOTING

If you encounter any issues with your Bellemave Twin House Bunk Bed, please refer to the troubleshooting section in your original assembly manual. Common issues and their solutions are typically addressed there.

General Troubleshooting Tips:

- **Squeaking/Wobbling:** Check all bolts and screws for tightness. Ensure the bed is on a level surface.
- **Missing Parts:** Refer to the package contents list. Contact customer support if parts are missing.
- **Difficulty Assembling:** Review the assembly manual carefully. Ensure all parts are oriented correctly. Do not force parts together.

For persistent problems or issues not covered in the manual, please contact Bellemave customer support.

8. SPECIFICATIONS

Feature	Specification
---------	---------------

Brand	Bellemave
Model Number	3080K
Material	Metal
Finish Type	Powder Coated
Furniture Finish	White
Form Factor	Bunk Bed, Loft Bed
Compatible Mattress Size	Twin
Overall Product Dimensions (L x W x H)	76.5 x 40.5 x 71 inches
Upper Bed Weight Capacity	220 Pounds
Recommended Upper Mattress Thickness	6 inches
Recommended Lower Mattress Thickness	8-10 inches
Assembly Required	Yes
Spring Box Required	No

9. WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation included with your purchase or contact Bellemave customer support directly. If you have any questions, require replacement parts, or need assistance with assembly or troubleshooting, please reach out to Bellemave customer service.

Contact information can typically be found on the product packaging or the Bellemave official website.