Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave bed-frames

Bellemave Multi-Functional Twin Over Twin/King Bunk Bed with Trundle Instruction Manual

Model: bed-frames | Brand: Bellemave

1. Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Always use the integrated ladder carefully to avoid injury.
- Do not exceed the weight limits: Upper bed - 150 lb, Down bed - 200/400 lb, Trundle - 200 lb.
- Follow assembly instructions carefully to ensure stability and prevent collapse.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten hardware.
- Only use mattresses of the specified thickness to maintain proper guardrail height.

2. Product Overview

The Bellemave Multi-Functional Bunk Bed offers versatile sleeping solutions, featuring an upper twin bed, an expandable lower bed that converts from twin to king size, and a pull-out trundle bed. Constructed from solid pine wood and high-quality MDF, this bunk bed is designed for durability and space-saving functionality.

Key Features:

- **Twin to King Bottom Bed:** The lower bed can be expanded from a twin size to a full or king size to accommodate different needs.
- **Pull-Out Trundle:** An additional twin-size trundle bed with wheels provides extra sleeping space.
- **Solid Construction:** Made of pine wood and MDF for lasting stability.
- **Reversible Ladder:** The integrated ladder can be placed on either the left or right side during assembly.
- **Safety Rails:** Full-length guardrails on the upper bunk ensure safety.

Dimensions:

Refer to the image below for detailed product dimensions.

SIZE:INCH




Image: Detailed dimensions of the Bellemave Twin Over Twin/King Bunk Bed with Trundle. The upper bed is 78.9 inches long, the total width is 116 inches when expanded, and the total height is 59.6 inches.

3. Setup and Assembly

Assembly is required for this bunk bed. Please ensure all parts are present and undamaged before beginning. A detailed assembly instruction manual is included with your product. Follow the step-by-step guide carefully.

Important Notes for Assembly:

- This item comes in 2 packages and may not be delivered at the same time. Please wait patiently for all packages before starting assembly.
- No box spring or foundation is needed; mattresses are placed directly on the slats.
- The ladder can be installed on either the left or right side to suit your room layout.

Visual Guide:

The following video demonstrates the assembly and features of the bunk bed.

Your browser does not support the video tag.

Video: An official product video from Orien Life demonstrating the assembly and key features of the Bellemave Twin to King Bunk Bed with Trundle.

4. Operating Instructions

Expanding the Bottom Bed:

The lower bed is designed to expand from a twin size to a larger size (full or king) as needed. To expand, gently pull the bed frame outwards. The frame is equipped with a sliding mechanism that allows for smooth extension. To contract, push the frame back inwards until it reaches the twin size configuration.



Image: The Bellemave bunk bed with the bottom bed fully expanded, showcasing its larger sleeping capacity.



Image: The Bellemave bunk bed with the bottom bed in its contracted, twin-size configuration.

Using the Trundle Bed:

The trundle bed is located beneath the lower bunk and can be easily pulled out for additional sleeping space. It features wheels for smooth movement. To use, simply grasp the front panel and pull the trundle out. To store, push it back under the main bed frame.



Image: A close-up view of the pull-out trundle bed, showing its wheels and how it slides out from under the main bunk bed structure.

5. Maintenance

Proper maintenance will extend the life and appearance of your Bellemave bunk bed.

- **Cleaning:** For general cleaning, wipe surfaces with a dry cloth. For deeper cleaning, use a slightly damp cloth and mild soap, then dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Product Care:** The manufacturer recommends dry cleaning for specific components, if applicable. Refer to any fabric care tags on mattresses or bedding.
- **Hardware Checks:** Periodically inspect all bolts, screws, and connections to ensure they are tight. Re-tighten as necessary to maintain structural integrity and safety.
- **Avoid Excessive Moisture:** Protect the wood from prolonged exposure to moisture, which can cause warping or damage.

6. Troubleshooting

If you encounter any issues with your Bellemave bunk bed, please refer to the following common solutions:

- **Wobbling or Instability:** Check all assembly hardware. Ensure all bolts and screws are fully tightened. Uneven flooring can also cause wobbling; try repositioning the bed or using shims.
- **Difficulty Expanding/Contracting Lower Bed:** Ensure there are no obstructions (e.g., bedding, rugs) preventing the smooth movement of the frame. Check the tracks for debris.
- **Trundle Not Rolling Smoothly:** Inspect the trundle wheels for any obstructions or damage. Ensure the floor surface is clear.
- **Missing Parts or Damaged Components:** If you received incomplete or damaged parts, please contact customer

service immediately.

7. Specifications

Feature	Detail
Brand	Bellemave
Model Number	bed-frames
UPC	733805837617
Color	White
Material	Pine wood + MDF
Finish Type	Painted
Product Dimensions (L x W x H)	78.9" x 116" x 59.6" (Expanded)
Upper Bed Size	Twin (40.4" x 79.5")
Down Bed Size (Normal/Stretch)	Twin (40.4" x 79.5") / King (77.5" x 79.5")
Trundle Bed Size	Twin
Total Height	59.8"
Upper Bed Weight Capacity	150 lb
Down Bed Weight Capacity	200 lb (Twin) / 400 lb (King)
Trundle Weight Capacity	200 lb
Upper Bed Recommended Mattress Thickness	6"
Down Bed Recommended Mattress Thickness	8"-10"
Trundle Recommended Mattress Thickness	6"
Number of Slats (Upper/Down/Trundle)	10/10/8
Assembly Required	Yes

8. Warranty and Support

While specific warranty details are not provided in the product information, Bellemave is committed to customer satisfaction. If you have any questions, concerns, or require assistance with your product, please contact our customer service team. Our experienced customer service team will respond within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official Bellemave website.

© 2025 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09QWWCL4M

More documents and user manuals: **https://manuals.plus/**