

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Zyerch](#) /

› [Zyerch 2 Person Pop Up Beach Tent Instruction Manual](#)

Zyerch CL026

Zyerch 2 Person Pop Up Beach Tent Instruction Manual

Model: CL026

1. INTRODUCTION AND OVERVIEW

The Zyerch 2 Person Pop Up Beach Tent is designed for quick and hassle-free setup, providing a comfortable and protected space for up to two people. Its lightweight and portable design makes it ideal for various outdoor activities such as beach trips, picnics, and camping.

Key features include:

- Spacious interior accommodating 2 people (Dimensions: 6.8ft L x 4.6ft W x 45"H).
- Excellent ventilation with 3 large mesh windows and a 4-sided design for air circulation and 360° views.
- UPF 50+ sun protection to shield against harmful UV rays.
- Durable and 25mph windproof construction with 190T/800mm water-resistant PU-coated polyester and welded seams.
- Effortless pop-up setup in seconds, requiring no assembly.



Figure 1.1: The Zyerch 2 Person Pop Up Beach Tent in light blue, shown with its compact carrying bag.

2. SAFETY INFORMATION

WARNING:

- Always secure the tent with the included guy lines and stakes, especially in windy conditions.
- Do not use the tent in winds exceeding 25mph without additional securing measures.
- Exercise caution when unfolding and folding the tent due to the spring-loaded pop-up mechanism. Keep clear of face and body.
- Inspect the tent for any damage, particularly to the poles, before each use. Discontinue use if significant damage is found.
- Keep away from open flames and heat sources.

3. SETUP INSTRUCTIONS

The Zyerch Pop Up Beach Tent is designed for an effortless, instant setup. No assembly of poles is required.

1. **Unpack the Tent:** Remove the tent from its carrying bag. It will be in a compact, folded disc shape.
2. **Release and Unfold:** Hold the tent away from your face and body. Gently untwist the tent from its folded position. The tent is spring-loaded and will automatically pop open into its full shape.
3. **Position the Tent:** Place the tent in your desired location.
4. **Secure the Tent:**
 - **For Sand/Beach Use:** Fill the attached sandbags located at the corners of the tent with sand to provide stability.
 - **For Grass/Soft Ground Use:** Use the included stakes to anchor the tent to the ground through the loops at the base.
 - **Wind Stability:** For added stability, especially in windy conditions, extend and secure the pre-attached guy lines using the provided stakes.



Figure 3.1: The effortless setup process, where the tent pops open automatically when released from its folded state.

Windproof



Figure 3.2: Detail of the windproof features, including sandbags and guy lines for securing the tent.

4. OPERATING THE TENT

Once set up, the Zyerch Beach Tent offers several features to enhance your comfort and protection.

4.1 Ventilation

The tent features three large mesh windows and a 4-sided ventilation design to ensure optimal airflow. To maximize ventilation, ensure all mesh windows are uncovered. This helps reduce heat buildup inside the tent and provides a 360° view of your surroundings.



Figure 4.1: The tent's interior showcasing the large mesh windows for excellent ventilation and panoramic views.

4.2 Sun Protection

The tent material provides UPF 50+ sun protection, effectively blocking harmful UV rays. This is crucial for preventing sunburn and heatstroke, especially for children. The tent also provides shade for items like snacks and drinks, keeping them cool and out of direct sunlight.

UPF 50+ Sun Protection



Figure 4.2: The tent providing UPF 50+ sun protection for a family enjoying the beach.

4.3 Packing Up the Tent

Folding the pop-up tent back into its compact disc shape requires a specific technique:

1. **Gather the Corners:** Bring the opposite corners of the tent together.
2. **Form a Figure-8:** Twist the tent into a figure-8 shape. One side will naturally fold over the other.
3. **Collapse into a Circle:** Continue to press down and fold the tent until it collapses into a flat circle.
4. **Secure with Strap:** Use the attached elastic strap or tie to keep the tent in its folded circular shape.
5. **Place in Bag:** Carefully place the folded tent back into its carrying bag.

Note: Practice may be required to master the folding technique. Refer to online video tutorials if needed by searching for "pop up tent folding instructions".

5. MAINTENANCE

Proper maintenance will extend the life of your Zyerch Beach Tent.

- Cleaning:** Clean the tent with a soft cloth, mild soap, and lukewarm water. Do not use harsh detergents or abrasive cleaners. Rinse thoroughly.
- Drying:** Always ensure the tent is completely dry before folding and storing it. Storing a damp tent can lead to mildew and fabric degradation. Air dry in a shaded, well-ventilated area.
- Storage:** Store the tent in its original carrying bag in a cool, dry place, away from direct sunlight and extreme temperatures.
- Inspection:** Periodically inspect the fabric, seams, zippers, and poles for any signs of wear or damage. Address minor issues promptly to prevent them from worsening.

6. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Tent does not pop open fully.	May be slightly tangled or not fully released.	Gently shake the tent or manually assist the poles to fully extend. Ensure no fabric is caught.
Difficulty folding the tent.	Incorrect folding technique.	Review Section 4.3 "Packing Up the Tent" and practice the figure-8 twist. Search for online video tutorials if needed by searching for "pop up tent folding instructions".
Tent feels unstable in wind.	Insufficient anchoring.	Ensure all sandbags are filled (if on sand) or stakes are firmly in the ground. Utilize all guy lines and adjust tension. Do not use in winds exceeding 25mph.
Fiberglass particles on tent or hands.	Wear and tear of pole sleeves or manufacturing residue.	Wear gloves when handling the tent if this occurs. Gently wipe down the tent with a damp cloth to remove loose fibers. If severe or persistent, contact customer support.
Poles appear bent or broken.	Impact, improper folding, or manufacturing defect.	If poles are significantly damaged, the tent's structural integrity may be compromised. Contact customer support for warranty information or replacement options.

7. SPECIFICATIONS

Feature	Detail
Brand	Zyerch
Model Name	pop up beach tent
Model Number	CL026

Feature	Detail
Capacity	2 Person Tent
Material	190T/800mm water-resistant PU-coated polyester (fabric), Polyethylene (PE) groundsheet, Metal (frame/poles)
Color	Light Blue
Product Dimensions (L x W x H)	81.6" L x 55.2" W x 45" H (approx. 6.8ft L x 4.6ft W x 3.75ft H)
Floor Area	31.28 Square Feet
Item Weight	3 Pounds (approx. 1.36 kg)
UV Protection	UPF 50+
Water Resistance Level	Water Resistant
Wind Resistance	Up to 25mph (with proper securing)
Included Components	Beach tent, carrying bag, stakes, guy lines
UPC	850035427385

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Zyerch 2 Person Pop Up Beach Tent comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use.

The warranty does not cover:

- Damage caused by improper use, abuse, or neglect.
- Damage caused by extreme weather conditions (e.g., winds exceeding 25mph, heavy storms).
- Normal wear and tear.
- Unauthorized repairs or modifications.


8.2 Customer Support

For warranty claims, technical assistance, or any questions regarding your Zyerch Pop Up Beach Tent, please contact Zyerch customer support. Refer to the product packaging or the retailer's website for the most current contact information.

When contacting support, please have the following information ready:

- Your purchase receipt or proof of purchase.
- The product model number (CL026).
- A detailed description of the issue.

Related Documents - CL026

	<p><u>User Manual for Zyerch Stylus Pen (AZ002/ST001B/ST002) for iPad</u> Comprehensive user manual for the Zyerch Stylus Pen, detailing setup, Bluetooth connection, troubleshooting, and product specifications for compatible iPad models.</p>
	<p><u>TaoTronics LED Stand Light TT-CL026 User Guide</u> Comprehensive user guide for the TaoTronics LED Stand Light, model TT-CL026. Learn about setup, features, operation, safety instructions, and troubleshooting for this versatile lighting solution.</p>