

[manuals.plus](#) /› [Sunbeam](#) /› [Sunbeam Twin Size Electric Fleece Heated Blanket User Manual](#)

Sunbeam Fleece

Sunbeam Twin Size Electric Fleece Heated Blanket User Manual

Model: Fleece

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Sunbeam Twin Size Electric Fleece Heated Blanket. Please read all instructions carefully before use and retain this manual for future reference.

The Sunbeam Fleece Heated Blanket offers comfortable softness and warmth, designed to provide a cozy experience. It features a removable cord and controller for easy machine washing and tumble drying, ensuring durability and softness wash after wash.

SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Do not use with infants, children, incapacitated persons, or anyone insensitive to heat.
- Do not use with damaged cords or plugs.
- Do not use if wet.
- Do not dry clean. Dry cleaning solvents may damage the insulation.
- Do not use pins or other metallic objects with this blanket.
- Ensure the controller is not covered or placed under the blanket during use to prevent overheating.

SETUP

Follow these steps to set up your electric heated blanket:

1. **Unpack:** Carefully remove the blanket and controller from the packaging.
2. **Position:** Lay the blanket flat on your bed. Ensure the controller cord can reach a power outlet without being stretched or pinched.
3. **Connect Controller:** Locate the connector on the blanket and the plug on the controller cord. Firmly push the controller plug into the blanket connector until it clicks securely into place.

4. **Plug In:** Plug the power cord into a 120V AC electrical outlet.



Image: The Sunbeam Twin Size Electric Fleece Heated Blanket, folded, with its attached controller showing temperature settings.

OPERATING INSTRUCTIONS

Your Sunbeam electric blanket is designed for ease of use with multiple heat settings and an automatic timer.

1. **Turn On:** Press the power button on the controller to turn the blanket on.
2. **Adjust Heat Setting:** Use the dial or buttons on the controller to select your desired heat level. The blanket offers 10 heat settings for personalized comfort.
3. **Set Timer:** The blanket features an automatic shut-off timer, which can be set for up to 10 hours. Refer to the controller's specific markings for timer adjustment.
4. **Turn Off:** Press the power button again to turn the blanket off. Unplug the blanket from the wall outlet when not in use for extended periods.



Image: A close-up view of two Sunbeam electric blanket controllers, showing the heat setting dial and power button.

MAINTENANCE AND CARE

Proper care will extend the life of your Sunbeam electric blanket. This blanket is machine washable.

- 1. Disconnect:** Always unplug the blanket from the wall outlet and disconnect the controller from the blanket before washing.
- 2. Pre-soak (Optional):** For best results, pre-soak the blanket for 15 minutes in cold water with a mild detergent.
- 3. Machine Wash:** Wash on the gentle cycle in a washing machine with cold water and a small amount of mild detergent. Do not bleach.
- 4. Rinse:** Rinse on the normal cycle.
- 5. Tumble Dry:** Tumble dry on low heat or air dry until completely dry. Do not iron. Do not plug in the blanket until it is completely dry.



Image: The Sunbeam Electric Fleece Heated Blanket, neatly folded, showcasing its soft fleece material.

TROUBLESHOOTING

If your electric blanket is not functioning as expected, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Blanket not heating.	Not plugged in, controller not connected securely, or power outage.	Ensure power cord is firmly plugged into a working outlet. Check that the controller is securely connected to the blanket. Verify power to the outlet.
Controller light blinking or off.	Safety shut-off activated or connection issue.	Unplug the blanket from the wall outlet for 30 seconds, then plug it back in. Ensure all connections are secure. If the issue persists, contact customer support.
Blanket feels unevenly heated.	Blanket not spread flat or internal wiring shifted.	Ensure the blanket is spread evenly on the bed without folds or bunches. If the problem continues, discontinue use and contact customer support.

SPECIFICATIONS

- **Model:** Fleece
- **Size:** Twin
- **Dimensions:** 62 x 84 Inches
- **Material:** 100% Fleece
- **Color:** Blue
- **Heat Settings:** 10
- **Timer:** Up to 10 Hours automatic shut-off
- **Care:** Machine Washable
- **Item Weight:** 3 Pounds
- **Manufacturer:** Sunbeam

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Sunbeam customer service. Retain your proof of purchase for any warranty claims.

You can visit the official Sunbeam store for more information and product registration [Sunbeam Official Store](#)