Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave Twin Bed with Trundle

Bellemave Twin Bed with Trundle Instruction Manual

Model: Twin Bed with Trundle (B09QYQCGLR)

1. Introduction

Thank you for choosing the Bellemave Twin Bed with Trundle. This manual provides essential information for the safe assembly, proper use, and maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.

2. Safety Information

WARNING: Failure to follow these safety instructions could result in serious injury or property damage.

- Always assemble the bed on a soft, clean surface to prevent damage to the product.
- Ensure all parts are securely fastened before use. Periodically check and re-tighten all connections.
- Do not allow children to play on or around the bed without supervision.
- Do not use power tools for assembly as this may overtighten and damage the fasteners or wood.
- **Weight Capacity:** The platform bed supports up to 275 LBS. The trundle bed supports up to 175 LBS. Do not exceed these limits.
- Keep small parts out of reach of children during assembly.

3. Package Contents

Before assembly, verify that all components and hardware are present. Refer to the included parts list in your packaging. If any parts are missing or damaged, do not proceed with assembly. Contact customer support immediately.
Typical components include:

- Headboard and Footboard panels
- Side rails
- Bed slats for main bed and trundle
- Trundle frame with casters
- Hardware pack (screws, bolts, nuts, Allen wrench)

4. Setup and Assembly Instructions

Recommended: Two adults for assembly.

1. **Prepare the Area:** Clear a spacious area for assembly. Lay out all components on a soft, non-abrasive surface to prevent scratches.
2. **Attach Side Rails to Headboard and Footboard:** Connect the side rails to the headboard and footboard using the provided bolts and nuts. Ensure all connections are snug but do not overtighten until all parts are aligned.
3. **Install Bed Slats (Main Bed):** Evenly space and secure the wooden slats across the main bed frame. Use the provided screws to attach them to the side rails. Ensure slats are firmly attached to support the mattress.
4. **Assemble Trundle Frame:** Follow the specific instructions for assembling the trundle frame, including attaching the casters.
5. **Install Trundle Slats:** Secure the wooden slats to the trundle frame in the same manner as the main bed.
6. **Insert Trundle:** Carefully slide the assembled trundle bed under the main bed frame.
7. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and screws.



Image 1: Overall dimensions of the Bellemave Twin Bed with Trundle. The main bed measures 79.5" L x 41.7" W x 37.5" H. The trundle measures 75.5" L x 39.2" W x 9.5" H. The main bed platform height is 17.7 inches.



Image 2: Angled view of the Bellemave Twin Bed with Trundle, showing the trundle bed fully extended from beneath the main bed frame. This illustrates the functional design for accommodating an additional sleeper.

5. Usage Instructions

5.1 Main Bed

Place a standard twin-size mattress (recommended thickness 8 inches) directly onto the bed slats. No box spring is required. Ensure the mattress is centered and fits securely within the frame.

5.2 Trundle Bed

To use the trundle bed, gently pull the trundle frame out from under the main bed using the integrated casters. Place a twin-size mattress (recommended thickness 8 inches) onto the trundle slats. After use, push the trundle back under the main bed for compact storage.



Image 3: Side view of the Bellemave Twin Bed with Trundle, illustrating the main bed frame and the trundle bed positioned underneath. This shows the compact storage of the trundle when not in use.

6. Maintenance

- **Cleaning:** Wipe the bed frame with a dry, soft cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the wood finish.
- **Regular Checks:** Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten as necessary to maintain stability and safety.
- **Avoid Moisture:** Keep the bed away from excessive moisture or direct sunlight to prevent warping or fading of the wood.



Image 4: Close-up detail of the headboard design, showcasing the vertical paneling and the smooth, curved top edge. This highlights the craftsmanship and finish of the wood.

7. Troubleshooting

- **Squeaking Noises:** Check all connections and tighten any loose bolts or screws. Ensure slats are properly seated and secured.
- **Trundle Not Sliding Smoothly:** Inspect the casters for any obstructions or damage. Ensure the floor surface is clear and level.
- **Wobbly Frame:** Verify that all bolts are fully tightened and that the bed is on a level surface.
- **Missing Parts:** If you discover missing parts during assembly, do not attempt to substitute. Contact Bellemave customer support for replacements.

8. Specifications

Feature	Detail

Feature	Detail
Product Type	Platform Bed with Trundle
Size	Twin
Color Options	White, Gray, Espresso, Walnut
Material	Plywood, Solid Pine Wood
Box Spring Required	No
Number of Slats (Platform Bed)	10
Number of Slats (Trundle Bed)	8
Weight Capacity (Platform Bed)	275 LBS
Weight Capacity (Trundle Bed)	175 LBS
Overall Product Dimensions	79.5" L x 41.7" W x 37.5" H
Recommended Mattress Thickness	8 inches

9. Warranty and Support

Bellemave products are manufactured with quality and care. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Bellemave website. If you have any questions, require replacement parts, or need assistance with assembly, please contact Bellemave customer support.

Contact Information: Please refer to your purchase documentation or the Bellemave official website for the most current customer support contact details.

© 2026 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09QYQCGLR

More documents and user manuals: **https://manuals.plus/**