

[Manuals.plus](#) /

› [i-Star](#) /

› i-Star Digital Alarm Clock (Model B09R1X3Q58) Instruction Manual

i-Star B09R1X3Q58

i-Star Digital Alarm Clock (Model B09R1X3Q58) Instruction Manual

Your guide to setup, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the i-Star Digital Alarm Clock. This manual provides essential information for setting up, operating, and maintaining your new alarm clock. Please read it thoroughly before use and retain it for future reference.



Image 1.1: The i-Star Digital Alarm Clock, showcasing its clear display of time and temperature.

2. SAFETY INFORMATION

- Do not expose the device to water or excessive moisture.

- Avoid placing the device near heat sources or in direct sunlight.
- Use only the specified power adapter or batteries.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Please check that all items are present:

- i-Star Digital Alarm Clock
- USB Power Cable
- User Manual (this document)

4. PRODUCT FEATURES

The i-Star Digital Alarm Clock offers a range of features designed for convenience and functionality:

- **Digital Time Display:** Clear and easy-to-read LED display.
- **Multiple Alarms:** Set up to 3 independent alarms with customizable activation days (5, 6, or 7 days a week).
- **Snooze Function:** Allows for extra sleep after the alarm sounds.
- **Temperature Display:** Shows ambient temperature in Celsius (°C) or Fahrenheit (°F).
- **Calendar Display:** View the current date.
- **12/24 Hour Format:** Switch between standard and military time.
- **Dual Power Options:** Operates via USB power cable or 3x AAA batteries (not supplied).




Image 4.1: Visual representation of the clock's main features.

5. SETUP

5.1 Powering the Device

The i-Star Digital Alarm Clock can be powered in two ways:

- **USB Power:** Connect the provided USB cable to the clock's power input and plug the other end into a USB power adapter (not supplied) or a powered USB port. This is the recommended primary power source.
- **Battery Power:** For portability or backup, insert 3x AAA batteries (not supplied) into the battery

compartment. Note that battery power may dim the display to conserve energy.



MAINS OR BATTERY POWERED

Powered by the mains or 3x AAA batteries (not supplied), adding versatility & portability

Image 5.1: The alarm clock can be powered by a USB cable or AAA batteries.

5.2 Initial Time and Date Setting

Upon first power-up or after a power reset, you may need to set the correct time and date. Refer to the 'Operating Instructions' section for detailed steps.

6. OPERATING INSTRUCTIONS

The clock typically features buttons for 'SET', 'UP', 'DOWN', and 'ALARM' or similar. Specific button functions may vary slightly, but the general process is as follows:

6.1 Setting the Time and Date

1. Press and hold the **SET** button until the display flashes, indicating time setting mode.
2. Use the **UP** and **DOWN** buttons to adjust the hour. Press **SET** to confirm.
3. Repeat the process for minutes, year, month, and day.
4. Press **SET** again to exit the setting mode.

6.2 Setting Alarms

The clock supports up to 3 alarms (AL1, AL2, AL3).

1. Press the **ALARM** button repeatedly to cycle through AL1, AL2, AL3, and alarm off.
2. When an alarm (e.g., AL1) is displayed, press and hold the **ALARM** button until the alarm time flashes.
3. Use **UP** and **DOWN** to set the alarm hour, then press **ALARM** to confirm.
4. Repeat for alarm minutes.
5. Next, set the alarm activation days (e.g., 5 days for weekdays, 6 days for weekdays + Saturday, 7 days for everyday). Use **UP** and **DOWN**, then press **ALARM** to confirm.
6. To activate or deactivate an alarm, press the **ALARM** button briefly when the desired alarm is displayed. An indicator (e.g., 'AL1' icon) will appear or disappear.



MULTIPLE ALARMS

Up to 3 alarms that can be set to activate
on 5, 6, or 7 days of the week

Image 6.1: The clock supports multiple alarms for flexible scheduling.

6.3 Snooze Function

When an alarm sounds, press any button (often the 'SNOOZE' or 'SET' button) to activate the snooze function. The alarm will temporarily stop and sound again after a set interval (e.g., 5-10 minutes).

6.4 Temperature Display

The clock displays the ambient temperature. To switch between Celsius (°C) and Fahrenheit (°F), locate the dedicated temperature button or use a combination of existing buttons (e.g., press and hold **DOWN** in normal time display mode).




Image 6.2: The clock displays both time and temperature, with options for Celsius or Fahrenheit.

6.5 12/24 Hour Format

To switch between 12-hour (with AM/PM indicator) and 24-hour formats, press the **UP** button in normal time display mode, or refer to the specific button combination in your clock's quick start guide.

7. MAINTENANCE

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** If using batteries, replace all three AAA batteries simultaneously when the display dims or functions become erratic. Ensure correct polarity.
- **Storage:** If storing the clock for an extended period, remove the batteries to prevent leakage.

8. TROUBLESHOOTING

- **Display is blank:**
 - Ensure the USB power cable is securely connected to a working power source.
 - If using batteries, check if they are inserted correctly and are not depleted. Replace if necessary.
- **Alarm does not sound:**
 - Verify that the alarm is activated (check for the alarm icon on the display).
 - Ensure the alarm time is set correctly.
- **Incorrect time/date:**
 - Follow the 'Setting the Time and Date' instructions to reset.
- **Temperature reading seems inaccurate:**
 - Ensure the clock is not placed near a direct heat source or in direct sunlight, which can affect readings.

9. SPECIFICATIONS

Feature	Detail
Brand	i-Star
Model	B09R1X3Q58
Dimensions	15.8 x 9.7 x 9.09 cm
Weight	322 g
Display Type	Digital
Power Source	Electric Cable (USB), 3x AAA Batteries (not supplied)
Special Features	Alarm, Snooze, Calendar Display, Temperature Display

10. WARRANTY AND SUPPORT

This i-Star product is covered by a standard manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official i-Star website. Please have your model number (B09R1X3Q58) ready when contacting support.