

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [DELSEY PARIS](#) /
- › [DELSEY PARIS Chatelet 2.0 Travel Laptop Backpack Instruction Manual](#)

DELSEY PARIS 40167660115

DELSEY PARIS Chatelet 2.0 Travel Laptop Backpack Instruction Manual

Brand: DELSEY PARIS

Model: 40167660115

INTRODUCTION

The DELSEY PARIS Chatelet 2.0 Travel Laptop Backpack is designed for the modern traveler, combining timeless elegance with practical functionality. Crafted with eco-friendly materials and thoughtful organization, this backpack ensures your essentials are secure and easily accessible during your journeys.

KEY FEATURES

- **Durable, Eco-friendly Fabric:** Made with recycled water bottles and vegan leather-trim, featuring a stylish chevron pattern.
- **Multiple Compartments:** Main compartment with various pockets for organization, and a dedicated padded rear compartment for laptops and tablets.
- **Smart Band:** Integrated smart band on the back allows the backpack to slide over the tubes of wheeled luggage for easy transport.
- **Comfortable Carry:** Features a top handle for quick grab-and-go, padded shoulder straps, and a padded back panel for enhanced comfort during extended wear.
- **SILVADUR™ Technology:** Deluxe soft touch lining treated with SILVADUR™ technology for effective odor control.
- **Hidden Pockets:** Includes a hidden front pocket for quick access to small belongings, two side pockets, and a small hidden pocket on the rear for added security.
- **Removable Pouch:** Comes with a removable pouch, ideal for storing beauty essentials or tech accessories.

PRODUCT OVERVIEW



Figure 1: Front view of the DELSEY PARIS Chatelet 2.0 Travel Laptop Backpack, showcasing its elegant design and front pockets.



Figure 2: Angled view highlighting the backpack's contours and material texture.



Figure 3: Side profile of the backpack, showing its slim design.



Figure 4: Rear view, displaying the padded shoulder straps and back panel for comfort.



Figure 5: Main compartment opened, revealing multiple organizational pockets.



Figure 6: Dedicated padded rear compartment designed to securely hold a laptop or tablet.





Figure 7: Close-up of the smart band, allowing the backpack to be securely attached to luggage handles.



Figure 8: View of the discreet hidden pocket located on the back panel for valuables.

SETUP

1. **Unpack:** Remove the backpack from its packaging.
2. **Adjust Straps:** Adjust the padded shoulder straps to a comfortable length for carrying. Ensure the backpack sits securely on your back.
3. **Utilize Compartments:** Familiarize yourself with the various pockets and compartments. Place your laptop or tablet in the dedicated padded rear compartment. Use the main compartment and front pockets for other essentials, utilizing the smaller organizational pockets for pens, keys, and small items.
4. **Removable Pouch:** Decide whether to use the removable pouch for toiletries or tech accessories and place it in a convenient location within the main compartment or a front pocket.

OPERATING YOUR BACKPACK

- **Accessing Main Compartment:** Unzip the main zipper to access the spacious interior. Organize items using the internal pockets.
- **Laptop/Tablet Access:** The rear padded compartment is accessible via a separate zipper, allowing for quick and secure retrieval of your electronic devices.
- **Smart Band Usage:** For travel with wheeled luggage, slide the smart band located on the back panel over the extended handle of your suitcase. This secures the backpack on top of your luggage, easing transport.

- **Hidden Pockets:** Utilize the hidden front pocket and the small hidden rear pocket for items requiring extra security, such as passports, wallets, or phones.
- **Side Pockets:** The two side pockets are suitable for smaller items that need to be quickly accessible.

CARE AND MAINTENANCE

- **Cleaning:** For general cleaning, wipe the exterior with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Spot Treatment:** For stubborn stains, gently scrub the affected area with a soft brush and a small amount of diluted fabric cleaner. Rinse thoroughly and air dry.
- **Drying:** Allow the backpack to air dry completely before storing to prevent mildew. Do not machine wash or tumble dry.
- **Storage:** Store the backpack in a cool, dry place away from direct sunlight when not in use.
- **Zipper Care:** Periodically check zippers for smooth operation. If a zipper becomes stiff, apply a small amount of zipper lubricant or wax.

TROUBLESHOOTING

- **Zipper Sticking:** If a zipper is difficult to move, ensure no fabric is caught. Apply a small amount of graphite from a pencil or a specialized zipper lubricant to the teeth.
- **Stains:** Refer to the "Care and Maintenance" section for spot cleaning instructions. For severe stains, professional cleaning may be required.
- **Odor:** The lining is treated with SILVADUR™ technology to control odor. If odors persist, air out the backpack in a well-ventilated area. A sachet of baking soda can also help absorb odors.
- **Loose Stitching:** If you notice any loose stitching, it is recommended to have it repaired by a professional to prevent further damage.

SPECIFICATIONS

| Attribute | Value |
|--------------------|----------------------|
| Product Dimensions | 7 x 12.5 x 7 inches |
| Item Weight | 3.39 pounds |
| Department | unisex-adult |
| Manufacturer | Delsey Luggage, Inc. |
| ASIN | B09R2K9VCF |
| Item Model Number | 40167660115 |
| Capacity Total | 23 Liters |

WARRANTY AND SUPPORT

The DELSEY PARIS Chatelet 2.0 Travel Laptop Backpack comes with a warranty. Please refer to the warranty

manual included with your purchase for detailed information regarding coverage, terms, and conditions. For additional support or inquiries, please visit the official DELSEY PARIS website or contact their customer service.