

## Pipishell PIMF3

# Pipishell Full Motion TV Wall Mount Bracket User Manual

Model: PIMF3

### 1. PRODUCT OVERVIEW

The Pipishell Full Motion TV Wall Mount Bracket is designed to securely hold most 26-60 inch LED, LCD, and OLED flat or curved TVs weighing up to 77 lbs. This mount offers versatile viewing options with its dual articulating arms, allowing for swivel, extension, tilt, and rotation adjustments. It is engineered for robust support and ease of installation.



Image 1.1: The Pipishell Full Motion TV Wall Mount Bracket, showcasing its robust design and articulating arms.

## 2. COMPATIBILITY AND SPECIFICATIONS

This TV wall mount is compatible with a wide range of televisions and wall types. Please verify your TV's specifications and wall construction before installation.

- **TV Size Compatibility:** Most 26-60 inch TVs.
- **Weight Capacity:** Up to 77 lbs (35 kg).
- **VESA Compatibility:** Standard mounting holes from 100x100mm to 400x400mm.
- **Wall Types:** Suitable for 8" to 16" wood stud walls and concrete/brick walls.


## Confirm Before Purchase



Check VESA  
Max 400x400mm  
Min 100x100mm



TV Size 26-60"  
Holds up to 77LBS



Wall Types  
8"/16" Wood Studs  
Brick Wall/Concrete Wall



Potential Cable  
Blockage

Image 2.1: Visual guide for confirming TV and wall compatibility, including VESA patterns and weight limits.

### Detailed Specifications:

Specification	Value
Brand	Pipishell
Model Number	PIMF3
Item Weight	7.92 pounds
Product Dimensions	17.32 x 6.42 x 3.27 inches
Color	metal black
Material	Alloy Steel
Mounting Type	Wall Mount
Movement Type	Swivel, Articulating
Maximum Compatible Size	60 Inches
Minimum Compatible Size	26 Inches
Maximum Tilt Angle	-15 to +5 Degrees

### 3. KEY FEATURES

- **Full Motion Flexibility:** Swivels 45° left to right, tilts 5° up and 15° down, extends from 3" to 15.12" from the wall, and allows for  $\pm 3^\circ$  rotation adjustment for leveling.



Image 3.1: Adjustability features including tilt and extension, allowing for optimal viewing angles.

- **Heavy-Duty Construction:** Equipped with ultra-strong 6 arms made of alloy steel to securely hold your TV.



Image 3.2: Detail of the robust, heavy-duty steel arms designed for secure TV support.

- **Easy Leveling:** Post-installation  $\pm 3^\circ$  rotation adjustment ensures your TV is perfectly level.





Image 3.3: Illustration of the post-installation leveling feature for precise alignment.

## 4. INSTALLATION GUIDE

The Pipishell TV wall mount is designed for quick and easy installation. Follow these general steps. A detailed graphical installation guide is included with your product for specific instructions and hardware details.

### 1. Step 1: Attach TV Brackets

Secure the vertical TV brackets to the back of your television using the appropriate screws and spacers provided. Ensure the brackets are centered and firmly attached to your TV's VESA mounting holes.

### 2. Step 2: Install Wall Plate

Locate the desired mounting position on your wall. Use a stud finder to identify wood studs or mark drill points for concrete/brick walls. Securely attach the wall plate to the wall using the provided lag bolts and anchors. Ensure the wall plate is level before tightening all fasteners.


### 3. Step 3: Hang TV

Carefully lift your TV with the attached brackets and hook them onto the wall plate. Secure the TV to the wall

plate using the safety screws or locking mechanisms as per the detailed instructions.

## Fast & Easy Installation

Please contact our product support team if you have questions or need assistance.



**Step 1:**  
Attach TV Brackets



**Step 2:**  
Install Wall Plate



**Step 3:**  
Hang TV



Image 4.1: Simplified visual steps for installing the TV wall mount.

## 5. OPERATING INSTRUCTIONS

Once installed, your Pipishell Full Motion TV Wall Mount allows for flexible adjustment to optimize your viewing experience.

- **Swivel Adjustment:** Gently push or pull the TV to swivel it left or right up to 45 degrees. This allows you to direct the screen towards different seating areas.



Image 5.1: Demonstrating the 90-degree swivel capability for flexible viewing angles.

- **Tilt Adjustment:** Loosen the tilt knobs on the TV brackets, adjust the TV to your desired vertical angle (5° up to 15° down), and then re-tighten the knobs to secure the position. This helps reduce glare and optimize viewing from different heights.
- **Extension and Retraction:** Pull the TV gently away from the wall to extend it up to 15.12 inches, or push it back towards the wall to retract it to a slim 3 inches. This feature is useful for accessing cables or achieving a flush look.
- **Level Adjustment:** If your TV appears unlevel after installation, use the  $\pm 3^\circ$  rotation adjustment feature. Refer to your detailed manual for specific instructions on how to loosen and adjust the leveling screws, then re-tighten.

## 6. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your TV wall mount.



- **Cleaning:** Wipe the mount with a soft, dry cloth to remove dust. Avoid abrasive cleaners or solvents that could damage the finish.
- **Check Connections:** Periodically check all screws and bolts to ensure they remain tight, especially after initial installation and any significant adjustments.
- **Lubrication:** The articulating joints are designed for smooth movement. If any stiffness occurs over time, a small amount of silicone-based lubricant can be applied to the pivot points, avoiding contact with electrical components.

## 7. TROUBLESHOOTING

If you encounter any issues during or after installation, refer to the following common troubleshooting tips:

- **TV is not level:** Use the post-installation leveling adjustment feature ( $\pm 3^\circ$  rotation). Loosen the designated screws, adjust the TV until level using a spirit level, and then re-tighten the screws firmly.
- **Mount feels unstable:** Ensure all lag bolts securing the wall plate to the wall studs or concrete are fully tightened. Verify that the TV brackets are securely hooked onto the wall plate and the safety screws/locking mechanisms are engaged. Do not exceed the maximum weight capacity of 77 lbs.
- **Difficulty with movement (swivel/tilt/extension):** Check for any obstructions. Ensure no cables are snagged. For tilt, confirm the tilt knobs are sufficiently loosened before attempting to adjust, and re-tighten afterward. If movement remains stiff, apply a small amount of silicone lubricant to the articulating joints.
- **Input blocking:** If the mount or TV position blocks access to input ports, utilize the extension and swivel features to pull the TV away from the wall and angle it for better access. Consider using right-angle adapters for cables if space is extremely limited.

## 8. CUSTOMER SUPPORT AND WARRANTY






Pipishell is committed to providing excellent customer service. If you have any questions regarding compatibility, installation, or need assistance with your TV mount, please do not hesitate to contact our product support team.

While specific warranty details are not provided in this manual, please refer to the product packaging or the official Pipishell website for comprehensive warranty information and contact details.

For support, you can typically find contact information on the manufacturer's website or through the retailer where the product was purchased.

© 2024 Pipishell. All rights reserved.

This manual is for informational purposes only. Pipishell is not responsible for any damage or injury caused by incorrect installation or use of this product.

	<p><a href="#">Pipishell PIMFK3 Full Motion TV Wall Mount Instruction Manual</a></p> <p>Comprehensive instruction manual for the Pipishell PIMFK3 Full Motion TV Wall Mount. Learn how to safely install and adjust your TV mount for optimal viewing.</p>
	<p><a href="#">Pipishell TV Wall Mount Adjustment Troubleshooting Guide</a></p> <p>Troubleshoot common issues with your Pipishell full-motion TV wall mount, including how to adjust swivel angle and extension. Learn step-by-step solutions for stiff joints and movement problems.</p>
	<p><a href="#">Pipishell PISF1 Full-Motion TV Wall Mount Installation Guide</a></p> <p>Detailed installation guide for the Pipishell PISF1 Full-Motion TV Wall Mount. Covers safety, parts, and step-by-step assembly for VESA 200x200mm, 44 lbs capacity TVs.</p>
	<p><a href="#">Pipishell PILFK1 Full-Motion TV Wall Mount Instruction Manual</a></p> <p>Comprehensive installation guide for the Pipishell PILFK1 full-motion TV wall mount. Covers VESA compatibility, weight limits, wall type requirements, parts list, step-by-step assembly, safety information, and FAQs for TVs up to 132 lbs.</p>
	<p><a href="#">Pipishell PIMF7 Full-Motion TV Wall Mount Instruction Manual</a></p> <p>Comprehensive instruction manual for the Pipishell PIMF7 full-motion TV wall mount, covering installation, safety, compatibility, and adjustment for TVs up to 77 lbs.</p>



[Pipishell PIMF3 TV Wall Mount Installation Instructions](#)

Detailed installation instructions for the Pipishell PIMF3 TV wall mount, covering safety information, tools needed, parts list, and step-by-step mounting procedures for both wood stud and concrete installations. Includes VESA measurement and TV screw compatibility checks.