

[Manuals.plus](#) /

> [G-Ocean](#) /

> G-Ocean 45 Inch Tower Fan User Manual

G-Ocean GFTF5501-US

G-Ocean 45 Inch Oscillating Tower Fan User Manual

Model: GFTF5501-US | Brand: G-Ocean

1. INTRODUCTION

Thank you for choosing the G-Ocean 45 Inch Oscillating Tower Fan. This bladeless fan is designed to provide efficient and quiet cooling for your home or office, featuring multiple speed and mode settings, a convenient 24-hour timer, and an intuitive LED display. Please read this manual thoroughly before operation to ensure proper use and maintenance.



Figure 1: G-Ocean 45 Inch Tower Fan with Remote Control.

2. PACKAGE CONTENTS

- Fan Base x1
- User Manual x1
- Remote Control x1

3. SETUP

Follow these steps to assemble and prepare your tower fan for use:

1. Carefully remove all components from the packaging.
2. Assemble the two-piece fan base by aligning the halves and clicking them together.
3. Unscrew the bottom of the fan unit and fit it securely into the assembled base. Tighten the screws to ensure stability.
4. Place the fan on a flat, stable surface.
5. Plug the power cord into a standard 120V AC outlet. Ensure the safety plug is fully inserted.



Figure 2: Assembly of the fan base. The base consists of two halves that snap together, and the fan unit is then secured to the base with screws.

4. OPERATING INSTRUCTIONS

Control Panel & LED Display

The fan features a touch-sensitive control panel on top and an LED display showing current settings and room temperature.

PERFECT PARTNER - AIR CONDITIONER

More Efficient Cooling



Save energy



Figure 3: Close-up of the G-Ocean Tower Fan's touch control panel and LED display, showing temperature and settings.

- **Power Button:** Press to turn the fan On/Off.
- **Speed Button:** Cycles through 3 fan speeds (Low, Medium, High).
- **Mode Button:** Cycles through 3 modes (Normal, Natural, Sleep).
- **Oscillation Button:** Activates/deactivates 60° oscillation.
- **Timer Button:** Sets the auto-off timer from 1 to 24 hours.
- **LED Display:** Shows current room temperature and active settings. The LED display automatically turns off after 3 minutes in sleep mode.

Remote Control

The included remote control allows convenient operation from a distance.

COOLER THAN EVER

Extra large size design, cool breeze wrapped around the whole body.



G-OCEAN

OTHERS




Figure 4: The remote control for the G-Ocean Tower Fan, featuring buttons for power, speed, mode, oscillation, timer, and LED display control.

- All functions available on the control panel are also accessible via the remote.
- Ensure the remote has working batteries (not included) for operation.

Modes Explained

- **Normal Mode:** Provides a consistent airflow at the selected speed.
- **Natural Mode:** Simulates natural wind by varying fan speed intermittently.
- **Sleep Mode:** Gradually adjusts airflow and dims the LED display after 3 minutes for undisturbed sleep.

Video Demonstration: Operating the Fan

Your browser does not support the video tag.

Video 1: A detailed review and demonstration of the G-Ocean Tower Fan's features, including its quiet operation and cooling capabilities. (Creator: Real Reviews with Steph)

5. SAFETY INFORMATION

For your safety and to prevent damage to the product, please observe the following:

- The bladeless design ensures safety, especially for households with children, preventing fingers from entering the fan.
- The fan is ETL certified and includes a safety plug to protect against voltage overload and surge damage.
- Do not insert any objects into the fan grille.
- Always unplug the fan before cleaning or moving it.
- Keep the fan away from water or excessive moisture.

6. MAINTENANCE

Regular cleaning will help maintain the fan's performance and longevity:

- Ensure the fan is unplugged before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Periodically clean the air intake and outlet grilles to prevent dust buildup, which can affect airflow.

7. TROUBLESHOOTING

If you encounter issues with your G-Ocean Tower Fan, refer to the following common solutions:

Problem	Possible Cause & Solution
Fan does not turn on.	Ensure the power cord is securely plugged into a working outlet. Check for power outages.
Remote control is not working.	Check if batteries are correctly inserted or need replacement. Ensure there are no obstructions between the remote and the fan.
Weak airflow.	Clean the air intake and outlet grilles. Ensure the fan is not obstructed. Increase fan speed.
Unusual noise.	Ensure the fan is placed on a flat, stable surface. Check for any foreign objects near the grilles.

8. SPECIFICATIONS

Feature	Detail
Brand	G-Ocean
Model Name	GFTF5501-US
Product Dimensions	6"D x 6"W x 45"H
Item Weight	10.18 pounds (4.63 Kilograms)
Power Source	AC
Voltage	120 Volts
Wattage	55 watts
Air Flow Capacity	211 Cubic Feet Per Minute
Oscillation Angle	60°
Control Method	Remote, Touch
Number of Power Levels	3
Special Features	24 Hour Timer, LED Display, Bladeless Design
Safety Certification	ETL Certified

9. WARRANTY & SUPPORT

G-Ocean offers a **1-year manufacturer warranty** with your purchase of this fan. If you need any help or have questions, please feel free to contact us.

For a detailed PDF version of this manual, please visit: [User Manual \(PDF\)](#)