

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bioby](#) /

› [Bioby Electric Baby Swing User Manual](#)

Bioby POA8202219

Bioby Electric Baby Swing User Manual

Model: POA8202219

Brand: Bioby



INTRODUCTION

The Bioby Electric Baby Swing is designed to provide a safe, comfortable, and engaging environment for infants. Featuring multiple swing speeds, built-in music, Bluetooth connectivity, and a remote control, this portable baby swing aims to offer hands-free parenting convenience while ensuring your baby's well-being. It includes a 5-point harness for security and a removable mosquito net for protection.

IMPORTANT SAFETY INFORMATION

Please read all instructions before assembly and use of the baby swing. Keep this manual for future reference. Failure to follow these warnings and instructions could result in serious injury or death.

- **WARNING:** Never leave child unattended.
- **WARNING:** Do not use this product once your child can sit up unaided or weighs more than 20 lbs (9 kg).
- **WARNING:** This product is not intended for prolonged periods of sleep.
- **WARNING:** Always use the restraint system. Ensure the harness is properly adjusted and secured.
- **WARNING:** Do not move or lift the product with the child inside.
- **WARNING:** Keep small parts away from children.
- Ensure the swing is placed on a flat, stable surface.
- Do not use near stairs or steps.
- Regularly inspect the product for loose parts, damaged components, or torn materials. Discontinue use if any damage is found.

PACKAGE CONTENTS

Verify that all components are present before assembly:

- Main Swing Unit (Base and Seat Frame)
- Seat Cover & Pillow
- Canopy with Mosquito Net
- Hanging Toys (Star and Moon)

- Remote Control
- Power Adapter (USB cable and wall adapter)
- User Manual (this document)

SETUP AND ASSEMBLY

Follow these steps to assemble your Bioby Electric Baby Swing:

1. Assemble the Base Bracket:

Insert the two curved base pieces into the central motor unit until they click securely into place. Ensure they are fully seated and stable.



Image: Step-by-step visual guide for assembling the base bracket.

2. Attach the Seat Frame:

Align the seat frame with the top of the assembled base. Push down firmly until it locks into position. You should hear a click indicating it's secure.

3. Install Seat Cover & Pillow:

Slide the fabric seat cover over the seat frame, ensuring it fits snugly. Secure the cover using the zippers and Velcro straps

located on the underside and back of the seat. Attach the head pillow to the top ring of the seat with its Velcro.




Image: Detailed steps for attaching the seat cover and head pillow.

4. Attach the Canopy with Toys:

Fasten the canopy clasps to the designated points on the seat frame pipe. The canopy includes a removable mosquito net. To attach the mosquito net, tie the small Velcro strap around the swivel part of the swing, ensuring it covers the opening completely. You can also hang the two included toys (star and moon) from the canopy bar.



Image: The fully assembled swing, demonstrating the canopy and hanging toys.

5. Connect Power:

Plug the power adapter into the swing's power port and then into a standard electrical outlet. The swing can also be powered by a power bank for portable use.

OPERATING INSTRUCTIONS

The Bioby Electric Baby Swing can be operated via the touch screen panel on the base or the included remote control.

Control Panel Functions:

- **Power Button:** Turns the swing on/off.
- **Swing Speed Buttons:** Adjusts between 5 gentle swing speeds.
- **Timer Buttons:** Sets the swing timer for 8, 15, or 30 minutes.
- **Music/Sound Buttons:** Selects from 8 preset melodies or natural sounds.
- **Bluetooth Button:** Activates Bluetooth for playing custom music from your device.
- **Volume Control:** Adjusts the audio volume.

Remote Control Functions:

The remote control duplicates most functions of the touch panel for convenient operation from a distance.



Image: Layout and functions of the remote control.

- **Power (Red Button):** Turns the swing on/off.
- **Music (Blue Button):** Toggles music playback.
- **Timer (Green Button):** Cycles through timer settings (8, 15, 30 minutes).
- **Volume Up/Down:** Adjusts music volume.
- **Next/Previous Song:** Skips between preset melodies.
- **Swing Speed (1-5 Buttons):** Directly selects swing speed.
- **AUTO (Yellow Button):** Activates automatic swing mode.
- **STOP (Orange Button):** Stops the swing motion.

Bluetooth Connectivity:

To connect your device via Bluetooth, press the Bluetooth button on the control panel or remote. Search for "Bioby Swing" on your device's Bluetooth settings and pair. Once connected, you can play your baby's favorite lullabies or sounds directly through the swing's speaker.

MAINTENANCE

Proper maintenance ensures the longevity and safety of your Bioby Electric Baby Swing.

- **Cleaning the Fabric:** The seat cushion is removable and machine-washable. Use a gentle cycle with cold water and mild detergent. Air dry or tumble dry on low heat. Do not bleach.



Image: Demonstrating the ease of removing the seat cover for cleaning.

- **Cleaning the Frame:** Wipe down the plastic and metal parts of the frame with a damp cloth and mild soap. Do not immerse the base unit in water.
- **Storage:** When not in use, the swing can be easily detached and folded for compact storage. Store in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

If you encounter issues with your Bioby Electric Baby Swing, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Swing does not turn on.	Not plugged in; power adapter issue.	Ensure power adapter is securely plugged into the swing and a working outlet. Try a different outlet.
Swing motion is weak or inconsistent.	Low power; weight exceeds limit; obstruction.	Ensure the swing is properly powered. Verify child's weight is within the 20 lbs limit. Check for any obstructions around the swing mechanism.
Bluetooth not connecting.	Device too far; swing not in pairing mode.	Ensure your device is within range. Press the Bluetooth button on the swing or remote to activate pairing mode. Restart both devices.
Remote control not working.	Battery depleted; obstruction.	Replace the CR2032 battery in the remote control. Ensure no objects are blocking the signal between the remote and the swing.

SPECIFICATIONS

- Product Dimensions:** 27.6"D x 24.4"W x 27.6"H
- Item Model Number:** POA8202219
- Maximum Weight Recommendation:** 20 Pounds
- Material Type:** Aluminum (frame), Polycotton (fabric)
- Power Source:** Battery Powered (CR2032 for remote, included) / AC Adapter (5V/1A output)
- Item Weight:** 7.27 Pounds
- Features:** 5 Swing Speeds, 3 Timer Options (8/15/30 mins), 8 Preset Music/Sounds, Bluetooth, Touch Screen/Remote Control, 5-Point Harness, Removable Mosquito Net, Portable.

WARRANTY AND SUPPORT

Bioby products are manufactured with high-quality materials and craftsmanship. For warranty information, technical support, or to purchase replacement parts, please contact Bioby customer service. Refer to the official Bioby website or the original product packaging for the most current contact details.

You can also find additional support and resources by visiting the [Bioby Store on Amazon](#).

A digital version of the user guide is available at: [User Guide \(PDF\)](#)

© 2023 Bioby. All rights reserved.

Related Documents - POA8202219

	Bioby BB008H Electric Baby Swing User Manual Comprehensive user manual for the Bioby BB008H Electric Baby Swing, detailing features, operation, safety guidelines, and specifications for this portable baby rocker chair with Bluetooth music and remote control.
---	---

	<p>Bioby BB006H Multi-Function Electric Swing User Manual</p> <p>Comprehensive user manual for the Bioby BB006H Multi-Function Electric Swing, detailing product specifications, assembly instructions, user operation, safety warnings, maintenance, and troubleshooting. Learn how to safely assemble, operate, and care for your baby swing.</p>
	<p>bioby BB501 Multi-Function Electric Swing User Manual - Setup, Operation & Safety</p> <p>Official user manual for the bioby BB501 Multi-Function Electric Swing. Find detailed instructions on assembly, operation, cleaning, maintenance, troubleshooting, and safety precautions for your baby's comfort and security.</p>
	<p>Bioby BB006H Multi-Function Electric Swing User Manual</p> <p>Comprehensive user guide for the Bioby BB006H Multi-Function Electric Swing. Covers product features, installation, operation, safety guidelines, cleaning, maintenance, and troubleshooting.</p>
	<p>Bioby Portable Bottle Warmer User Manual - Model N1</p> <p>Comprehensive user manual for the Bioby Portable Bottle Warmer (Model N1), covering setup, operation, safety precautions, troubleshooting, and maintenance. Learn how to use your bottle warmer for fast, accurate temperature control.</p>