

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [La Crosse Technology](#) /
- › [La Crosse Technology LW3101 Wi-Fi Weather Station User Manual](#)

La Crosse Technology LW3101

La Crosse Technology LW3101 Wi-Fi Weather Station User Manual

Model: LW3101

INTRODUCTION

Thank you for choosing the La Crosse Technology LW3101 Wi-Fi Weather Station. This manual provides detailed instructions to help you set up, operate, and maintain your device, ensuring you get the most accurate weather information and forecasts.

PRODUCT FEATURES

- **Time & Date:** Displays current time and date with language selection and 12/24 hour format options.
- **Internet Weather Forecasts:** Provides 3-day forecasts at a glance, including 12-hour and 6-day outlooks, predicted weather conditions, and precipitation percentages.
- **Indoor/Outdoor Temperature & Humidity:** Displays readings in Celsius or Fahrenheit.
- **Alerts & Data Logging:** Features alerts and recording for indoor and outdoor data.
- **Heat Index & Dew Point:** Calculates and displays heat index and dew point values.
- **Atmospheric Pressure:** Shows atmospheric pressure with 5 trend arrows.
- **Wi-Fi Connectivity:** Connects to the La Crosse View application for additional forecast icons, daily min/max values, and rain probabilities on the screen.
- **Expandable Sensors:** Allows for the addition of supplementary sensors.
- **Adjustable Backlight:** Features adjustable or automatic backlight with an auto-dim function.
- **Low Battery Indicator:** Provides indicators for low battery levels for both the station and its sensor.

PACKAGE CONTENTS

The La Crosse Technology LW3101 Wi-Fi Weather Station package includes:

- 1 x LW3101 Weather Station
- 1 x Instruction Manual
- *Note: Batteries are not included and are required for operation.*

SETUP

1. Initial Setup

1. **Power On:** Insert the required batteries (not included) into the weather station and the outdoor sensor. Ensure correct polarity.
2. **Sensor Placement:** Place the outdoor sensor in a shaded area, protected from direct sunlight and rain, to ensure accurate temperature and humidity readings.
3. **Station Placement:** Position the main weather station indoors, away from direct heat sources or vents, for accurate indoor readings.

2. Wi-Fi Connection

To access internet-based forecasts and advanced features, connect your LW3101 to your home Wi-Fi network using the La Crosse View application.

1. **Download App:** Download the "La Crosse View" app from your smartphone's app store.
2. **Create Account:** Open the app and follow the on-screen instructions to create a new account or log in.
3. **Add Device:** In the app, select "Add Device" and choose your LW3101 model.
4. **Follow Prompts:** The app will guide you through connecting your weather station to your Wi-Fi network. Ensure your phone is connected to the 2.4GHz band of your Wi-Fi router during setup.



Image: The La Crosse Technology LW3101 weather station display showing current weather data and forecasts, alongside a smartphone screen displaying the La Crosse View application with detailed weather information.

OPERATING INSTRUCTIONS

1. Display Overview

The main display shows various information:

- **Top Section:** Internet weather forecasts (3-day, 12-hour, 6-day outlooks).
- **Middle Section:** Indoor and outdoor temperature/humidity, heat index, dew point.
- **Bottom Section:** Atmospheric pressure, time, and date.

2. Time and Date Settings

Once connected to Wi-Fi, the time and date will automatically synchronize. You can adjust the language and 12/24 hour format through the device settings or the La Crosse View app.

3. Weather Forecast Display

The station receives weather forecasts via the internet. The display will show icons representing predicted conditions, along with temperature ranges and precipitation probabilities for the coming days.

4. Temperature and Humidity Readings

The station displays both indoor and outdoor temperature and humidity. Ensure the outdoor sensor is properly placed for accurate external readings.




Image: A smartphone screen displaying the La Crosse View application, showing a detailed graph of temperature fluctuations over several hours, along with current temperature and humidity readings.

5. Alerts

You can set customizable alerts for temperature and humidity thresholds through the La Crosse View app. The station will notify you when these thresholds are met.

6. Backlight Adjustment

The display backlight can be adjusted manually or set to an automatic dimming function for comfortable viewing in various lighting conditions.

MAINTENANCE

1. Battery Replacement

When the low battery indicator appears on the display for either the main station or the outdoor sensor, replace the batteries promptly with new ones of the specified type. Ensure correct polarity during replacement.

2. Cleaning

Clean the weather station and sensor with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the display or casing. Keep the devices dry.

TROUBLESHOOTING

- **No Display/Power:** Check battery installation and ensure they are fresh. If using an AC adapter (if applicable, not specified here), ensure it is properly connected.
- **No Outdoor Sensor Data:** Ensure the outdoor sensor is within range of the main station and has fresh batteries. Try re-pairing the sensor according to the app instructions.
- **Inaccurate Forecasts:** Verify your Wi-Fi connection is stable. Internet-based forecasts rely on external data sources; minor discrepancies may occur.
- **Wi-Fi Disconnection:** Check your home Wi-Fi network. Restart your router and the weather station. Reconnect through the La Crosse View app if necessary.
- **Display Segments Missing:** This could indicate a hardware issue. Contact customer support if troubleshooting steps do not resolve the problem.

SPECIFICATIONS

Manufacturer	La Crosse Technology
Model Number	LW3101-MEG
Package Dimensions	20.9 x 17.1 x 7.9 cm; 600 grams
Color	Grey
Style	Modern
Material	Metal or Plastic
Power Source	Battery Powered
Number of Items in Package	1
Measurement Accuracy	+/-1°C
Display Type	LED
Special Features	Wireless, Wi-Fi Connectivity
Components Included	Instruction Manual
Batteries Included	No
Batteries Required	Yes

WARRANTY INFORMATION

Specific warranty details for the La Crosse Technology LW3101 are not provided in this manual. Please refer to the warranty card included with your product or visit the official La Crosse Technology website for the most up-to-date warranty information.

SUPPORT

For technical assistance, troubleshooting, or further inquiries regarding your La Crosse Technology LW3101 Wi-Fi Weather Station, please visit the official La Crosse Technology support website or contact their customer service department. Contact information can typically be found on the manufacturer's website or on the product packaging.

