

[Manuals.plus](#) /

› [Briloner](#) /

› BRILONER 4025-045 Textile Pendant Light Instruction Manual

Briloner 4025-045

BRILONER 4025-045 Textile Pendant Light

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the BRILONER 4025-045 Textile Pendant Light. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before beginning installation and retain them for future reference.

Product Overview

The BRILONER 4025-045 is a modern 4-light pendant fixture designed for indoor use, featuring a matte black metal body and four fabric shades in black, grey, and white. It uses E27 bulbs (not included) allowing for personalized light selection.



Image: The BRILONER 4025-045 pendant light, highlighting its four E27 bulb bases.



Image: The pendant light installed above a dining table, showcasing its aesthetic in a home environment.

2. Safety Instructions

- **Electrical Safety:** Always disconnect the main power supply before installation, maintenance, or bulb replacement. If you are unsure about electrical wiring, consult a qualified electrician.
- **Indoor Use Only:** This fixture has an IP20 rating, meaning it is protected against solid objects larger than 12.5mm but has no protection against water. It is designed exclusively for indoor use in dry locations. Do not expose to moisture or water.
- **Bulb Specifications:** Use only E27 bulbs with a maximum wattage of 40W per socket. Exceeding this limit can cause overheating and damage to the fixture or create a fire hazard.
- **Secure Mounting:** Ensure the ceiling structure can safely support the weight of the fixture (approximately 1.3 kg).
- **Handling:** Handle the fixture and bulbs with care to prevent damage.

3. Package Contents

Carefully unpack the box and ensure all components are present and undamaged. If any parts are missing or damaged, do not proceed with installation and contact your retailer.

Included in the Box:

- 1 x BRILONER 4025-045 Pendant Light fixture (including metal body and 4 fabric shades)
- Mounting hardware (screws, wall plugs, ceiling bracket)

Not Included (Required for Operation):

- 4 x E27 light bulbs (max. 40W each)



Image: A detailed view of the four fabric shades (two black, one grey, one white) and the matte black metal bar.

4. Setup and Installation

Tools Required (not included): Screwdriver, drill, wire strippers, voltage tester, pencil, measuring tape.

Pre-Installation:

1. **Turn off Power:** Locate the circuit breaker for the area where you will install the light and turn off the power. Verify the

power is off using a voltage tester.

2. **Determine Mounting Location:** Choose a suitable location on the ceiling. Consider the fixture's dimensions (740mm Length x 1200mm Height) to ensure adequate clearance.



Image: The pendant light shown with its overall dimensions: 740mm length and 1200mm height.

Installation Steps:

1. **Attach Ceiling Bracket:** Secure the provided mounting bracket to the ceiling using the screws and wall plugs. Ensure it is firmly attached to a joist or appropriate ceiling support.
2. **Wire Connections:** Connect the electrical wires from your ceiling to the fixture's wires. Typically, this involves connecting:
 - Live (L) wire (usually brown or black) to the fixture's live wire.
 - Neutral (N) wire (usually blue) to the fixture's neutral wire.
 - Earth (E) wire (usually green/yellow) to the fixture's earth wire.

Use appropriate terminal blocks or wire connectors and ensure all connections are secure.

- 3. **Mount the Fixture:** Carefully lift the fixture and attach it to the ceiling bracket, securing it with the provided screws. Ensure no wires are pinched.
- 4. **Install Bulbs:** Screw four E27 bulbs (max 40W each, not included) into the sockets. Do not overtighten.
- 5. **Restore Power:** Once installation is complete and all connections are secure, turn the main power supply back on.

5. Operating Instructions

The BRILONER 4025-045 pendant light is operated via a standard wall switch connected to your household electrical circuit. There is no integrated switch on the fixture itself.

- **Turning On/Off:** Use your existing wall switch to turn the light fixture on or off.
- **Bulb Selection:** Since bulbs are not included, you have the flexibility to choose E27 bulbs that best suit your needs in terms of light color (warm white, cool white, daylight) and brightness, as long as they do not exceed 40W per socket. Compatible bulb types include LED, incandescent, and halogen.

6. Maintenance

Cleaning:

- Always disconnect power before cleaning.
- Wipe the metal parts with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- For the fabric shades, gently dust with a soft brush or a dry cloth. Avoid using wet cloths or liquid cleaners on the fabric.

Bulb Replacement:

- Ensure the power is off and the bulbs have cooled down completely before attempting to replace them.
- Carefully unscrew the old E27 bulb and screw in the new E27 bulb (max 40W).

7. Troubleshooting

- **Light does not turn on:**
 - Check if the power supply is on at the circuit breaker.
 - Ensure the wall switch is in the 'ON' position.
 - Verify that the bulbs are correctly screwed in and not faulty. Replace with new bulbs if necessary.
 - Check electrical connections for loose wires (ensure power is off before inspecting).
- **Light flickers:**
 - Ensure bulbs are fully screwed into their sockets.
 - Try different bulbs to rule out faulty bulbs.
 - Check for loose wiring connections (ensure power is off before inspecting).

If you experience persistent issues, please contact a qualified electrician or your retailer for assistance.

8. Specifications

Attribute	Specification
-----------	---------------

Brand	Briloner
Manufacturer	Briloner Leuchten
Model Number	4025-045
Product Dimensions (L x W x H)	740 mm x 70 mm x 1200 mm
Item Weight	1.3 Kilograms
Material	Metal (body), Textile (shades)
Color	Black/Grey/White (2x black, 1x grey, 1x white shades)
Number of Lights	4
Socket Type	E27
Max Wattage per Bulb	40W
Voltage	230 Volts
IP Rating	IP20 (Indoor use only)
Installation Type	Ceiling Mount
Included Components	1 pendant lamp
Bulbs Included	No
Country of Origin	China

9. Warranty and Support

Specific warranty details for the BRILONER 4025-045 Textile Pendant Light are not provided in this document. For warranty information, please refer to the documentation included with your purchase or contact your retailer directly.

For technical support or inquiries regarding your product, please contact Briloner Leuchten customer service through their official website or the contact information provided by your point of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09R6RC3VN>

More documents and user manuals: <https://manuals.plus/>