

[Manuals.plus](#) /

> [TCL](#) /

> TCL 75" Class 4-Series 4K UHD HDR Smart Roku TV User Manual

TCL 75S455

TCL 75" Class 4-Series 4K UHD HDR Smart Roku TV User Manual

Model: 75S455 | Brand: TCL

INTRODUCTION

This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your TCL 75" Class 4-Series 4K UHD HDR Smart Roku TV (Model: 75S455). This television offers stunning 4K picture quality with four times the resolution of Full HD, enhanced clarity, and detail. High Dynamic Range (HDR) technology delivers bright and accurate colors for a lifelike viewing experience. With Roku TV, you gain access to thousands of streaming channels and a simple, customizable home screen for all your entertainment needs.



Figure 1: Front view of the TCL 75-inch 4K UHD HDR Smart Roku TV.



Figure 2: The TCL 75-inch 4K UHD HDR Smart Roku TV on a media console.

WHAT'S IN THE BOX


Upon opening your TCL TV package, ensure all the following components are present:

- TCL Roku TV (75S455)
- Power Cable
- Remote Control
- 2x Remote Control Batteries (AAA)
- TV Stands (2 pieces)
- Quick Start Guide
- User Guide (this manual)

TCL

75" Class (74.5" diag.)

4-Series | 75S455



Dimensions:

TV with Stand:
65.7" x 40.2" x 13.5"

TV without Stand:
65.7" x 37.8" x 3.6"

What's in the Box:

- TCL Roku TV
- TV Stands
- Power Cable
- TV Remote + Batteries
- Quick Start Guide

*Features and specifications subject to change.
*Actual remote has pre-set channel buttons.
Channels can vary by country.

Figure 3: Package contents and TV dimensions overview.

SETUP

1. Unpacking and Placement

Carefully remove the TV from its packaging. It is recommended to have two people for this process due to the TV's size and weight. Place the TV on a stable, flat surface or prepare for wall mounting.

2. Attaching the Stands (Optional)

If you are not wall-mounting the TV, attach the included stands. Align each stand with the corresponding screw holes on the bottom of the TV. Secure them firmly with the provided screws. Ensure the stands are properly seated and the TV is stable before proceeding.







Figure 4: Detail of the TV stand attachment.

3. Connecting Devices

Your TCL Roku TV offers various input ports for connecting external devices such as cable boxes, gaming consoles, Blu-ray players, and sound systems. Refer to the image below for common port locations.

- **HDMI Ports:** For high-definition audio and video devices.
- **USB Port:** For connecting USB storage devices to view media.
- **Ethernet Port:** For a wired internet connection.
- **RF Input:** For connecting an antenna or cable TV.
- **Optical Digital Audio Out:** For connecting to a soundbar or audio receiver.





Figure 5: Side view of the TV's input ports.

4. Power Connection

Connect the power cable to the TV's power input and then plug it into a wall outlet. The TV will enter standby mode.

5. Initial Setup (Roku TV)

Upon first power-on, the TV will guide you through the Roku TV setup process. This includes selecting your language, connecting to a Wi-Fi network (or using Ethernet), and activating your Roku account. Follow the on-screen prompts to complete the setup.

OPERATING YOUR TV

1. Remote Control Functions

The included remote control is designed for simplicity, with fewer buttons than traditional TV remotes. Key functions include navigation (directional pad), Home, Back, Options (*), Play/Pause, Fast Forward, Rewind, and dedicated shortcut buttons for popular streaming channels.

2. Roku TV Home Screen

The Roku TV home screen provides centralized access to all your entertainment. You can easily switch between broadcast TV, streaming channels, gaming consoles, and other connected devices. The interface is customizable, allowing you to arrange your favorite channels and inputs.

Simple, Customizable Home Screen

Easy by design



Figure 6: The Roku TV home screen interface.

3. Streaming and Entertainment

Access a vast library of content through the Roku platform. This includes free TV, live news, sports, movies, and over 250 live TV channels, award-winning Roku Originals, and more. Explore the Roku Channel Store to add new streaming services.

Roku TV

Endless entertainment




Figure 7: Examples of content available on Roku TV.

4. Voice Control and Mobile App

The TCL Roku TV supports voice control through popular voice assistants like Alexa and Google Assistant, allowing for hands-free operation. Additionally, the Roku mobile app transforms your smartphone into a full-function Roku remote, offering convenient search, private listening, and more.

Easy Voice Control
Say it. Play it.


Easy Voice Control
Works with popular voice assistants




Figure 8: Easy Voice Control with Roku TV.

Powerful Mobile App

The must-have app for streamers



Figure 9: The powerful Roku mobile app for streamers.

MAINTENANCE

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a screen-specific cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Cabinet:** Use a soft, dry cloth to clean the TV cabinet. Do not use liquid cleaners or sprays directly on the TV.
- **Software Updates:** Ensure your TV is connected to the internet to receive automatic software updates. These updates provide new features, performance improvements, and bug fixes. You can check for updates manually via the Settings menu on your Roku TV.
- **Ventilation:** Ensure adequate ventilation around the TV. Do not block the ventilation openings on the back or sides of the TV.

TROUBLESHOOTING

If you encounter issues with your TCL Roku TV, refer to the common problems and solutions below. For more complex issues, consult the official TCL support resources.

Problem	Possible Solution
No Power	Ensure the power cable is securely connected to both the TV and a working electrical outlet. Try a different outlet.
No Picture, But Has Sound	Check input source (HDMI, AV, etc.). Ensure all cables are securely connected. Try restarting the TV.
No Sound, But Has Picture	Check volume level and mute status. Verify audio output settings (TV speakers, external audio system). Check audio cables.
Remote Control Not Working	Replace batteries. Ensure no obstructions between remote and TV. Re-pair the remote if it's a Roku Voice Remote.
Cannot Connect to Wi-Fi	Verify Wi-Fi password. Restart your router and modem. Move the TV closer to the router or use a wired Ethernet connection.
Picture Quality Issues (Blurry, Distorted)	Check source resolution. Ensure cables are high-quality and properly connected. Adjust picture settings (brightness, contrast, sharpness).

SPECIFICATIONS

Feature	Detail
Brand	TCL
Model Number	75S455
Screen Size	75 Inches (191 cm diagonal)
Display Technology	LED
Resolution	4K Ultra HD (3840 x 2160)
High Dynamic Range (HDR)	Supported
Refresh Rate	120 Hz
Smart TV Platform	Roku TV
Connectivity	Wi-Fi, Ethernet, HDMI, RF, USB
Audio Output	15 Watts (Built-In Speakers)
Product Dimensions (with stand)	3.6"D x 65.7"W x 37.8"H

Feature	Detail
Item Weight	47.9 pounds
Energy Consumption	225 kWh per year (estimated)

ADDITIONAL RESOURCES

For more detailed information and specific guides, please refer to the official PDF documents:

- [Installation Manual \(PDF\)](#)
 - [User Manual \(PDF\)](#)
 - [User Guide \(PDF\)](#)
-

WARRANTY AND SUPPORT

Your TCL 75S455 TV comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical support, service inquiries, or to register your product, please visit the official TCL support website or contact their customer service line. Keep your purchase receipt and product serial number handy for any warranty claims.

For the latest support information, visit the [TCL Store on Amazon](#).