

Prominence Home 51633-01

Prominence Home Guyanna 62-Inch LED Ceiling Fan User Manual

Model: 51633-01

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Prominence Home Guyanna 62-inch LED Ceiling Fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

The Guyanna ceiling fan features soft-toned blades and an energy-efficient LED light. It includes a remote control for adjusting lighting and fan speed. The centralized light is fully dimmable and can operate independently of the fan.



Downrod

Built for standard ceiling heights - adaptable for taller ceilings with longer downrod (sold separately).

Angled

Sloped or vaulted ceilings may require angle mounting.

Image: Overview of the Prominence Home Guyanna 62-inch indoor ceiling fan, highlighting its espresso motor finish, 5 blades, powerful 3-speed airflow, and 3000K color temperature LED light.

SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always turn off power at the main circuit breaker or fuse box before installation or servicing. Ensure all electrical connections comply with local codes and ordinances. If you are unsure about wiring, consult a qualified electrician.

This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

Ensure the mounting structure can support the weight of the fan. All wiring must be in accordance with national and local electrical codes. The fan is designed for indoor use only.




Image: Illustration showing compliance with safety standards, including ETL, DOE, CA CEPA, CARB, and CEC regulations, indicating the product has been safety tested.

PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- Blade Irons
- Blades (5 Hand Carved Wood Blades)
- Hardware Pack
- Light Kit (Integrated LED)
- Owner's Manual
- Remote Control with Wall Dock

SETUP AND INSTALLATION

Before installation, ensure the power is disconnected at the circuit breaker. This fan is designed for hardwired installation. Follow the detailed wiring diagrams provided in the included owner's manual for proper electrical connections.

Mounting Options

The Guyanna fan supports dual mounting options: downrod mount for standard ceiling heights and angled mount for sloped or vaulted ceilings. A longer downrod may be required for taller ceilings (sold separately).



Image: Diagram illustrating the product dimensions, including a 62-inch blade span and 14.1 inches from the ceiling to the bottom of the blades.

Room Size Recommendation

For optimal performance, consider the size of your room when installing the fan. This 62-inch fan is suitable for large rooms up to 360 square feet.



Image: A guide recommending fan sizes based on room dimensions: Small Room (less than 8 ft x 10 ft, up to 32-in fan), Medium Room (up to 12 ft x 14 ft, 32-in to 48-in fan), and Large Room (up to 12 ft x 18 ft, 48-in to 58-in fan). This 62-inch fan is suitable for larger rooms.

OPERATING INSTRUCTIONS

Your Prominence Home Guyanna ceiling fan is operated using the included remote control. The remote allows independent control of the fan and light functions.

Remote Control Functions

- **High Speed:** Activates the fan at its highest setting.
- **Medium Speed:** Activates the fan at a moderate setting.
- **Low Speed:** Activates the fan at its lowest setting.
- **Power Fan Off:** Turns the fan off.
- **Light Delay Mode:** Taps to turn the light off after 1 minute.
- **Light Control:** Tap to turn the light on/off. Press and hold to dim or brighten the LED light.



Image: Detailed view of the 3-speed remote control, showing buttons for fan speed (High, Medium, Low, Off), light control (on/off, dimming), light delay mode, and the reversible motor switch.

Dimmable LED Lighting

The integrated LED light is fully dimmable. To adjust the brightness, press and hold the light control button on the remote until the desired light level is achieved. The light operates at 3000K color temperature.



Image: Close-up of the frosted integrated globe light kit, indicating a 3000K color temperature and a dimmable lighting range from 20% to 100%.

Reversible Motor Function

The fan features a reversible motor for year-round comfort. A switch on the remote control allows you to change the motor direction:

- **Summer Mode:** Blades rotate counter-clockwise, pushing cool air downwards for a strong wind and rapid cooling effect.
- **Winter Mode:** Blades rotate clockwise, drawing warm air up and distributing it evenly to balance indoor heating and cooling.



Image: Visual representation of the reversible motor function, showing airflow patterns for both winter (upward, balancing heating) and summer (downward, rapid cooling) modes.

Your browser does not support the video tag.

Video: An official product video demonstrating the Prominence Home 62-inch Guyanna Ceiling Fan in Espresso finish, showcasing its design and operation.

MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish or electrical components.
- **Blade Care:** Periodically check the blade screws for tightness. Loose blades can cause wobbling and noise.
- **Light Kit:** The integrated LED light is designed for long-term use and is not user-replaceable. If the light malfunctions, contact customer support.

TROUBLESHOOTING

If you experience issues with your ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker/fuses. Ensure all wiring connections are secure. Replace remote battery or re-pair remote.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting hardware.	Tighten all blade screws. Ensure blades are balanced (use a balancing kit if necessary). Verify mounting hardware is secure.

Problem	Possible Cause	Solution
Light does not work	No power to the light; Loose wire connections; Integrated LED malfunction.	Check power supply. Ensure light kit wiring is secure. If integrated LED, contact customer support.
Remote control not working	Low or dead battery; Remote not paired with fan.	Replace battery. Refer to the full owner's manual for remote pairing instructions.

SPECIFICATIONS

- **Brand:** Prominence Home
- **Model Name:** Guyanna
- **Model Number:** 51633-01
- **Color:** Bronze
- **Product Dimensions:** 62"D x 62"W x 14.18"H
- **Blade Span:** 62 inches
- **Number of Blades:** 5
- **Blade Material:** Wood
- **Light Type:** Integrated LED
- **Color Temperature:** 3000K
- **Wattage:** 19 watts (LED)
- **Voltage:** 120V
- **Number of Speeds:** 3
- **Control Method:** Remote Control (Button Control)
- **Mounting Type:** Downrod Mount
- **Indoor Outdoor Usage:** Indoor
- **Special Features:** Reversible Motor, Dimmable Light
- **Certification:** ETL Listed
- **UPC:** 671961516338

WARRANTY

This Prominence Home Guyanna ceiling fan is covered by a**Limited Lifetime Warranty**. For specific terms and conditions, please refer to the warranty information included with your product or contact Prominence Home customer support.

SUPPORT

For technical assistance, missing parts, or warranty claims, please contact Prominence Home customer support. Refer to the contact information provided in your product packaging or visit the official Prominence Home website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09R7W68H5>

More documents and user manuals: **<https://manuals.plus/>**