

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Z-Lite](#) /

› [Z-Lite 493F4-MB Clarion 4-Light Flush Mount Light Fixture Instruction Manual](#)

## Z-Lite 493F4-MB

# Z-Lite 493F4-MB Clarion 4-Light Flush Mount Light Fixture Instruction Manual

Model: 493F4-MB

## INTRODUCTION

---

Thank you for purchasing the Z-Lite 493F4-MB Clarion 4-Light Flush Mount Light Fixture. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new lighting fixture. Please read all instructions carefully before beginning installation and retain this manual for future reference.



The Z-Lite Clarion Flush Mount Light Fixture seamlessly integrates into a modern living room setting, providing ambient illumination.

## SAFETY INFORMATION

---

**WARNING: RISK OF ELECTRIC SHOCK. Disconnect power at the circuit breaker or fuse box before installation or servicing. Improper wiring can result in electric shock or fire.**

- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Use UL/cUL listed wire connectors suitable for the size, type, and number of conductors.
- Do not exceed the maximum wattage specified for this fixture.
- Ensure the fixture is properly grounded.
- Handle glass components with care to prevent breakage.

## PACKAGE CONTENTS

---

Verify that all parts listed below are included in your package. If any parts are missing or damaged, contact Z-Lite customer service before proceeding with installation.

- Light Fixture Assembly
- Mounting Hardware Kit (mounting strap, screws, wire nuts)
- Glass Shade
- Instruction Manual (this document)

## TOOLS REQUIRED

---

The following tools are typically required for installation:

- Phillips Head Screwdriver
- Flathead Screwdriver
- Wire Strippers
- Pliers
- Electrical Tape (optional)
- Safety Glasses

## SETUP AND INSTALLATION

---

Follow these steps carefully to install your Z-Lite Clarion Flush Mount Light Fixture.

### Step 1: Prepare for Installation

1. **Turn off power:** Locate the circuit breaker or fuse box and turn off the power to the junction box where you will be installing the fixture. Verify the power is off using a voltage tester.
2. **Unpack contents:** Carefully remove all components from the packaging. Place them on a clean, flat surface to avoid scratching or damage.

### Step 2: Install Mounting Strap

1. Attach the mounting strap to the junction box using the provided mounting screws. Ensure the strap is securely fastened and level.

### Step 3: Make Electrical Connections

Refer to the wiring diagram below for proper connections. If you are unsure, consult a qualified electrician.

- Connect the **green** or bare copper ground wire from the fixture to the ground wire from the junction box (usually bare copper or green). Secure with a wire nut.
- Connect the **white** wire from the fixture to the white (neutral) wire from the junction box. Secure with a wire nut.
- Connect the **black** wire from the fixture to the black (hot) wire from the junction box. Secure with a wire nut.
- Carefully tuck all wires into the junction box.

### Step 4: Attach Fixture to Mounting Strap

1. Align the fixture base with the holes on the mounting strap.
2. Secure the fixture to the mounting strap using the provided fixture screws. Tighten until the fixture is snug against the ceiling.



A close-up of the Z-Lite Clarion Flush Mount Light Fixture, highlighting the four light sockets and the clear, textured glass shade.

### Step 5: Install Light Bulbs

1. Insert four (4) incandescent bulbs with an E26 Medium base, up to 60 watts each (not included), into the sockets. Do not exceed the maximum wattage.

### Step 6: Final Assembly

1. Carefully attach the glass shade to the fixture according to the specific design (usually by twisting or securing with decorative nuts). Ensure it is securely in place.



An angled view of the Z-Lite Clarion Flush Mount Light Fixture, emphasizing its matte black finish and the clear, textured glass shade.

## Step 7: Restore Power

1. Once installation is complete, restore power at the circuit breaker or fuse box.
2. Test the fixture to ensure it functions correctly.

## OPERATING INSTRUCTIONS

---

The Z-Lite 493F4-MB Clarion Flush Mount Light Fixture operates via a standard wall switch. If connected to a compatible dimmer switch, the light output can be adjusted.

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the lights on or off.
- **Dimming (if applicable):** If a dimmer switch is installed, rotate or slide the dimmer control to adjust the brightness level. Ensure that the installed bulbs are compatible with dimming.

## MAINTENANCE

---

### Cleaning

To maintain the appearance of your fixture, clean it regularly.

- **Always disconnect power** before cleaning.
- Wipe the fixture with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- For glass components, a mild glass cleaner can be used, applied to a cloth first, not directly to the fixture.

### Bulb Replacement

When a bulb needs replacement:

- **Turn off power** to the fixture at the circuit breaker.
- Allow bulbs to cool completely before touching.
- Carefully remove the glass shade.
- Unscrew the old bulb and replace it with a new E26 Medium base incandescent bulb, up to 60 watts.
- Reattach the glass shade securely.
- Restore power and test the fixture.

## TROUBLESHOOTING

---


If you experience issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse. Ensure wall switch is ON.
	Loose or incorrect wiring.	Turn off power. Check all wire connections.
	Defective bulb.	Replace bulb with a new one.
Light flickers.	Loose bulb.	Tighten bulb securely.
	Incorrect dimmer switch or bulb type.	Ensure dimmer is compatible with incandescent bulbs. Replace bulbs if not dimmable.
Fixture hums.	Incompatible dimmer switch.	Replace dimmer switch with one designed for incandescent loads.

## SPECIFICATIONS

---

- **Model:** 493F4-MB
- **Brand:** Z-Lite
- **Dimensions:** 20.75" L x 20.75" W x 6.25" H
- **Color:** Matte Black
- **Material:** Alloy Steel, Glass
- **Light Source Type:** Incandescent
- **Number of Light Sources:** 4
- **Bulb Base:** E26 Medium
- **Max Wattage per Bulb:** 60 Watts
- **Voltage:** 120 Volts
- **Installation Type:** Flush Mount
- **Indoor/Outdoor Usage:** Indoor
- **Certification:** UL Listed



Dimensional drawing illustrating the width (20.75") and height (6.25") of the Z-Lite Clarion Flush Mount Light Fixture.

## WARRANTY AND SUPPORT

---

This Z-Lite fixture is covered by a manufacturer's warranty. Please refer to the warranty documentation included with your purchase or contact Z-Lite customer service for specific details regarding warranty coverage and claims.

For technical assistance, missing parts, or warranty inquiries, please contact Z-Lite customer support through their official website or the retailer where the product was purchased.