

## AEG AP81B25WET

# AEG Hygienic 8000 Cordless Vacuum Cleaner AP81B25WET Instruction Manual

Model: AP81B25WET

## 1. INTRODUCTION AND SAFETY INFORMATION

This manual provides essential instructions for the safe and efficient use of your AEG Hygienic 8000 Cordless Vacuum Cleaner. Please read all instructions carefully before operating the appliance and retain this manual for future reference.

### 1.1 Important Safety Instructions

- Always ensure the vacuum cleaner is switched off and unplugged from the charger before performing any maintenance or cleaning.
- Do not use the appliance to pick up water or other liquids, flammable substances, hot ashes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the vacuum cleaner if it is damaged or malfunctioning. Contact authorized service personnel for repairs.
- Use only the charging adapter and battery pack supplied with the appliance.
- This appliance is intended for household use only.

## 2. PRODUCT OVERVIEW

The AEG Hygienic 8000 is a versatile cordless vacuum cleaner designed for both dry vacuuming and wet cleaning with its integrated mop nozzle. It features a powerful motor and an advanced filtration system.



This image displays the AEG Hygienic 8000 cordless vacuum cleaner in its upright configuration, alongside its various attachments: the UltimatePower mop nozzle, UltimatePower multi-floor nozzle, crevice tool, furniture brush, ergonomic corner attachment, and charging station.

## 2.1 Included Components

- Main Vacuum Unit
- Extension Tube
- UltimatePower Multi-floor Nozzle
- UltimatePower Mop Nozzle (for wet cleaning)
- Crevice Tool
- Furniture Brush
- Ergonomic Corner Attachment
- Charging Station
- Spray Bottle (for mop nozzle)
- Lithium-ion Battery (pre-installed or separate)

## 3. SETUP

---

### 3.1 Assembly

1. **Unpack:** Carefully remove all components from the packaging.
2. **Attach Extension Tube:** Connect the extension tube to the main vacuum unit until it clicks into place.
3. **Attach Nozzle:** Select the desired nozzle (e.g., UltimatePower Multi-floor Nozzle) and attach it to the end of the extension tube.
4. **Battery Installation:** If the battery is not pre-installed, slide the lithium-ion battery into the designated slot on the main unit until it locks securely.



This image illustrates the process of removing or inserting the lithium-ion battery from the main unit of the AEG Hygienic 8000 cordless vacuum cleaner.

### 3.2 Charging the Battery

1. **Position Charging Station:** Place the charging station on a flat, stable surface near a power outlet.
2. **Connect Charger:** Plug the charging adapter into the charging station and then into a wall outlet.
3. **Dock Vacuum:** Place the assembled vacuum cleaner onto the charging station. Ensure it is properly seated. The battery indicator lights on the control panel will illuminate to show charging status.
4. **Full Charge:** Allow the battery to fully charge before first use. A full charge typically takes several hours.



The AEG Hygienic 8000 cordless vacuum cleaner is shown docked in its charging station, ready for charging or storage. The charging station provides a convenient way to store the vacuum and its accessories.

## 4. OPERATING INSTRUCTIONS

### 4.1 Basic Operation (Dry Vacuuming)

1. **Power On:** Press the power button on the control panel to turn on the vacuum cleaner.
2. **Select Mode:** Use the mode selection buttons (Min, Auto, Mid, Turbo) to adjust suction power. The 'Auto' mode intelligently adjusts power based on the surface.
3. **Vacuuming:** Guide the vacuum cleaner across the surface to be cleaned. The powerful motor provides 6x more suction for thorough cleaning.
4. **Under Furniture:** The low-profile design allows for easy cleaning under furniture.



A user is shown operating the AEG Hygienic 8000 cordless vacuum cleaner on a hard floor in a kitchen setting, demonstrating its ease of use for general cleaning.





The vacuum cleaner's low-profile head is depicted cleaning underneath a sofa, highlighting its ability to reach difficult areas.



The vacuum cleaner head is shown actively removing dirt and debris from a carpeted surface, illustrating its dry vacuuming performance.

## 4.2 Using the UltimatePower Mop Nozzle (Wet Cleaning)

The integrated UltimatePower Mop Nozzle allows for simultaneous vacuuming and wet cleaning.

1. **Attach Mop Nozzle:** Replace the standard floor nozzle with the UltimatePower Mop Nozzle.
2. **Fill Spray Bottle:** Fill the provided spray bottle with water or a suitable floor cleaning solution.
3. **Spray Surface:** Lightly spray the floor surface in front of the mop nozzle.
4. **Activate Mop:** The mop nozzle uses rotating pads to remove liquids and stubborn dirt.
5. **Clean:** Guide the vacuum cleaner over the pre-sprayed area.





The UltimatePower Mop Nozzle is shown in action, effectively cleaning a liquid spill on a tiled floor, demonstrating its wet cleaning capability.

### **4.3 Control Panel Overview**



A detailed view of the vacuum cleaner's control panel, showing the power button, mode selection (Min, Auto, Mid, Turbo), and indicators for battery and water/wet cleaning.

- **Power Button:** Turns the vacuum cleaner on and off.
- **Mode Selection (+/-):** Cycles through suction modes: Min, Auto, Mid, Turbo.
- **Battery Indicator:** Displays the current battery charge level.
- **Wet Cleaning Indicator:** Illuminates when the mop function is active or water is detected.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

### 5.1 Emptying the Dustbin

1. **Power Off:** Ensure the vacuum cleaner is switched off.
2. **Detach Dustbin:** Locate the dustbin release button and detach the dustbin from the main unit.
3. **Empty Contents:** Hold the dustbin over a waste bin and open the bottom flap to empty the collected dirt and debris.
4. **Reattach Dustbin:** Close the flap and reattach the dustbin to the main unit until it clicks securely.

### 5.2 Cleaning the 5-Stage Filtration System

The advanced 5-stage filtration system removes up to 99.99% of micro-dust particles. Regular cleaning is crucial for maintaining suction power.



This image provides an exploded diagram of the vacuum cleaner's advanced 5-stage filtration system, showing the individual components that contribute to capturing micro-dust particles.

1. **Access Filters:** With the dustbin detached, carefully remove the filter components as shown in the diagram.
2. **Clean Filters:** Tap the filters gently to remove loose dust. For thorough cleaning, rinse the washable filters under cold running water. Do not use detergents.
3. **Dry Completely:** Allow all filter components to air dry completely for at least 24 hours before reassembling. Do not use heat to dry.
4. **Reassemble:** Reinsert the dry filters into the dustbin in the correct order and reattach the dustbin to the main unit.

### 5.3 Brush Roll Clean Function

The Brush Roll Clean feature helps remove tangled hair and fibers from the brush roll.

1. **Activate:** With the vacuum powered on and the floor nozzle attached, press the Brush Roll Clean pedal (if available on your model) for a few seconds.
2. **Check:** The brush roll will automatically clean itself. Check the brush roll afterwards to ensure all debris has been removed.

## 6. TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly inserted.	Charge the battery. Ensure the battery is securely inserted.
Reduced suction power	Dustbin is full. Filters are clogged. Nozzle or tube is blocked.	Empty the dustbin. Clean the filters. Check for and remove blockages.
Brush roll not rotating	Brush roll is tangled with hair/fibers. Obstruction in the nozzle.	Use the Brush Roll Clean function or manually remove tangles. Clear any obstructions.
Mop nozzle not dispensing water	Spray bottle is empty. Nozzle jets are clogged.	Refill the spray bottle. Clean the nozzle jets.

If the problem persists after trying these solutions, please contact AEG customer support.

## 7. SPECIFICATIONS

Feature	Detail
Brand	AEG
Model Number	AP81B25WET
Product Dimensions	79.4 x 22.4 x 35.9 cm
Item Weight	2.9 Kilograms
Form Factor	Upright
Finish	Glossy
Battery Type	Lithium-ion
Power Source	Battery
Voltage	25.2 Volts
Wattage	25.2 watts
Cordless	Yes
Special Features	Suction and Drying (Mop Function)
Filter Type	HEPA Filter (5-stage filtration)
Surface Recommendation	Carpets, hard floors, upholstery, pet accessory, furniture
Runtime (Minimum Mode)	Up to 35 minutes (suitable for approx. 75 m²)
Suction Power	6x more suction compared to previous model CX7-2-35WR (IEC 62885-2)

## 8. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the official AEG website or contact their customer service department.

**Online Support:** Visit the official [AEG website](#) for FAQs, troubleshooting guides, and contact information.

**Service Centers:** Information on authorized service centers can be found on the AEG website.



© 2023 AEG. All rights reserved.

### Related Documents - AP81B25WET

<div><div><div>AEG</div><div>Instruction Book</div></div><div><div>ULTIMATE 8000</div><div>ANIMAL 8000</div><div>HYGIENIC 8000</div></div><div></div></div>	<div><div><a href="#">AEG ULTIMATE 8000, ANIMAL 8000, HYGIENIC 8000 Cordless Vacuum Cleaner Instruction Manual</a></div><div>Comprehensive instruction manual for AEG ULTIMATE 8000, ANIMAL 8000, and HYGIENIC 8000 cordless vacuum cleaners. Covers assembly, operation, maintenance, safety, and accessory information.</div></div>
<div><div><div>AEG</div><div>Instruction Book</div></div><div><div>ULTIMATE 8000</div><div>ANIMAL 8000</div><div>HYGIENIC 8000</div></div><div></div></div>	<div><div><div><a href="#">AEG 8000 Series Cordless Vacuum Cleaner Instruction Manual</a></div><div>Comprehensive instruction manual for AEG 8000 series cordless vacuum cleaners, including Ultimate, Animal, and Hygienic models. Covers assembly, usage, maintenance, and accessory information.</div></div></div>
<div><div><div>AEG</div><div>Instruction Book</div></div><div><div>ULTIMATE 8000</div><div>ANIMAL 8000</div><div>HYGIENIC 8000</div></div><div></div></div>	<div><div><div><a href="#">AEG Ultimate 8000 Series Cordless Vacuum Cleaner Instruction Manual</a></div><div>Comprehensive instruction manual for AEG Ultimate 8000, Animal 8000, and Hygienic 8000 series cordless vacuum cleaners. Includes assembly, usage, maintenance, and accessory information.</div></div></div>






# AEG

Instruction Book

ULTIMATE 8000  
ANIMAL 8000  
HYGIENIC 8000



## [AEG ULTIMATE 8000, ANIMAL 8000, HYGIENIC 8000 Cordless Vacuum Cleaner Instruction Manual](#)

Comprehensive instruction manual for AEG ULTIMATE 8000, ANIMAL 8000, and HYGIENIC 8000 cordless vacuum cleaners. Covers assembly, operation, maintenance, safety, and accessory information.

lang:it **score:12** filesize: 3.42 M page\_count: 8 document date: 2022-09-19