

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Volkano](#) /

› [Volkano Pumped Series IPX4 Sports Armband Wireless Bluetooth Speaker Instruction Manual](#)

Volkano VK-3134-BKGR

Volkano Pumped Series IPX4 Sports Armband Wireless Bluetooth Speaker

MODEL: VK-3134-BKGR

Introduction

The Volkano Pumped Series Sports Armband Wireless Bluetooth Speaker is designed for active individuals seeking portable audio. This wearable speaker allows you to enjoy music and take calls while remaining aware of your surroundings. Its durable, water-resistant design makes it suitable for various outdoor and indoor activities.



**BLUETOOTH
WIRELESS**

COMPATIBLE WITH

 |  | 

**EXTENSIVE
COMPATIBILITY**

Compatible with Bluetooth devices including Samsung Galaxy, Apple Iphone, Ipad, Iphone, Computers and more

Image: The Volkano Pumped speaker offers extensive compatibility with Bluetooth devices, including smartphones and tablets.

Package Contents

Please ensure all items are present in your package:

- Volkano Pumped Series Wearable Speaker
- Running Armband
- Micro USB Charging Cable
- Instruction Manual



PACKAGE CONTENTS

- Volkano Pumped Series Wearable Speaker
- Running Armband
- Micro USB Charging Cable
- Instruction Manual

Image: All components included in the Volkano Pumped Series speaker package.

Product Overview and Features

The Volkano Pumped speaker is designed for convenience and performance:

- **Battery Life:** The speaker features a built-in 500mAh rechargeable battery, providing up to 7 hours of music playback. A full charge takes approximately 1.5 hours. Actual playtime may vary based on volume level and audio content.
- **Wearable Design:** The flexible and adjustable armband is designed to fit arm sizes from 10-14 inches (25-35 cm). Constructed from soft, sweatproof Lycra fabric, it provides a secure fit for activities like running, jogging, walking, or working.
- **Situational Awareness:** The wireless design allows you to listen to music or podcasts without earbuds, maintaining awareness of your surroundings. This is beneficial for activities where situational awareness is important, such as walking or cycling.
- **Hands-Free Functions:** The speaker supports hands-free phone calls. It includes Bluetooth 5.0 for wireless connectivity, an SD card input for direct music playback, and a camera shutter control function. The speaker delivers a total power output of 3W RMS.
- **Water Resistance:** With an IPX4 water resistance rating, the speaker is protected against splashes and sweat, making it suitable for outdoor activities like cycling, hiking, or walking. Note that IPX4 rating

means it is not fully waterproof and should not be submerged.

FEATURES



Up To
7 Hrs
Speaker
Playtime



500 mAh
Battery



Easy To Wipe



IPX4 Water
Resistant



Sweat Resistant



15 Hrs
Charging Time

Image: Key features of the Volkano Pumped speaker, including battery life and water resistance.

SMALL DEVICE BIG SOUND

Entertainment on the go | Adjustable armband fits you comfortably



1.3" Driver

3W ^{RMS}
TOTAL POWER



Sensitivity
106 dB



Reflective
Armband



Image: The speaker's compact design and reflective armband for visibility.




Image: Examples of activities where the Volkano Pumped speaker can be used.

Controls and Inputs

Familiarize yourself with the speaker's controls and input ports:




Image: Detailed diagram of the speaker's buttons and ports.

The speaker features buttons for power, volume control, track navigation, mode selection, call management, and a camera shutter function. It also includes a Micro USB charging port and an SD card slot.

Product Video

Video: Official product video demonstrating the features and various uses of the Volkano Pumped Wearable Bluetooth Speaker.

Setup

Charging the Speaker

1. Connect the provided Micro USB charging cable to the speaker's charging port.
2. Connect the other end of the cable to a USB power source (e.g., wall adapter, computer USB port).
3. The charging indicator light will illuminate. Once fully charged (approximately 1.5 hours), the light will change or turn off.

Powering On/Off

- To power on, press and hold the Power button until you hear an audible prompt or see an indicator light.

- To power off, press and hold the Power button again until the speaker shuts down.

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "Volkano Pumped" from the list of found devices.
4. Once connected, the speaker will provide an audible confirmation, and the LED indicator will stop flashing.

Operating Instructions

Music Playback

- **Play/Pause:** Press the Play/Pause button once.
- **Volume Up/Down:** Press the Volume + or Volume - buttons.
- **Next/Previous Track:** Press and hold the Volume + for next track or Volume - for previous track.

Hands-Free Calls

- **Answer Call:** Press the Call button once.
- **End Call:** Press the Call button once during a call.
- **Reject Call:** Press and hold the Call button.

SD Card Playback

- Insert a Micro SD card with audio files into the designated slot.
- The speaker will automatically switch to SD card mode or you may need to press the Mode button to select it.

Camera Shutter Control

- Ensure your phone's camera app is open.
- Press the Camera Shutter button on the speaker to remotely trigger your phone's camera.

Maintenance

- **Cleaning:** The Lycra armband is sweatproof and easy to wipe clean. Use a damp cloth to gently clean the speaker unit. Avoid harsh chemicals.
- **Water Resistance:** The speaker has an IPX4 rating, meaning it is resistant to splashes and sweat. Do not submerge the speaker in water or expose it to heavy rain. Ensure all ports are securely closed when near moisture.
- **Storage:** Store the speaker in a cool, dry place when not in use.

Troubleshooting

- **Speaker does not power on:** Ensure the battery is charged. Connect the speaker to a power source using the Micro USB cable.
- **No sound:** Check the volume levels on both the speaker and your connected device. Ensure the speaker is properly paired via Bluetooth or that the SD card is inserted correctly.
- **Bluetooth pairing issues:** Make sure the speaker is in pairing mode. Turn off Bluetooth on your device and turn it back on. Try unpairing and re-pairing the speaker. Ensure no other devices are

connected to the speaker.

- **Short battery life:** Battery life can vary based on volume and usage. Ensure the speaker is fully charged before use. Extremely high volume levels will reduce playback time.

Specifications

Model Number	VK-3134-BKGR
Bluetooth Version	5.0
Water Resistance Rating	IPX4
Speaker Output Power	3W RMS
Battery Capacity	500 mAh
Charging Time	1.5 Hours
Playback Time	Up to 7 Hours
Wireless Range	Up to 33 Feet (10 meters)
Product Dimensions	3.74"D x 0.94"W x 2.17"H (9.5cm D x 2.4cm W x 5.5cm H)
Item Weight	3.17 Ounces (90 grams)
Material	Waterproof Lycra Armband
Connectivity	Bluetooth, SD Card

Warranty and Support

Warranty Information

This Volkano product is covered by a 1-Year Limited Warranty. Please refer to the warranty card included in your package for full terms and conditions.

Customer Support

For any questions, assistance, or support regarding your Volkano Pumped speaker, please message us via the official Volkano seller page on the platform where you purchased the product. Your satisfaction is important to us.