

[Manuals.plus](#) /

> [Outsunny](#) /

> Outsunny Outdoor Wicker Rocking Chair User Manual

Outsunny 867-048BU

Outsunny Outdoor Wicker Rocking Chair User Manual

Model: 867-048BU

INTRODUCTION

Thank you for choosing the Outsunny Outdoor Wicker Rocking Chair. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new rocking chair. Please read this manual thoroughly before assembly and retain it for future reference.

SAFETY INFORMATION

Always follow basic safety precautions when using this product to reduce the risk of injury. Keep all parts and packaging materials away from children. Ensure all components are securely fastened before use. Do not exceed the maximum weight capacity of 352 pounds.

General Safety Guidelines:

- Inspect the chair regularly for any loose parts or damage.
- Do not stand on the chair.
- Use on a flat, stable surface to prevent tipping.
- Keep away from open flames or excessive heat.
- This product is designed for outdoor use.

PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, contact Outsunny customer service.

Item	Description	Quantity
Rocking Chair Frame	Aluminum frame with PE rattan wicker accents.	1

Item	Description	Quantity
Seat Cushion	Padded cushion for the seat.	1
Back Cushion	Padded cushion for the backrest.	1
Hardware Pack	Includes all necessary bolts, washers, and tools for assembly.	1

SETUP AND ASSEMBLY

Assembly is required for this rocking chair. It is recommended to have two people for easier and safer assembly. Please follow the steps below carefully.

Tools Required:

- Included Allen Wrench
- (Optional) Phillips Head Screwdriver

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratching.
2. **Attach Side Frames:** Connect the front and back crossbars to the side frames using the provided bolts. Do not fully tighten bolts yet.
3. **Secure Seat Base:** Attach the seat base to the assembled frame. Ensure the PE rattan wicker section is facing upwards.
4. **Attach Rocker Base:** Secure the curved rocker base to the bottom of the chair frame. This allows for the rocking motion.
5. **Tighten All Bolts:** Once all components are loosely assembled, carefully tighten all bolts evenly. Do not overtighten.
6. **Place Cushions:** Position the seat cushion on the chair seat and the back cushion against the backrest. The cushions are designed for optimal comfort.

COMFORTABLE CUSHION

for greater relaxation

Thick Soft Padding



Removable
Cushion Covers



Washable
Cushion Covers

NOTE: This fabric does not block rain

Figure 1: Product Dimensions. This image illustrates the overall dimensions of the rocking chair, including height, width, and depth, along with seat and backrest measurements. The maximum weight capacity is indicated as 352 lbs.

DETAILS DISPLAY



High backrest



Curved arms



Rocker base



Durable construction

Figure 2: PE Rattan Wicker Detail. This image highlights the hand-woven polyethylene rattan wicker, emphasizing its UV resistance, durability, and weather-resistant properties.

OPERATING INSTRUCTIONS

The Outsunny Outdoor Wicker Rocking Chair is designed for comfortable outdoor relaxation. Simply sit on the chair and gently push off with your feet to initiate the rocking motion. The chair's design allows for a smooth and comfortable sway.



Figure 3: Rocking Chair in Use. This image shows the rocking chair positioned outdoors, ready for use, highlighting its classic style and comfortable appearance.



Figure 4: Rocking Chair on Patio. The chair is shown on a wooden patio, demonstrating its suitability for various outdoor environments.

Your browser does not support the video tag.

Video 1: Product Overview. This video provides a brief overview of the Outsunny Outdoor Wicker Rocking Chair, showcasing its features and design in various outdoor settings.

MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your Outsunny rocking chair. Follow these guidelines for optimal care.

Cleaning:

- **Frame:** Wipe clean with a damp cloth and mild soap. Rinse thoroughly and dry completely to prevent water spots or corrosion.
- **Cushions:** The cushion covers are removable and washable. Refer to the care label on the cushions for specific washing instructions. Allow cushions to dry completely before reattaching or storing.



Figure 5: Cleaning the Wicker. This image demonstrates the process of wiping down the PE rattan wicker for maintenance.

Storage:

- During prolonged periods of non-use or harsh weather conditions, it is recommended to store the chair indoors or cover it with a protective outdoor furniture cover.
- Store cushions in a dry, protected area to prevent mold and mildew.

TROUBLESHOOTING

If you encounter any issues with your rocking chair, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Chair feels unstable or wobbly.	Loose bolts or uneven surface.	Ensure all assembly bolts are tightened securely. Move the chair to a flat, level surface.
Cushions appear flat or uncomfortable.	Normal wear and compression over time.	Fluff cushions regularly. Consider adding additional padding if desired.
Rattan wicker appears faded.	Prolonged exposure to direct sunlight.	While UV-resistant, continuous exposure can cause fading. Store or cover the chair when not in use.

SPECIFICATIONS

- **Model Name:** Rattan Rocking Chair
- **Model Number:** 867-048BU
- **Brand:** Outsunny
- **Color:** Blue
- **Overall Dimensions:** 27.25" W x 36.5" D x 35.5" H
- **Sitting Height:** 17.25"
- **Seat Cushion Dimensions:** 22.75" W x 22.75" D
- **Backrest Dimension:** 22.75" H x 20.5" W
- **Maximum Weight Recommendation:** 352 Pounds
- **Material:** Aluminum Frame, PE Rattan Wicker, Cotton Fill Cushions
- **Indoor/Outdoor Usage:** Outdoor
- **Product Care Instructions:** Wipe Clean

WARRANTY AND SUPPORT

Outsunny products are designed for quality and durability. For warranty information, replacement parts, or technical support, please contact Outsunny customer service directly.

Contact Information:

- Visit the official Outsunny website for support resources.
- Refer to your purchase receipt for specific warranty terms.

© 2025 Outsunny. All rights reserved.
For more information, visit [Aosom.com](https://www.aosom.com)