

Lifelight - Shark Light

Generic 3.6" L Lifelight - Shark Light Instruction Manual

Model: Lifelight - Shark Light

INTRODUCTION

Thank you for choosing the Generic 3.6" L Lifelight - Shark Light. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new device. Please read this manual thoroughly before use and retain it for future reference.

PRODUCT OVERVIEW

The Lifelight - Shark Light is a compact, handheld flashlight designed for various illumination needs. Its durable construction and convenient size make it suitable for everyday carry.



Figure 1: Front view of the Generic 3.6" L Lifelight - Shark Light. This image shows the compact design and the light

SETUP AND FIRST USE

- Unpacking:** Carefully remove the Lifelight - Shark Light from its packaging. Inspect for any signs of damage.
- Battery Installation:** The device requires batteries for operation. Locate the battery compartment, typically at the rear or side of the flashlight. Insert the required batteries, ensuring correct polarity (+/-) as indicated inside the compartment. Close the compartment securely.
- Attachment (Optional):** If desired, attach the flashlight to a keychain or other item using the integrated split ring closure.

Important Safety Note:

- Handle with care to prevent damage.
- Keep away from heat sources to avoid battery damage or malfunction.

OPERATING INSTRUCTIONS

To operate the Lifelight - Shark Light:

- Turning On:** Locate the power button or switch, usually near the head or body of the flashlight. Press or slide the switch to turn the light on.
- Turning Off:** Press or slide the power button/switch again to turn the light off.

Note: Some models may feature multiple light modes (e.g., high, low, strobe). Cycle through modes by pressing the power button repeatedly.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the exterior of the flashlight with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Battery Replacement:** When the light dims or fails to turn on, replace the batteries. Refer to the "Setup and First Use" section for battery installation instructions. Always use the recommended battery type.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, remove the batteries to prevent leakage.
- **General Handling:** Continue to handle the device with care and keep it away from heat sources.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Dead or incorrectly installed batteries.	Replace batteries, ensuring correct polarity.
Light is dim.	Low battery power.	Replace batteries.
Light flickers.	Loose battery connection or low battery power.	Check battery compartment for secure fit; replace batteries if necessary.

SPECIFICATIONS

Brand: Generic

Model: Lifelight - Shark Light

Size: 3.6 inches (Length)

Closure Type: Split Ring

Care Instructions: Handle with care. Keep away from heat sources. Replace batteries when necessary.

UPC: 769593771956

ASIN: B09RK8Z44F

First Available: April 5, 2022

WARRANTY AND SUPPORT

This product is manufactured by Generic. For support inquiries or to report issues, please contact the retailer or refer to the product packaging for manufacturer contact information. Please retain your proof of purchase for any warranty claims.

Note: Specific warranty terms may vary by retailer and region. Please consult your purchase documentation for details.