

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Paladone](#) /

› [Paladone PlayStation White PS5 Controller Alarm Clock Instruction Manual](#)

Paladone PP9405PS

Paladone PlayStation White PS5 Controller Alarm Clock Instruction Manual

Model: PP9405PS

[Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)

INTRODUCTION

Thank you for purchasing the Paladone PlayStation White PS5 Controller Alarm Clock. This officially licensed digital alarm clock is designed to display time and alarm settings, featuring a unique PlayStation controller design. Please read this manual carefully to ensure proper setup and operation.

SETUP

Unboxing and Initial Power-Up

1. Carefully remove the alarm clock from its packaging.
2. Locate the included USB power cable.
3. Connect the micro USB end of the cable to the port on the back of the alarm clock.
4. Connect the standard USB end to a compatible USB power adapter (not included) or a powered USB port. The clock will power on and the digital display will illuminate.



MICRO USB TO USB POWERED

*comes with 148 cm (58 in) power chord
(adadapter not included)*

Image: Rear view of the alarm clock, highlighting the micro USB power input. The clock is powered via a USB cable.



Image: The included 148 cm (58 inch) micro USB to USB power cord. A power adapter is not supplied.

OPERATION

Setting Time and Date

1. Press the **X button** (typically located on the right side of the controller) to enter time/date setting mode.
2. Use the **directional arrow keys** (D-pad on the left side) to adjust the numbers (hours, minutes, year, month, day).
3. Press the **X button** again to confirm each setting and move to the next.

Setting the Alarm

1. Press the **Circle button** (typically located on the right side of the controller) to enter alarm setting mode.
2. Use the **directional arrow keys** (D-pad) to adjust the desired alarm time.
3. Press the **Circle button** again to confirm the alarm time.
4. To activate or deactivate the alarm, press the **Triangle button**. An alarm icon will appear on the display when active.

Snooze Function

When the alarm sounds, press any button on the controller to activate the snooze function. The alarm will temporarily pause and sound again after a short interval.

Display Illumination

The digital display illuminates to show the time and settings. The brightness is fixed and cannot be adjusted.



Image: Front view of the alarm clock, illustrating the function of the X button for time/date, Circle button for alarm, and directional arrows for adjustments.

MAINTENANCE

- To clean the alarm clock, use a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the device to extreme temperatures, direct sunlight, or moisture.
- Ensure the USB cable is securely connected to prevent power interruptions.

TROUBLESHOOTING

Problem	Solution
Clock display is off.	Ensure the USB power cable is securely connected to both the alarm clock and a working power source. The clock requires continuous power to operate.
Alarm does not sound.	Verify that the alarm time is correctly set and that the alarm is activated (check for the alarm icon on the display).

Problem	Solution
Time/Date resets after power loss.	This alarm clock does not feature a battery backup. In case of power interruption, the time and date will need to be reset manually.
Display is too bright at night.	The display brightness is fixed and cannot be adjusted. Consider placing the clock in a location where its light is less disruptive if this is an issue.

SPECIFICATIONS

Brand: Paladone

Model: PP9405PS

Product Dimensions: Approximately 10 cm (3.9 in) height x 15 cm (5.9 in) width

Item Weight: 8.8 ounces

Material: Plastic

Display Type: Digital

Power Source: Corded Electric (USB powered, cable included)

Batteries Required: No

Special Features: Alarm, Digital Time Display, PlayStation Controller Design

OFFICIALLY
LICENSED



Image: Front view of the alarm clock, illustrating its approximate dimensions of 10 cm (3.9 in) in height and 15 cm (5.9 in) in width.

WARRANTY AND SUPPORT

This product is covered by the manufacturer's warranty. For detailed warranty information or technical support, please refer to the contact information provided on the product packaging or visit the official Paladone website.