

[Manuals.plus](#) /

› [Asrcs](#) /

› Asrcs Dog Training Collar User Manual

Asrcs X12

Asrcs Dog Training Collar User Manual

Brand: Asrcs

Model: X12

1. PRODUCT OVERVIEW

The Asrcs Dog Training Collar with Remote is designed to assist in correcting various dog behaviors such as barking, walking, leash training, aggression, and other obedience issues. It offers multiple adjustable training modes and is suitable for small, medium, and large dogs.



Figure 1.1: Asrcs Dog Training Collar System

Key Features:

- **Wireless Control:** Up to 1650FT remote range for effective outdoor training.
- **Multiple Training Modes:** Features Beep, Emergency Flashlight, 0-99 levels Vibration, and 0-99 levels Static Shock training modes.
- **Long-Lasting Battery:** 2-in-1 charging port allows simultaneous charging of remote and receiver. Provides long standby and working times.
- **Waterproof Receiver:** IPX7 water-resistant material allows the collar to be worn during swimming or in rain.
- **LCD Backlit Display:** Remote control features an LED backlit display for night use.
- **Security Keypad Lock:** Prevents accidental operation of the remote.
- **Universal Fit:** Adjustable nylon collar fits neck sizes from 8 to 27.5 inches, suitable for dogs weighing 6 to 160 lbs.

2. WHAT'S INCLUDED

The Asrcs Dog Training Collar package includes the following components:

- 1 x Handheld Remote
- 1 x Receiver Collar
- 1 x Adjustable Collar
- 1 x Test Light Tool
- 1 x 2 in 1 USB Charging Cable
- 2 x Long Contact Points
- 2 x Short Contact Points
- 4 x Conductive Silicone Caps
- 1 x Wrist Strap
- 1 x User Manual



Figure 2.1: Package Contents

3. COMPONENTS AND CONTROLS

Familiarize yourself with the remote transmitter and receiver collar components:

PANEL INTRODUCTION



Figure 3.1: Remote and Receiver Panel Introduction

Remote Transmitter:

- **LCD Screen:** Displays battery capacity, mode, and intensity levels.
- **LED Flashlight:** For visibility in low light conditions.
- **Channel/Screen Lock Button:** To switch between channels (A/B/AB) or lock/unlock the screen.
- **Tone Button:** Activates the Beep mode.
- **Vibration Button:** Activates the Vibration mode (0-99 levels).
- **Shock Button:** Activates the Static Shock mode (0-99 levels).
- **Shock/Vibration Up/Down Buttons:** Adjusts intensity levels.
- **Anti-lost Lanyard Hole:** For attaching the wrist strap.

Receiver Collar:

- **On/Off/Encode Button:** Powers the receiver on/off and used for pairing.

- **LED Power Indicator:** Shows battery status.
- **LED Signal Indicator:** Indicates signal reception.
- **Contact Points:** Deliver stimulation (metal prongs).
- **Conductive Silicone Caps:** Cover contact points for comfort and safety.
- **Charging Hole:** For connecting the charging cable.

4. SETUP GUIDE

4.1. Charging the Devices

Before first use, fully charge both the remote transmitter and the receiver collar. Use the provided 2-in-1 USB charging cable.

- Connect the 2-in-1 USB charging cable to both the remote and receiver.
- Plug the USB end into a compatible USB power source (e.g., computer, power bank, USB wall adapter).
- Charging typically takes 2-3 hours. The LED indicator on the receiver will show charging status (green when full).

LONG LASTING BATTERY LIFE & USB CHARGING



The diagram illustrates the components and features of a dog training collar system. On the left is a black remote control with a blue screen displaying battery level, lock status, and signal strength. A circular inset shows a close-up of the keypad lock, which has a blue light and a lock icon. To the right of the inset is a blue screen showing a battery icon and a lock icon. Below the remote is a black receiver unit with a blue screen and a lock icon. Below the receiver is a black nylon collar strap with a black plastic buckle. Below the strap is a black micro USB charging port. Below the port are four icons representing different charging methods: a laptop, a power bank, a wall charger, and a car charger.

Remote:
Up to 180 days standby time, working time 60 days.

Keypad Lock:
More convenient and safe training your dog, To prevent accidental operation.

Receiver:
Up to 35 days standby time, working time 15 days.

Micro USB Charging Port
Charge your dog training collar anytime and anywhere

Figure 4.1: Long Lasting Battery Life & USB Charging

4.2. Attaching the Collar Strap and Contact Points

The adjustable nylon collar strap needs to be threaded through the receiver unit.

- Thread the adjustable nylon collar through the slots on the receiver unit.
- Choose the appropriate length contact points (short for short-haired dogs, long for long-haired dogs) and screw them onto the receiver.
- Place the conductive silicone caps over the contact points for added comfort and safety.



Figure 4.2: Installing Contact Points and Silicone Caps

4.3. Fitting the Collar

Proper fit is crucial for effective and safe training.

- Place the collar around your dog's neck so that the contact points are directly touching the skin on the underside of the neck.
- Ensure the collar is snug enough that two fingers cannot fit underneath, but not so tight as to cause discomfort.
- The adjustable nylon collar fits neck sizes from 8 to 27.5 inches, suitable for dogs weighing 6 to 160 lbs.

FOR ALL SIZE DOGS

Adjustable collar for all size dogs (Over 6LBS)



6lbs

160lbs



Figure 4.3: Collar Sizing Guide for All Dog Sizes

4.4. Syncing Transmitter with Collar-Receiver

The remote and receiver are pre-matched to the A&B common channel. You can open the product and use it directly. If re-pairing is needed:

- Ensure both devices are charged and powered off.
- Long press the ON/OFF button on the receiver until the LED light turns green and flashes rapidly.
- Within 10 seconds, press any button on the remote transmitter (Beep, Vibration, or Shock).
- The receiver's LED will stop flashing and turn solid green, indicating successful pairing.

Your browser does not support the video tag.

Video 4.1: Demonstrating the pairing process and functionality of the training collar.

5. OPERATING MODES

The Asrcs Dog Training Collar offers four primary training modes:

4 TRAINING MODES

Choose the proper mode for your dog



Figure 5.1: Available Training Modes

- **Beep Mode:** Delivers an audible tone. Press the Tone Button on the remote.
- **Vibration Mode:** Delivers a non-harmful vibration. Adjustable from 0 to 99 levels using the Up/Down buttons. Press the Vibration Button.
- **Static Shock Mode:** Delivers a static correction. Adjustable from 0 to 99 levels using the Up/Down buttons. Press the Shock Button. Use with caution and only when necessary.
- **Emergency Flashlight:** Activates a flashlight on the remote for visibility.

5.1. Security Keypad Lock

To prevent accidental activation of training modes, especially the static shock, use the keypad lock feature.

- Press the Channel/Screen Lock Button on the side of the remote to lock the keypad. A lock icon will appear on the

LCD screen.

- Press the button again to unlock the keypad.



Figure 5.2: Security Keypad Lock and Remote Range

6. IMPORTANT SAFETY INFORMATION

Please read and follow all safety instructions to ensure the well-being of your pet and the effectiveness of the training collar.

- **Proper Contact:** Ensure the contact points on the receiver collar have direct contact with your dog's skin on the underside of the neck. Improper contact can lead to inconsistent stimulation or skin irritation.
- **Wearing Duration:** Do not leave the receiver collar on your dog for more than 12 hours per day to prevent pressure necrosis (bed sores).

- **Initial Training Levels:** Always start training at the lowest vibration or static shock level and gradually increase if necessary. Observe your dog's reaction to determine the appropriate level.
- **Collar Fit:** Adjust the collar to be snug but not too tight. You should be able to fit one or two fingers between the collar and your dog's neck.
- **Supervision:** Always supervise your dog when using the training collar. Do not leave your dog unattended with the collar on.
- **Not for Aggressive Dogs:** This training collar is not intended for use on aggressive dogs. Consult a professional dog trainer for behavioral issues.
- **Skin Irritation:** Regularly check your dog's neck for any signs of irritation, redness, or sores. If irritation occurs, discontinue use and consult a veterinarian.

7. MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your Asrcs Dog Training Collar.

- **Cleaning:** Regularly clean the receiver collar and contact points with a damp cloth. Ensure they are dry before re-attaching to your dog.
- **Water Exposure:** The receiver is IPX7 waterproof, meaning it can withstand submersion up to 1 meter for 30 minutes. However, always ensure the charging port cover is securely closed before water exposure.
- **Battery Care:** Charge the devices regularly, even if not in frequent use, to maintain battery health. Store in a cool, dry place when not in use for extended periods.

Your browser does not support the video tag.

Video 7.1: Demonstrating the waterproof capabilities of the receiver collar.

8. TROUBLESHOOTING

If you encounter any issues with your Asrcs Dog Training Collar, refer to the following common problems and solutions:

- **Collar not responding to remote:**
 - Check if both remote and receiver are powered on and charged.
 - Ensure the remote and receiver are within the 1650FT operating range.
 - Verify that the remote and receiver are properly synced (refer to Section 4.4).
 - Check if the remote's keypad lock is engaged.
- **No stimulation (Beep, Vibration, Shock):**
 - Ensure the contact points are making proper skin contact with your dog.
 - Increase the intensity level of the chosen mode on the remote.
 - Test the shock function using the provided test light tool.
- **Collar LED indicator not working:**
 - The battery might be completely drained. Charge the receiver.

- If the issue persists after charging, contact customer support.

- **Collar is too loose or too tight:**

- Adjust the nylon strap according to your dog's neck size (refer to Section 4.3).

9. SPECIFICATIONS

Feature	Detail
Model Number	X12
Remote Range	Up to 1650 FT
Training Modes	Beep, Emergency Flashlight, Vibration (0-99), Static Shock (0-99)
Receiver Waterproof Rating	IPX7
Battery Type	Lithium Polymer (Rechargeable)
Charging Time	2-3 hours (approx.)
Collar Material	Nylon
Adjustable Collar Size	8 to 27.5 inches
Recommended Dog Weight	6 to 160 lbs
Item Weight	8.8 ounces
Item Dimensions (LxWxH)	3.6 x 1.8 x 0.8 inches

10. WARRANTY AND SUPPORT

For any warranty claims, technical support, or further assistance, please refer to the contact information provided in the original product packaging or consult the seller directly on the platform where the product was purchased.

Always retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question