

[Manuals.plus](#) /

› [Contigo](#) /

› Contigo Cortland Chill 2.0 Stainless Steel Water Bottle User Manual

## Contigo Cortland Chill 2.0

# Contigo Cortland Chill 2.0 Stainless Steel Water Bottle User Manual

### PRODUCT OVERVIEW

The Contigo Cortland Chill 2.0 Stainless Steel Water Bottle is designed for superior hydration, keeping beverages cold for up to 24 hours and hot for up to 6 hours. It features AUTOSEAL technology for spill-proof use, a hygienic spout cover, a secure lock button, and an integrated carry handle for convenience.





Image: Contigo Cortland Chill 2.0 Stainless Steel Water Bottle in Blueberry color.

## INITIAL SETUP

### Unpacking

- Remove all packaging materials and labels from the bottle.

### First Use Cleaning

Before initial use, wash the bottle and lid thoroughly. The lid is top-rack dishwasher safe. The stainless steel body should be hand washed with warm, soapy water.



Image: Underside of the lid, illustrating the 'PUSH TO CLEAN' feature for easy access to internal components.

## OPERATION

### Filling the Bottle

- Unscrew the lid by turning it counter-clockwise.
- Fill the bottle with your desired beverage. Do not overfill past the neck of the bottle.
- Screw the lid back on clockwise until it is securely tightened.







Image: Bottle with lid removed, illustrating the wide opening for easy filling and cleaning.

### Using the AUTOSEAL Lid

The AUTOSEAL technology ensures a 100% spill-proof and leak-proof experience. To drink, simply press the AUTOSEAL button located on the back of the lid. Release the button to automatically seal the spout.





Image: Close-up of the lid, highlighting the AUTOSEAL button for drinking.

### Spout Cover

The integrated spout cover protects the drinking area from dirt and germs. Flip the cover open before pressing the AUTOSEAL button to drink, and close it after use to maintain hygiene.





Image: Top view of the lid with the spout cover in the open position.

### **Secure Lock Button**

To prevent accidental pressing of the AUTOSEAL button, slide the lock button (located next to the AUTOSEAL button) to the locked position. Slide it back to the unlocked position before drinking.



Image: Top view of the lid, showing the secure lock button in its position.

### Integrated Carry Handle

The bottle features an integrated carry handle for easy and comfortable transport. The handle can be folded down when not in use.

## CARE AND MAINTENANCE

### Cleaning Instructions

- **Lid:** The lid is top-rack dishwasher safe. For thorough cleaning, open the underside of the lid by pressing the 'PUSH TO CLEAN' button. Ensure all parts are completely dry before reassembling.
- **Body:** Hand wash the stainless steel body with warm, soapy water. Do not use abrasive cleaners, scrubbers, or

harsh chemicals, as these can damage the finish and insulation.

- Do not use bleach or cleaners containing chlorine on any part of the bottle.

Storage

- Store the bottle with the lid off to allow for proper air circulation and prevent odors.

TROUBLESHOOTING

Leaking

- Ensure the lid is screwed on tightly and correctly aligned with the bottle threads.
- Check that the AUTOSEAL button is fully released and the spout cover is completely closed.
- Verify that the secure lock button is not stuck in an open position, which could allow the AUTOSEAL button to be pressed inadvertently.
- Inspect the lid's internal components for any debris or damage that might prevent a proper seal.

Poor Temperature Retention

- Confirm that the lid is completely sealed and the spout cover is closed after each use.
- Avoid filling with extremely hot liquids that could create excessive pressure, which might compromise the seal over time.

Splashing When Drinking

- If the bottle has been sealed for an extended period, a vacuum may form inside. Briefly press the AUTOSEAL button with the bottle upright and away from your face to release any built-up pressure before drinking.

SPECIFICATIONS

| Feature               | Detail                             |
|-----------------------|------------------------------------|
| Brand                 | Contigo                            |
| Model Name            | Cortland Chill 2.0                 |
| Model Number          | 2169255                            |
| Material              | Stainless Steel                    |
| Color                 | Blueberry                          |
| Capacity              | 24 oz (710 ml)                     |
| Item Weight           | 0.39 kg                            |
| Dimensions (W x H)    | 2.95"W x 10.7"H                    |
| Insulation            | Double-wall Vacuum-Insulated       |
| Temperature Retention | Cold for 24 hours, Hot for 6 hours |
| UPC                   | 607869299608                       |

## WARRANTY INFORMATION

The Contigo Cortland Chill 2.0 Stainless Steel Water Bottle is backed by a Limited Lifetime Warranty against manufacturing defects.

For complete details regarding warranty terms, conditions, and how to make a claim, please visit the official Contigo website or contact their customer support directly.

## CUSTOMER SUPPORT

Should you require further assistance, have questions about your product, or wish to register your Contigo Cortland Chill 2.0 water bottle, please refer to the following resources:

- **Official Contigo Store:** Visit the [Contigo Official Store on Amazon](#) for product information and updates.
- **Online FAQ:** Many common questions are answered in the Frequently Asked Questions section on the official Contigo website.
- **Contact:** For direct support, please use the contact information provided on the official Contigo website.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question