Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Nerf /
- > Nerf Ultra Strike Motorized Blaster User Manual

Nerf ULTRA STRIKE

Nerf Ultra Strike Motorized Blaster User Manual

Model: ULTRA STRIKE (F6024U50)

1. Introduction

The Nerf Ultra Strike Motorized Blaster is designed for high-performance dart firing, offering speed and precision in competitive play. This manual provides essential information for the safe and effective operation, assembly, and maintenance of your blaster.



Image: The Nerf Ultra Strike blaster, white and orange, with a red magazine and 10 grey AccuStrike darts laid out in front.

2. SAFETY INFORMATION

WARNING: TO AVOID EYE INJURY:

- · Do not aim at eyes or face.
- The use of eyewear is recommended for players and people within range.

- Use only official Nerf darts. Other darts may not meet safety standards.
- · Do not modify darts or the blaster.

WARNING: CHOKING HAZARD:

- May produce small parts.
- Not recommended for children under 3 years.

Recommended age: 8 years and up.

3. PACKAGE CONTENTS

Ensure all items listed below are present in your package:

- 1 x Nerf Ultra Strike Motorized Blaster
- 1 x 10-Dart Removable Magazine
- 10 x Nerf Ultra AccuStrike Darts



Image: The Nerf Ultra Strike blaster shown inside its retail packaging, highlighting the blaster and darts.

4. SETUP

4.1 Battery Installation

The Nerf Ultra Strike Blaster requires 6 x 1.5V AA alkaline batteries (not included).

- 1. Locate the battery compartment on the blaster.
- 2. Using a Phillips head screwdriver (not included), unscrew the battery compartment cover.
- 3. Insert 6 AA alkaline batteries, ensuring correct polarity (+/-).
- 4. Replace the battery compartment cover and secure it with the screw.

4.2 Magazine and Dart Loading

- 1. Load the 10 Nerf Ultra AccuStrike darts into the removable magazine. Ensure darts are fully seated.
- 2. Insert the loaded magazine firmly into the blaster's magazine well until it clicks into place.



Image: The back of the product box illustrating the integrated sight, clip storage, motorized function, and removable 10-dart clip.

5. OPERATING INSTRUCTIONS

5.1 Firing the Blaster

- 1. Ensure the blaster is loaded with darts and batteries are installed.
- 2. Hold the blaster firmly.
- 3. Press and hold the acceleration button (usually located below the trigger or on the side of the grip) to power up the motor. You will hear the motor spin up.
- 4. While holding the acceleration button, press the trigger to fire a dart.
- 5. Release the trigger to stop firing, or continue holding the acceleration button and pressing the trigger for rapid-fire action until the magazine is empty.



Image: A close-up view of the blaster's ergonomic grip and the two-stage trigger system, showing the acceleration button and firing trigger.

6. MAINTENANCE

- **Cleaning:** Wipe the blaster with a dry, soft cloth. Do not use water or cleaning solutions, as this can damage the electronic components.
- **Dart Care:** Keep darts clean and free from debris. Bent or damaged darts may affect performance and can jam the blaster.
- **Storage:** Store the blaster in a cool, dry place away from direct sunlight. Remove batteries if the blaster will not be used for an extended period to prevent corrosion.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blaster does not power on.	Batteries are dead or incorrectly installed.	Replace batteries with new AA alkaline batteries, ensuring correct polarity.
Darts are not firing or are jamming.	Magazine not fully inserted; darts are damaged or not official Nerf Ultra darts; dart jam.	Ensure magazine is fully inserted. Use only official, undamaged Nerf Ultra darts. Check for and clear any dart jams.
Motor spins but darts do not fire.	Magazine is empty or darts are not loaded correctly.	Reload magazine with darts, ensuring they are fully seated.

8. Specifications

Model: ULTRA STRIKE (F6024U50)

Brand: Nerf

Product Dimensions (L x W x H): 60.96 x 6.67 x 27.62 cm (24 x 2.63 x 10.87 inches)

Weight: 990 grams (2.18 lbs)

Recommended Age: 8 years and up

Batteries Required: Yes, 6 x 1.5V AA Alkaline Batteries (not included)

Material: Plastic

Dart Type: Nerf Ultra AccuStrike Darts (compatible only with Nerf Ultra darts)

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official Nerf website. Keep your purchase receipt as proof of purchase. **Online Support:** www.hasbro.com/en-us/consumer-care

© 2024 Nerf. All rights reserved.

Related Documents - ULTRA STRIKE

OLTAN

NERF ULTRA DORADO Blaster: Instructions and Safety Guide

Official instructions for the NERF ULTRA DORADO blaster, including loading, firing, safety warnings, and troubleshooting. Learn how to use your NERF ULTRA DORADO safely and effectively.



Nerf Pro Stryfe X Dart Blaster: User Manual and Safety Instructions

Comprehensive guide to operating the Nerf Pro Stryfe X Dart Blaster, including charging, loading, firing, safety warnings, and storage. Features detailed instructions for safe play and regulatory information.



NERF N-Strike Elite AccuStrike FalconFire Blaster: Instructions and Features

Official instructions and overview for the NERF N-Strike Elite AccuStrike Series FalconFire dart blaster, including how to load, fire, and store the toy. Features product details and safety information.



Nerf N-Strike Elite Strongarm Blaster: User Guide

Official instructions for the Nerf N-Strike Elite Strongarm toy blaster. Learn how to load darts, fire single shots, and use the slam-fire feature for rapid firing. Includes safety warnings and product details.



Nerf Roblox Arsenal Pulse Laser Blaster Instructions

Comprehensive guide on how to operate, load, fire, and clear jams for the Nerf Roblox Arsenal Pulse Laser motorized dart blaster. Includes safety warnings and battery information.



Nerf Ultra One Blaster: Assembly, Loading, and Firing Instructions

A comprehensive guide to assembling, loading, and operating the Nerf Ultra One Motorized Blaster, including important safety information and troubleshooting tips.