

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

havit SK802BT-BLACK-INT

HAVIT SK802BT Bluetooth Speaker User Manual

Model: SK802BT-BLACK-INT

INTRODUCTION

Thank you for choosing the HAVIT SK802BT Bluetooth Speaker. This portable outdoor speaker is designed to deliver premium sound quality with strong bass and high pitch, offering versatile connectivity options including Bluetooth, TF card, FM radio, and AUX modes. Its lightweight and durable construction makes it ideal for easy portability and outdoor use. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new speaker.



This image displays the HAVIT SK802BT Bluetooth Speaker from the front. It features a robust black casing with two large speaker grilles on either side. In the center, there is a vertical control panel with orange buttons: 'M' for mode, '-' for volume down/previous track, '+' for volume up/next track, and a play/pause button. An orange, flexible carrying strap is visible across the top of the speaker.

SETUP

Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port

and the other end to a compatible USB power adapter (not included) or a computer's USB port. The charging indicator light will typically turn off or change color once fully charged.

Powering On/Off

- To power on: Press and hold the power button (usually integrated with the play/pause button or a dedicated button) for a few seconds until you hear an audible prompt or see an indicator light.
- To power off: Press and hold the power button again for a few seconds.

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing blue LED or an audible prompt). If not, press the 'M' (Mode) button to switch to Bluetooth mode.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "HAVIT SK802BT" from the list of devices.
4. Once paired, the speaker will indicate a successful connection, and the LED light will typically become solid blue.

TWS (True Wireless Stereo) Connection

The SK802BT supports TWS connection, allowing two SK802BT speakers to play audio simultaneously for a stereo experience.

1. Ensure both SK802BT speakers are powered on and not connected to any Bluetooth device.
2. On one of the speakers (this will be the primary speaker), double-press the 'M' (Mode) button or a dedicated TWS button (if available). The speaker will enter TWS pairing mode.
3. The primary speaker will automatically search for and connect to the secondary speaker. Once connected, you will hear an audible confirmation.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section. Audio will play through both speakers in stereo.

OPERATING INSTRUCTIONS

Mode Switching

Press the 'M' (Mode) button to cycle through the available modes: Bluetooth, TF Card, FM Radio, and AUX.

Volume Control

- Volume Up: Short press the '+' button.
- Volume Down: Short press the '-' button.

Playback Control (Bluetooth/TF Card Mode)

- Play/Pause: Short press the Play/Pause button.
- Next Track: Long press the '+' button.
- Previous Track: Long press the '-' button.

FM Radio Operation

- Switch to FM mode using the 'M' button.
- To auto-scan and save channels: Short press the Play/Pause button. The speaker will scan and store available FM stations.
- To switch channels: Use the '+' and '-' buttons to navigate through saved stations.

AUX Mode

Connect an audio device to the speaker's AUX input port using a 3.5mm audio cable (not included). The speaker will automatically switch to AUX mode or can be manually selected using the 'M' button.

App Control

The HAVIT SK802BT speaker supports app control. Download the official HAVIT app from your device's app store to unlock additional features and control options. Follow the in-app instructions for connecting your speaker.

MAINTENANCE

Cleaning

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners, alcohol, or other chemical solvents, as these may damage the surface. Avoid getting moisture into any openings.

Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery at least once every three months to maintain battery health.

Battery Care

To prolong the lifespan of the built-in battery, avoid fully discharging it frequently. Charge the speaker when the low battery indicator appears. Do not expose the speaker to high temperatures or attempt to replace the battery yourself.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed correctly.	Charge the speaker fully. Press and hold the power button for 3-5 seconds.
No sound.	Volume too low; Incorrect mode; Device not connected.	Increase speaker and device volume. Ensure correct mode (BT, AUX, TF, FM). Re-pair Bluetooth or check AUX cable connection.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker.	Ensure speaker is in Bluetooth pairing mode. Turn on Bluetooth on your device. Move device closer to speaker (within 10 meters). Forget previous pairings on your device and try again.

Problem	Possible Cause	Solution
Poor sound quality/distortion.	Volume too high; Low battery; Interference; Source audio quality.	Reduce volume. Charge the speaker. Move away from other electronic devices. Try a different audio source.
TWS connection fails.	Speakers already paired to a device; Speakers too far apart.	Ensure both speakers are disconnected from any Bluetooth device. Place speakers close to each other. Follow TWS pairing steps carefully.

SPECIFICATIONS

Model: SK802BT-BLACK-INT

Brand: HAVIT

Connectivity Technology: Bluetooth

Wireless Communication Technology: Bluetooth

Power Source: Battery Powered

Speaker Maximum Output Power: 10 Watts

Special Feature: Lightweight, TWS Connection Support

Control Method: App, Buttons

Color: Black

Is Waterproof: No

Item Weight: 2.83 pounds

Package Dimensions: 11.42 x 8.46 x 5.39 inches

Manufacturer: HAVIT Online

WARRANTY AND SUPPORT

HAVIT products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official HAVIT website. Please retain your proof of purchase for warranty claims.

For further assistance, you may contact HAVIT customer support through their official channels, typically found on their website or product packaging.