

[manuals.plus](#) /› [ZWILLING](#) /› [ZWILLING Enfinigy Wireless Charging Scale Instruction Manual \(Model 53104-400-0\)](#)

ZWILLING 53104-400-0

ZWILLING Enfinigy Wireless Charging Scale Instruction Manual

Model: 53104-400-0

1. INTRODUCTION

The ZWILLING Enfinigy Wireless Charging Scale is a modern appliance designed for precise ingredient measurement and convenient smart device charging. It is an indispensable tool for achieving accurate results in baking and cooking, as well as for portion control and converting measurements. This scale features a slim, lightweight design with a seamless glass surface for easy cleaning.

2. KEY FEATURES

- **High Capacity:** Weighs up to 22lb/10kg.
- **High Accuracy:** Accurate to 0.1oz/0.1g for precise measurements.
- **Integrated Wireless Charging:** Charge your smartphone or tablet by simply placing it in the center of the scale surface.
- **Easy-to-Clean Surface:** Hygienic, seamless glass surface allows direct weighing and easy cleanup.
- **Large Weighing Surface:** Ensures the LCD display remains visible even with large quantities and containers.
- **Tare Function:** Allows you to factor in container weight for accurate net measurements.
- **Rechargeable Battery:** Built-in rechargeable battery, powered via included micro USB cord.

3. SETUP

3.1 Unpacking

Carefully remove the ZWILLING Enfinigy Wireless Charging Scale from its packaging. Ensure all components, including the scale and micro USB charging cable, are present.

3.2 Initial Charging

Before first use, fully charge the scale's internal battery using the provided micro USB cable. Connect the cable to the scale's charging port and a suitable USB power adapter (not included). The charging indicator lights will show the charging status.



Image: The USB-C charging port located on the side of the ZWILLING Enfinigy Wireless Charging Scale. A white USB-C cable is shown being inserted into the port, indicating how to charge the scale's internal battery.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

To turn the scale on, press the power button located on the front edge. The LCD display will illuminate. To turn off, press and hold the power button until the display turns off. The scale will automatically shut off after a period of inactivity to conserve battery.



Image: A detailed view of the scale's front edge, highlighting the power button and the subtle indicator lights for wireless charging and battery status.

4.2 Switching Measurement Units

The scale can measure in grams (g) and ounces (oz). To switch between units, press the unit button (often integrated with the power button or a separate button) while the scale is on. The display will show the currently selected unit.

4.3 Tare Function

The tare function allows you to weigh ingredients in a container without including the container's weight. Place an empty container on the scale, then press the "Tare" button (often labeled "Zero"). The display will reset to zero. You can then add ingredients, and only their weight will be shown.



Image: A large grey cooking pot is placed on the scale, demonstrating the scale's ability to handle larger items and the visibility of the display even with a wide container. This illustrates the use of the tare function.

4.4 Wireless Charging Your Smart Device

To use the wireless charging feature, ensure the scale is sufficiently charged. Place your compatible smartphone or tablet directly on the center of the scale's surface. The wireless charging indicator light on the scale will illuminate, and your device should begin charging. For optimal charging, ensure the device is centered on the charging pad.



Image: A smartphone is positioned on the ZWILLING Enfinigy Wireless Charging Scale, displaying a low battery icon and indicating that it is receiving a wireless charge. This highlights the dual functionality of the product.



Image: An overhead shot of the ZWILLING Enfinigy Wireless Charging Scale with a smartphone centered on its surface, clearly showing the wireless charging symbol on both the scale and the phone, confirming active charging.

Your browser does not support the video tag.

Video: This video demonstrates how to properly place a smart device on the ZWILLING Enfinigy Wireless Charging Scale to initiate wireless charging. It highlights the correct alignment for effective power transfer.

Your browser does not support the video tag.

Video: A short video showcasing the dual functionality of the ZWILLING Enfinigy as both a food scale and a wireless charging station. It quickly illustrates the convenience of having both features in one device.

5. MAINTENANCE

5.1 Cleaning

The ZWILLING Enfinigy Wireless Charging Scale features a seamless glass surface that is easy to clean. Wipe the surface with a damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the glass or electronic components. Ensure the scale is completely dry before storage or next use.

5.2 Storage

Store the scale in a dry place away from extreme temperatures and humidity. Its slim design allows for easy storage in drawers or on shelves.

6. TROUBLESHOOTING

- **Inaccurate Readings:** Ensure the scale is placed on a flat, stable surface. Avoid placing it near vibrating appliances or in drafty areas. Recalibrate if necessary (refer to manufacturer's specific instructions if available, as general scales may not have user calibration).
- **Scale Not Turning On:** Check the battery level. If the scale is rechargeable, ensure it is fully charged.
- **Wireless Charging Not Working:**
 - Ensure your smart device is compatible with Qi wireless charging.
 - Verify the scale's battery is charged.
 - Ensure your device is centered correctly on the scale's charging area.
 - Remove any thick phone cases that might interfere with wireless charging.
- **Display Issues:** If the display shows an error message or is unresponsive, try turning the scale off and on again. If the issue persists, contact customer support.

7. SPECIFICATIONS

Brand	ZWILLING
Model Number	53104-400-0
Color	Silver
Material	Stainless Steel
Weight Limit	22 Pounds / 10 Kilograms
Readout Accuracy	0.1 grams
Display Type	LCD
Special Feature	Wireless Charging Station
Product Dimensions	9.4 x 11.5 x 1.8 inches
Item Weight	2 Pounds

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official ZWILLING website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

For additional product information and support, visit the [ZWILLING Store on Amazon](#).