

Remington S9531

Remington Shine Therapy 2-inch Hair Straightener

Model: S9531

User Manual

1. IMPORTANT SAFEGUARDS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:
 - Always unplug this appliance immediately after using it.
 - Do not use while bathing or in a shower.
 - Do not place or store this appliance where it can fall or be pulled into a tub or sink.
 - Do not place in or drop into water or other liquid.
 - If an appliance falls into water, unplug it immediately. Do not reach into the water.
- **WARNING:** To reduce the risk of burns, electrocution, fire, or injury to persons:
 - This appliance should never be left unattended when plugged in.
 - Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
 - Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
 - Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
 - Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
 - Never use while sleeping.
 - Never drop or insert any object into any opening.
 - Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
 - Do not use an extension cord with this appliance.

- This appliance is hot when in use. Do not let eyes or bare skin touch heated surfaces.
- Do not place the heated unit directly on any surface while it is hot or plugged in.

2. PRODUCT OVERVIEW

The Remington Shine Therapy 2-inch Hair Straightener is designed to provide smooth, shiny, and frizz-free results. Its advanced features contribute to optimal hair health and styling efficiency.

Key Features:

- **Advanced Ceramic Plates:** Features 9X more ceramic than standard Remington models, ensuring even and consistent heat distribution.
- **Argan Oil & Keratin Infusion:** Plates are infused with antioxidant-rich Argan oil, protein-packed Keratin, and a micro-conditioner to enhance hair health and luster.
- **2-inch Wide Floating Plates:** Provides full coverage and an effortless glide, reducing styling time.
- **2X Shine-Enhancing Technology:** The micro-conditioner combined with advanced ceramic technology helps reduce frizz and delivers radiant shine.
- **High Heat Capability:** Reaches up to 450°F (232°C) for effective styling on various hair types.
- **Digital Temperature Display:** Allows for precise temperature control.
- **Travel-Friendly Design:** Compact and easy to use for styling at home or while traveling.



2x Shine Enhancing TECHNOLOGY*

*micro-conditioner + advanced ceramic

Image: Close-up of the straightener's digital display and control buttons.



Image: The straightener with its dimensions (10.8 inches length, 2.2 inches width) indicated.

3. SETUP

1. Unpack the hair straightener and remove all packaging materials.
2. Inspect the appliance for any signs of damage. Do not use if damaged.
3. Ensure your hands are dry before plugging the appliance into a standard electrical outlet.

4. OPERATING INSTRUCTIONS

Follow these steps for effective and safe hair straightening:

1. Plug in the Remington Shine Therapy hair straightener. The digital display will illuminate.
2. Press and hold the power button (usually marked with a ⏻ symbol) to turn on the appliance.
3. Allow the straightener to heat up. It typically reaches the desired temperature in approximately 30 seconds.
4. Adjust the temperature using the '+' and '-' buttons. The temperature can be set up to 450°F (232°C).

5. Section your hair for easier and more consistent styling.
6. Place a section of hair between the advanced ceramic plates, ensuring the plates come in full contact with the hair.
7. Glide the flat iron smoothly down the length of the hair, applying even pressure. Avoid holding the straightener in one place for too long to prevent heat damage.
8. Repeat this process for all sections of hair, adjusting the heat setting as needed for different hair types or desired results.
9. After use, turn off the device by pressing and holding the power button, then unplug it from the electrical outlet.
10. Allow the appliance to cool completely before storing.

Recommended Temperature Settings:

Use the following guidelines to select the appropriate temperature for your hair type:



**CREATE A LOOK THAT
RADIATES SHINE
AND CONFIDENCE**

**FROM STRAIGHT, SHINY LOCKS TO
SULTRY, SMOOTH CURLS, IT'S THE PERFECT
STYLING TOOL TO ACHIEVE YOUR FAVORITE LOOK!**

Image: Recommended temperature settings for various hair types, including fine, color-treated, textured, and thick hair.

Hair Type	Temperature Range
Fine or Easy to Style	310°F - 350°F (154°C - 177°C)
Color Treated	350°F - 390°F (177°C - 199°C)
Textured	350°F - 390°F (177°C - 199°C)
Thick or Hard to Style	370°F - 450°F (188°C - 232°C)




Image: A user demonstrating the application of the straightener on a section of hair.

5. MAINTENANCE

Cleaning:

- Ensure the appliance is turned off, unplugged, and completely cool before cleaning.
- Wipe the plates and exterior surfaces with a damp cloth. Do not use abrasive cleaners or solvents.
- Do not immerse the appliance in water.

Storage:

- Store the appliance in a cool, dry place, away from children.
- Do not wrap the cord around the appliance, as this can cause premature wear and breakage.
- Use the plate lock feature (if available) to keep the plates closed for compact storage.

6. TROUBLESHOOTING

- **Appliance not heating up:** Ensure the straightener is properly plugged into a working electrical outlet and the power button has been pressed and held until the display illuminates.
- **Poor styling results:** Verify that the correct temperature setting is selected for your hair type. Ensure hair is clean, dry, and sectioned properly before styling.
- **Frizz persists:** Ensure hair is completely dry before use. Consider using a heat protectant spray.

7. SPECIFICATIONS

- **Product Dimensions:** 10.8 x 2.2 x 2.2 inches
- **Item Model Number:** S9531
- **Weight:** 1.26 Pounds
- **UPC:** 074590556070
- **Manufacturer:** Remington
- **ASIN:** B09RTL3V3F
- **Product Benefits:** Straightening, Shine Enhancing, Frizz Reduction
- **Plate Material:** Advanced Ceramic infused with Argan Oil & Keratin
- **Plate Size:** 2 inches (Wide Floating Plates)
- **Color:** Champagne
- **Max Temperature:** 450°F (232°C)

8. WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please refer to the warranty card included with your product or visit the official Remington website. Keep your proof of purchase for any warranty claims.