

[Manuals.plus](#) /

› [Kastar](#) /

› Kastar K7006 Battery 2-Pack Replacement for Kodak KLIC-7006 Instruction Manual

Kastar BA-2B-K7006-A

Kastar K7006 Battery 2-Pack Replacement for Kodak KLIC-7006 Instruction Manual

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Kastar K7006 Lithium-ion replacement batteries. These batteries are designed to be compatible with various Kodak camera models and the Kodak KLIC-7006 charger. Please read this manual thoroughly before using the product.

SAFETY GUIDELINES

Adhere to the following safety guidelines to prevent damage to the battery, camera, or personal injury:

- Kastar lithium-ion battery cells meet UL1642 & CE safety standards.
- The battery pack includes built-in over-charge, over-discharge, over-voltage, over-current, and over-heating protection circuits.
- Do not disassemble, crush, puncture, or short-circuit the battery.
- Do not expose the battery to high temperatures (above 60°C / 140°F) or direct sunlight.
- Keep batteries away from water and fire.
- Dispose of used batteries according to local regulations.
- Keep out of reach of children.

PACKAGE CONTENTS

The package includes:

- Two (2) Kastar K7006 Lithium-ion Batteries




Kastar®
Convenience of Life

Kastar®
Convenience of Life

**HIGH
CAPACITY**

**Battery for
Camera & Camcorder**



Help us Improve!

Dear customer,

Thanks for you purchasing from us!
I would be happy to hear your opinion
about the product. What is good, What
can be better. Please share your
thoughts. They will help us improve.



Image: The retail packaging for the Kastar K7006 battery 2-pack, showing product branding and key features.

COMPATIBILITY

The Kastar K7006 battery is compatible with the following models:

Compatible Battery Models:

- Kodak KLIC-7006
- Kodak LB-012

Compatible Charger Models:

- Kodak KLIC-7006 Charger

Compatible Camera Models:

- Kodak Easyshare: M22, M23, M200, M215, MD30, M522, M530, M531, M532, M550, M552, M575, M577, M580, M583, M750, M873, M883, M5350, M5370
- Kodak Easyshare Mini: M200
- Kodak Easyshare Touch: M577
- Kodak PixPro: FZ51 (KDK-FZ-51BL), FZ52, FZ53, SL5 Smart Lens Camera

INSTALLATION

To install the Kastar K7006 battery into your compatible camera:

1. Ensure the camera is powered off.
2. Locate the battery compartment on your camera, typically on the bottom or side.
3. Open the battery compartment cover.
4. Insert the Kastar K7006 battery, aligning the gold contacts on the battery with the contacts inside the camera's battery compartment. Ensure the battery is oriented correctly according to the polarity indicators (+/-) if present.
5. Gently push the battery until it clicks into place or is securely seated.
6. Close the battery compartment cover firmly.



Image: A Kastar KLIC-7006 Lithium-ion battery shown in a clear protective case, highlighting its contacts and labeling.

CHARGING AND OPERATION

Charging the Battery:

1. Remove the battery from the camera.
2. Insert the Kastar K7006 battery into a compatible Kodak KLIC-7006 charger.
3. Connect the charger to a power source.
4. Observe the charger's indicator light for charging status. Charging is complete when the indicator light changes (refer to your charger's manual for specific indications).
5. Disconnect the charger from the power source and remove the fully charged battery.

Operating Your Camera:

- After installing a charged battery, power on your camera.
- Monitor the battery level indicator on your camera's display.

- For optimal performance, avoid completely draining the battery before recharging.

CARE AND STORAGE

- Store batteries in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, charge batteries to approximately 50% capacity.
- Avoid storing batteries in a completely discharged state for extended periods, as this can reduce their lifespan.
- Clean battery contacts periodically with a dry, clean cloth to ensure good connection.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Battery not charging.	Incorrectly inserted battery, faulty charger, dirty contacts.	Ensure battery is correctly inserted. Check charger connection. Clean battery and charger contacts. Try a different charger if available.
Camera not powering on.	Battery not charged, battery incorrectly installed, camera issue.	Ensure battery is fully charged. Reinstall battery correctly. Test with another known good battery if possible.
Short battery life.	Frequent video recording, extreme temperatures, battery aging.	Reduce video recording time. Operate camera within recommended temperature ranges. Consider replacing older batteries.

TECHNICAL SPECIFICATIONS

Feature	Detail
Battery Type	Lithium-ion
Battery Voltage	3.7V
Battery Capacity	1400mAh
Product Dimensions	1.22 x 0.23 x 1.55 inches
Item Weight	1.5 ounces
Model Number	BA-2B-K7006-A
Manufacturer	Kastar

WARRANTY AND SUPPORT

Kastar provides an **18-month warranty** for this product, as indicated on the product packaging. For warranty claims, technical assistance, or any questions regarding your Kastar K7006 batteries, please contact Kastar customer support through their official channels or the retailer where the product was purchased.

Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09RV8LPDK>

More documents and user manuals: <https://manuals.plus/>