

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ronix](#) /
- › [Ronix Vault Wakeboard and Divide Boots Instruction Manual](#)

Ronix Vault Wakeboard 140 cm with Divide Boots 7.5-11.5

Ronix Vault Wakeboard and Divide Boots Instruction Manual

Model: Vault Wakeboard 140 cm with Divide Boots 7.5-11.5 (Model Number: 222071-986280)

1. INTRODUCTION

Thank you for choosing the Ronix Vault Wakeboard and Divide Boots. This manual provides essential information for the proper assembly, safe use, and maintenance of your new wakeboarding equipment. Please read all instructions carefully before use to ensure your safety and the longevity of the product.



Image 1.1: The official Ronix Wakeboards logo.

2. SAFETY INFORMATION

Wakeboarding is an inherently dangerous sport that can result in serious injury or death. Always follow these safety guidelines:

- Always wear a U.S. Coast Guard approved personal flotation device (PFD) suitable for wakeboarding.
- Never wakeboard under the influence of alcohol or drugs.
- Ensure the boat driver is experienced and aware of all safety procedures.
- Maintain a safe distance from other boats, swimmers, and obstacles.
- Inspect your equipment (board, bindings, rope, handle) before each use for any signs of wear or damage.
- Do not attempt maneuvers beyond your skill level.
- Be aware of water conditions, weather, and potential hazards.

3. PRODUCT COMPONENTS

Your Ronix Vault Wakeboard package includes the following main components:

- Ronix Vault Wakeboard (140 cm)
- Ronix Divide Wakeboard Boots (Size 7.5-11.5)
- Mounting hardware (screws and washers for binding attachment)



Image 3.1: The Ronix Vault Wakeboard (140 cm) paired with Ronix Divide Boots (7.5-11.5).

4. SETUP INSTRUCTIONS

4.1 Attaching the Divide Boots to the Vault Wakeboard

- 1. Identify Stance:** Determine your preferred stance (regular or goofy) and the desired width between your feet. The board features multiple insert patterns to accommodate various stances.
- 2. Position Boots:** Place the Divide Boots onto the board's inserts. Ensure the boots are centered over the desired insert pattern. The Vault board is designed with a 3-stage rocker, which influences ride characteristics; proper boot placement is key for balance and control.
- 3. Align and Secure:** Align the boot's base plate with the chosen inserts. Insert the provided screws through the boot's base plate and into the board's inserts.
- 4. Tighten Screws:** Using a screwdriver, hand-tighten all screws evenly until snug. Do not overtighten, as this can damage the board or the binding inserts. Periodically check screw tightness before each ride.

4.2 Adjusting Divide Boots

The Divide Boots feature a lacing system for a secure and comfortable fit. Adjust the laces to ensure your foot is snug but not overly constricted. A proper fit prevents excessive movement within the boot, which can lead to discomfort or loss of control.

5. OPERATING INSTRUCTIONS

5.1 Understanding Your Vault Wakeboard

The Ronix Vault Wakeboard is designed with specific characteristics to enhance your riding experience:

- 3-Stage Rocker:** The Vault features an exaggerated 3-stage rocker, which provides a more aggressive pop off the wake. This design offers higher lift and a more vertical trajectory for jumps.
- Energy Response:** The board's construction provides a balanced energy response, offering a blend of stored energy for power generation and neutral reaction for consistent control.




Image 5.1: Diagram explaining different rocker types (3-stage, continuous, hybrid) and energy response levels (stored, neutral,

instant) in Ronix wakeboards. The Vault model utilizes a 3-stage rocker.

5.2 Getting Started

1. **Water Start Position:** Sit in the water with your knees bent, the board perpendicular to the boat, and the handle held firmly. Keep your arms straight and let the boat pull you up.
2. **Standing Up:** As the boat accelerates, allow the board to plane. Gradually stand up, keeping your weight centered over the board. Avoid pulling on the handle; let the boat do the work.
3. **Stance and Balance:** Once standing, maintain a balanced stance with knees slightly bent. The Vault's design assists in stability for beginner to intermediate riders.



Image 5.2: A rider on a Ronix Vault Wakeboard, demonstrating its performance on the water.

6. MAINTENANCE

Proper maintenance extends the life of your wakeboard and boots.

- **Rinse After Use:** After each use, rinse the board and boots thoroughly with fresh water to remove salt, chlorine, and debris.
- **Dry Completely:** Allow the board and boots to air dry completely in a shaded, well-ventilated area before storage. Avoid direct sunlight for prolonged periods, as UV rays can degrade materials.
- **Inspect Hardware:** Regularly check all screws and binding hardware for tightness. Retighten as necessary.
- **Storage:** Store your wakeboard and boots in a cool, dry place, away from extreme temperatures. Consider using a board bag for added protection during transport and storage.
- **Binding Care:** Inspect the laces and straps of your Divide Boots for wear. Clean any dirt or sand from the boot interiors.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Issue	Possible Cause	Solution
Bindings feel loose	Screws have loosened over time.	Hand-tighten all binding screws. Check before each ride.
Difficulty getting up on the board	Incorrect body position, pulling on the handle, insufficient boat speed.	Keep arms straight, knees bent, let the boat pull you. Ensure consistent boat speed.

Issue	Possible Cause	Solution
Foot discomfort in boots	Boots too tight or too loose, improper sock choice.	Adjust laces for a snug but comfortable fit. Wear appropriate wakeboarding socks.
Board feels unstable	Incorrect stance width or angle, uneven weight distribution.	Experiment with binding angles and stance width. Practice weight distribution.

8. SPECIFICATIONS

- **Brand:** Ronix
- **Model:** Vault Wakeboard
- **Model Number:** 222071-986280
- **Board Length:** 140 cm
- **Boot Model:** Divide Boots
- **Boot Size:** 7.5-11.5 (US Men's)
- **Board Material:** Fiberglass
- **Rocker Type:** 3-Stage
- **UPC:** 840298202171

9. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the official Ronix website or contact your authorized Ronix dealer. Keep your proof of purchase for any warranty claims.

For further assistance, you may visit the [Ronix Store on Amazon](#).