

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Farberware](#) /

› [Farberware Dual Brew Coffee Maker Instruction Manual](#)

Farberware 655772020932

Farberware Dual Brew Coffee Maker Instruction Manual

Model: 655772020932

INTRODUCTION

Welcome to the world of convenient coffee brewing with your new Farberware Dual Brew Coffee Maker. This versatile appliance is designed to cater to all your coffee needs, whether you prefer a full pot for sharing or a quick single-serve cup. Its intuitive controls and dual brewing capabilities make it an essential addition to any kitchen.



Figure 1: Front view of the Farberware Dual Brew Coffee Maker.

SETUP

Before first use, ensure all packaging materials are removed. Wash the carafe, filter basket, and single-serve components in warm, soapy water. Rinse thoroughly and dry.

Initial Setup Steps:

1. Place the coffee maker on a flat, stable, heat-resistant surface near an electrical outlet.
2. **For Carafe Brewing:** Open the lid on the left side. Insert the reusable filter or a paper filter into the filter basket. Add desired amount of ground coffee. Close the lid.
3. **For Single-Serve Brewing:** Open the lid on the right side. Insert a K-cup or the reusable single-serve filter with ground coffee. Close the lid.
4. **Add Water:** Open the water reservoir lid at the back. Fill the reservoir with fresh, cold water up to the desired

level for either carafe or single-serve brewing. *Do not overfill.*

5. Plug the power cord into a standard 120V AC electrical outlet. The digital display will illuminate.



Figure 2: Top view showing the carafe filter basket (left) and single-serve K-cup holder (right).

OPERATING INSTRUCTIONS

Setting the Clock:

- Press the **HOUR** button to set the hour.
- Press the **MIN** button to set the minutes.
- The clock will automatically set after a few seconds of inactivity.

Brewing a Full Pot (Carafe):

1. Ensure the carafe is placed on the warming plate.
2. Prepare the left side with ground coffee and water as described in the Setup section.
3. Press the **BREW** button. The coffee maker will begin brewing.
4. To program a delayed brew, press the **PROG** button, then set the desired brew time using the **HOUR** and **MIN** buttons. Press **AUTO** to confirm.

Brewing a Single-Serve Cup:

1. Place your mug on the single-serve drip tray.
2. Prepare the right side with a K-cup or reusable filter with ground coffee and water as described in the Setup section.
3. Press the **CAPSULE** button for K-cup brewing or **GROUND** for single-serve ground coffee.
4. The coffee maker will begin brewing your single cup.



Figure 3: The coffee maker ready for brewing, showing both carafe and single-serve options.



Figure 4: Options for single-serve brewing: a K-cup or a reusable filter for ground coffee.

MAINTENANCE

Daily Cleaning:

- Unplug the coffee maker before cleaning.
- Wash the carafe, carafe lid, filter basket, and single-serve components (K-cup holder, reusable filter) in warm, soapy water. These parts are generally top-rack dishwasher safe, but hand washing is recommended for longevity.
- Wipe the exterior of the coffee maker with a soft, damp cloth. Do not immerse the unit in water.

Descaling (Monthly or as needed):

Mineral deposits from water can build up over time, affecting performance. Descaling your coffee maker regularly.

1. Fill the water reservoir with a mixture of one part white vinegar and two parts water.
2. Place the empty carafe on the warming plate.
3. Run a full brew cycle without coffee.
4. After the cycle, let the solution sit in the carafe for 15-20 minutes.
5. Discard the solution and rinse the carafe thoroughly.
6. Run 2-3 cycles with fresh, clean water to flush out any remaining vinegar taste.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee grounds in cup (single-serve)	K-cup not properly punctured; reusable filter overfilled or not seated correctly.	Ensure K-cup is firmly seated. Do not overfill reusable filter; ensure it is properly closed and placed.
Machine not brewing / only small amount of coffee	Insufficient water in reservoir; mineral buildup; machine malfunction.	Check water level. Perform descaling procedure. If problem persists, contact customer support.
Clock losing time	Internal clock mechanism issue.	Reset the clock. If it consistently loses time, contact customer support.
Coffee not hot enough	Mineral buildup; warming plate issue.	Perform descaling procedure. Ensure carafe is properly seated on warming plate.

SPECIFICATIONS

- **Brand:** Farberware
- **Model Number:** 655772020932
- **Product Dimensions:** 10"D x 14"W x 14"H
- **Coffee Maker Type:** Drip Coffee Machine
- **Filter Type:** Paper (and reusable included)
- **Included Components:** Carafe, Single-serve K-cup holder, Reusable single-serve filter
- **Operation Mode:** Fully Automatic
- **Voltage:** 120 Volts
- **Human Interface Input:** Touchscreen
- **Item Weight:** 15.8 ounces



Figure 5: Product dimensions for proper placement.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Farberware website. Keep your purchase receipt for warranty claims.

If you encounter any issues not covered in this manual, please contact Farberware customer service for assistance.

Related Documents - 655772020932

<p>FARBERWARE DUAL BREW COFFEE MAKER</p>  <p>Please read this manual carefully before operating your unit and retain for future reference. No gift box is not included.</p> <p>814100109</p>	<p>Farberware Dual Brew Coffee Maker - User Manual</p> <p>Comprehensive user manual for the Farberware Dual Brew Coffee Maker, covering important safety instructions, parts identification, operation, brewing methods for single-serve and carafe, cleaning, maintenance, troubleshooting, and technical data.</p>
<p>FARBERWARE DUAL BREW COFFEE MAKER</p>  <p>Please read this manual carefully before operating your unit and retain for future reference. No gift box is not included.</p> <p>814100109</p>	<p>Farberware Dual Brew Coffee Maker User Manual</p> <p>Comprehensive user manual for the Farberware Dual Brew Coffee Maker, covering important safety instructions, parts identification, operation, brewing methods for single-serve and carafe, cleaning, maintenance, descaling, troubleshooting, and technical data.</p>
<p>FARBERWARE 12 CUP COFFEE MAKER</p>  <p>Please consider the option for recycling your unit and do not apply for a refund when you no longer use it.</p> <p>814100109</p>	<p>Farberware 12-Cup Coffee Maker (Model 103744) - User Manual</p> <p>Comprehensive user manual for the Farberware 12-Cup Coffee Maker, Model 103744. Includes setup, operation, cleaning, troubleshooting, and warranty information.</p>
 <p>FARBERWARE MILLENNIUM</p> <p>USE & CARE INSTRUCTIONS</p>	<p>Farberware FES15B Espresso Maker: Use and Care Instructions</p> <p>Comprehensive use and care instructions for the Farberware Millennium FES15B Espresso Maker, covering important safety precautions, operation, brewing espresso, preparing cappuccino, user maintenance, descaling, and warranty information.</p>
 <p>FARBERWARE SPECIAL SELECT</p> <p>USE & CARE INSTRUCTIONS</p>	<p>Farberware Dual Thermal Carafe Coffeemaker Use & Care Instructions</p> <p>Comprehensive use and care instructions for the Farberware Dual Thermal Carafe Coffeemaker, including safety guidelines, brewing coffee and tea, cleaning, storage, and warranty information for models FSCM200M, FSCM200RM, FSCM200BM, and FSCM200CBM.</p>
 <p>FARBERWARE SPECIAL SELECT</p> <p>USE & CARE INSTRUCTIONS</p>	<p>Farberware Dual Thermal Carafe Coffeemaker: Use & Care Instructions</p> <p>Detailed use and care guide for the Farberware Dual Thermal Carafe Coffeemaker (models FSCM200M, FSCM200RM, FSCM200BM, FSCM200CBM), covering safety, operation, cleaning, and warranty information.</p>