

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Conair](#) /
- > [Conair True Glow Sonic Facial Brush Kit \(Model 21PS078200\) Instruction Manual](#)

Conair 21PS078200

Conair True Glow Sonic Facial Brush Kit

Model: 21PS078200

1. PRODUCT OVERVIEW

The Conair True Glow Sonic Facial Brush Kit is designed for deep facial cleansing. It features sonic technology, is waterproof, and rechargeable, offering a gentle yet effective way to clean pores and remove impurities. The kit includes the main brush unit, a charging base, and two brush heads.



The Conair True Glow Sonic Facial Brush Kit, featuring the main brush unit resting on its charging base. The brush has a white handle, a grey power button, and a white brush head. The charging base is also white.

2. SETUP

2.1 Initial Charge

Before first use, ensure the Conair True Glow Sonic Facial Brush is fully charged. Place the brush onto its charging base and connect the charging cable to a power outlet. The indicator lights on the brush will show

charging status.



A front view of the Conair True Glow Sonic Facial Brush, showing the power button and indicator lights, positioned on its white charging base.



The charging cable for the Conair True Glow Sonic Facial Brush Kit, with its plug ready to connect to the charging base.

2.2 Attaching a Brush Head

Align the desired brush head with the top of the main unit and gently press down until it clicks into place. Ensure it is securely fastened before use.



The brush head detached from the main unit of the Conair True Glow Sonic Facial Brush, showing the attachment mechanism.

3. OPERATING INSTRUCTIONS

1. **Prepare Your Face:** Wet your face with warm water.
2. **Apply Cleanser:** Apply your preferred facial cleanser directly to the brush head.
3. **Wet Brush Head:** Briefly wet the brush head under running water.
4. **Power On:** Press the power button on the handle to turn on the device.
5. **Select Speed:** The brush typically offers multiple speed settings (e.g., High, Medium, Low). Press the power button repeatedly to cycle through the speeds.
6. **Cleanse:** Gently move the brush in circular motions across your face for approximately 60 seconds. Avoid pressing too hard.
7. **Power Off:** Press and hold the power button to turn off the device.



A woman demonstrating the use of the Conair True Glow Sonic Facial Brush on her face, illustrating its ergonomic design.

4. MAINTENANCE

4.1 Cleaning the Brush

After each use, ensure the device is turned off and unplugged from its charging base. Rinse the brush head thoroughly with warm water and allow it to air dry. Do not use silicone-based products for cleaning the device.



A detailed close-up of the sonic facial brush head, highlighting the soft bristles designed for facial cleansing.

4.2 Replacing Brush Heads

Brush heads should be replaced periodically for optimal performance and hygiene. To remove a brush head, gently twist and pull it off the main unit. Attach a new brush head by aligning and pressing until it clicks into place.

5. TROUBLESHOOTING

If the device does not turn on or operate as expected, ensure it is fully charged. If issues persist, please refer to the support information below for assistance.

6. SPECIFICATIONS

- **Model Number:** 21PS078200
- **Brand Name:** Conair
- **Model Name:** True Glow Sonic Facial Brush Kit
- **Power Source:** Rechargeable Battery Powered
- **Operation Mode:** Automatic
- **Material Type:** Silicone (referring to brush head material)
- **Product Care Instructions:** Wash with Warm Water
- **Package Dimensions:** 13.39 x 11.58 x 6.34 inches
- **Weight:** 1.64 Pounds
- **Date First Available:** February 6, 2022
- **Manufacturer:** Conair Corporation

- **UPC:** 074108446817

7. WARRANTY AND SUPPORT

For warranty information or product support, please contact Conair Corporation directly. Refer to the product packaging or the official Conair website for the most up-to-date contact details and warranty terms.