Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave House Twin Low Loft Bed

Bellemave House Twin Low Loft Bed with Storage Drawers Instruction Manual

Model: House Twin Low Loft Bed

1. Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Bellemave House Twin Low Loft Bed with Storage Drawers. Please read all instructions carefully before assembly and retain this manual for future reference.
The Bellemave House Twin Low Loft Bed is designed to provide a comfortable sleeping area and a playful environment for children. It features a unique house-shaped frame with a roof and windows, along with two integrated storage drawers for organization.

2. Safety Information

Your safety and the safety of your child are paramount. Please adhere to the following safety guidelines:

- **Assembly:** Ensure all parts are present and undamaged before beginning assembly. Follow all assembly steps precisely. Do not use power tools for assembly unless specifically instructed, as this may overtighten fasteners and damage the wood.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 250 lbs for the bed.
- **Mattress:** Use a mattress with a thickness between 4 and 6 inches to ensure the safety of the guardrails.
- **Guardrails:** The bed is equipped with full-length guardrails. Ensure they are securely attached at all times to prevent falls.
- **Ladder:** The short ladder is designed for easy access. Ensure it is tightly attached and stable before use.
- **Ventilation:** The semi-enclosed design provides a comforting atmosphere while maintaining air circulation. Do not obstruct the open areas.
- **Supervision:** Always supervise young children using the bed, especially during play.
- **Maintenance:** Regularly check all bolts and fasteners to ensure they remain tight. Loose fasteners can compromise the bed's stability.

3. Package Contents

Before assembly, verify that all components listed below are present in your package. If any parts are missing or damaged, please contact customer support.

- Bed Frame Components (Plywood, MDF, Pinewood)
- Slats
- Ladder
- 2 Storage Drawers
- Hardware Pack (screws, bolts, nuts, etc.)
- Assembly Instructions Manual

4. Setup and Assembly

Assembly of the Bellemave House Twin Low Loft Bed is required. It is recommended that two adults perform the assembly. Please follow the detailed step-by-step instructions provided in the separate assembly guide included in your package. Ensure you have adequate space for assembly and that all tools (typically a screwdriver and Allen wrench, often included) are at hand.

4.1 Key Assembly Steps Overview

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts using the provided parts list in the assembly guide.
3. Assemble the main bed frame structure, ensuring all connections are secure but not overtightened initially.
4. Attach the roof and window panels to form the house structure.
5. Install the guardrails around the sleeping area.
6. Attach the ladder securely to the designated position.
7. Place the bed slats onto the support rails.
8. Assemble the two storage drawers and slide them into place under the bed.
9. Once fully assembled, tighten all fasteners securely.



Image: Close-up view of the bed's ladder, slats, and a storage drawer, illustrating key components for assembly.



Image: Top-down view highlighting the roof structure and the arrangement of the bed slats.

5. Operating Instructions

The Bellemave House Twin Low Loft Bed is designed for sleeping and provides integrated storage.

5.1 Sleeping Area

- Place a twin-size mattress (recommended thickness 4-6 inches) onto the bed slats.
- Ensure the mattress fits snugly within the frame and below the top edge of the guardrails for safety.

5.2 Storage Drawers

- The two drawers located under the bed are designed for storing bedding, toys, books, or other items.
- Pull the drawers out gently to access contents and push them back in fully when not in use to maintain a tidy space.
- Do not overload the drawers to ensure smooth operation and prevent damage.





Image: Front view of the bed, illustrating the integrated storage drawers.

6. Maintenance

Regular maintenance will help prolong the life and safety of your Bellemave bed.

- **Cleaning:** Wipe the bed frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the wood finish.
- **Fasteners:** Periodically check all bolts, screws, and other fasteners to ensure they are tight. Retighten as necessary to maintain structural integrity.
- **Drawer Tracks:** Keep drawer tracks free of dust and debris to ensure smooth operation.
- **Environmental Conditions:** Avoid placing the bed in direct sunlight or near heat sources, which can cause wood to dry out or warp. Maintain a stable room temperature and humidity.

7. Troubleshooting

If you encounter any issues with your bed, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose fasteners.	Check and tighten all bolts and screws. Ensure the bed is on a level surface.
Drawers do not slide smoothly.	Debris in tracks, misaligned, or overloaded.	Clear tracks of debris. Ensure drawers are assembled correctly and not overloaded. Check alignment.
Squeaking noises.	Loose connections or friction between parts.	Tighten all fasteners. If squeaking persists, identify the source and apply a small amount of furniture wax or silicone spray to contact points (avoiding areas that bear weight).

If you are unable to resolve an issue using the troubleshooting guide, please contact Bellemave customer support for assistance.

8. Specifications

Detailed product specifications for the Bellemave House Twin Low Loft Bed:

- **Product Type:** Low Loft Bed
- **Size:** Twin
- **Overall Product Dimensions:** 80.7"L x 40.7"W x 71"H
- **Inner Bed Size (L*W):** 75.2" x 39.2"
- **Material:** Plywood, MDF, Pinewood
- **Weight Capacity:** 250 lbs
- **Recommended Mattress Thickness:** 4"-6"
- **Box Spring Required:** No
- **Assembly Required:** Yes
- **Number of Packages:** 1
- **Overall Product Weight:** 117 lbs

- **Country of Origin:** Vietnam
- **UPC:** 733805837624
- **ASIN:** B0BS6MDDZ4



Image: Detailed dimension diagram of the bed, including measurements for all major components.

9. Warranty Information

The Bellemave House Twin Low Loft Bed comes with a**One-Year Product Warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper assembly, misuse, abuse, accidents, or normal wear and tear.
Please retain your proof of purchase for warranty claims.

10. Customer Support

If you have any questions, concerns, or require assistance with your Bellemave House Twin Low Loft Bed, please do not hesitate to contact our customer support team. We are committed to ensuring your satisfaction.
For support, please refer to the contact information provided with your purchase or visit the official Bellemave store online.

© 2025 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09RWQ44QX

More documents and user manuals: **https://manuals.plus/**