

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Kyota](#) /
- › [Kyota Yutaka M898 4D Massage Chair User Manual](#)

## Kyota KY-M898

# Kyota Yutaka M898 4D Massage Chair User Manual

Model: KY-M898

## INTRODUCTION

---

This manual provides essential information for the safe and effective operation of your Kyota Yutaka M898 4D Massage Chair. Please read all instructions carefully before use and retain this manual for future reference.



Figure 1: Kyota Yutaka M898 4D Massage Chair in black, showcasing its sleek design and comfortable seating.

## SAFETY INFORMATION

---

For your safety, observe the following precautions:

- Maximum weight capacity: [number] lbs.
- Do not use the chair under the influence of alcohol or medication.
- Ensure the chair is stable and placed on a hard, flat surface.
- Do not adjust the chair while it is in use by a person.
- Keep at least 2 inches of wall clearance behind the chair for recline.

## SETUP & ASSEMBLY

---

The Kyota Yutaka M898 massage chair is designed for minimal assembly. The main unit is largely pre-assembled. Please refer to the following steps for final setup.

### Unpacking and Placement

1. Carefully remove the chair from its packaging.
2. Place the chair on a level, stable surface. Ensure there is at least 2 inches (5cm) of clearance from any wall or obstruction behind the chair to allow for recline.
3. Connect the power cord to the chair's power inlet and then to a suitable power outlet.



Figure 2: Chair dimensions and required wall clearance for zero-gravity recline.

### Footrest and Controller Setup

1. Ensure the footrest is securely attached.
2. Attach the tablet-style remote control to its designated holder on the armrest.



Video 1: Kyota Joubu M880 Highlight Video. This video demonstrates general features and operation that may be similar to the M898 model.

### PRODUCT FEATURES

- **4D Full-Body Massager:** Body roller technology along a 49-inch L-track uses in-and-out motions plus sweeping left-and-right and up-and-down motions to create a deep-tissue massage experience.
- **Kneading Calf & Foot Massage:** Calf-kneading mechanisms and shiatsu reflexology foot rollers

soothe tired, aching feet.

- **Zero-Gravity Recline:** Experience weightlessness with NASA technology, requiring only 2 inches of wall clearance.
- **Immersive Sensory Relief:** Engage onboard nature sounds and chromotherapy programs, or connect via Bluetooth for personal audio.
- **Total Control:** Operate the chair using the easy-access joystick, voice commands, wired remote, or the iOS/Android app.
- **Wireless Charging Pad:** Conveniently charge your phone with the built-in armrest pad.
- **Lumbar & Foot Heat:** Targeted heating functions to warm muscles and relieve stress.



Figure 3: Overview of Kyoto Yutaka M898 key features.

## OPERATING INSTRUCTIONS

### Power On/Off

Locate the power button on the side control panel or the main remote. Press once to power on, press and hold to power off.

### Using the Remote Control

The chair features an intuitive tablet-style touchscreen remote. Navigate through menus to select massage programs, adjust settings, and control chair functions.

### Automatic Programs

Choose from 12 choreographed auto programs designed for various needs, such as Neck, Relax, Stretch, Recovery, Lumbar, and more. These programs are accessible with a single press of a button.

### Manual Massage Modes

Customize your massage experience by selecting specific techniques (e.g., kneading, tapping, shiatsu), adjusting intensity, speed, and targeting specific body areas (e.g., full, upper, lower, partial, spot).

### Zero Gravity Function

Activate the zero-gravity recline to elevate your legs above your heart, promoting circulation and spinal decompression. This position can be selected from the remote control.



Figure 4: The chair reclines into a zero-gravity position, requiring minimal space from the wall.

### Heating Function

Activate lumbar and foot heating elements via the remote to warm muscles and enhance relaxation.

### Bluetooth Audio & Nature Sounds

Connect your device via Bluetooth to the integrated speakers to play your favorite music or guided meditations. Alternatively, select from onboard nature sounds for an immersive experience.

## Wireless Charging

Place your compatible smartphone on the wireless charging pad located on the armrest to charge your device during your massage session.

## Voice Control

The chair supports intelligent voice commands for hands-free operation. Refer to the remote control interface for available voice commands.

## MAINTENANCE & CARE

---

To maintain your massage chair, simply wipe it clean with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.

## TROUBLESHOOTING

---

If you encounter any issues with your massage chair, please refer to the following general troubleshooting tips:

- **No Power:** Ensure the power cord is securely plugged into both the chair and the wall outlet. Check the main power switch on the chair.
- **Remote Not Responding:** Check if the remote is properly connected or charged (if applicable). Restart the chair and remote.
- **Unusual Noises:** Discontinue use and contact customer support if you hear any abnormal sounds.

## SPECIFICATIONS

---

Feature	Specification
Brand	Kyota
Model Number	KY-M898
Product Dimensions	67"D x 35"W x 49"H
Color	Black/Black
Special Features	4D Massage, Zero-Gravity Recline, Chromotherapy, Nature Sounds, Bluetooth Integration, Wireless Charging Pad
Material	Memory Foam
UPC	810024207138

## WARRANTY & SUPPORT

---

For warranty information or technical support, please refer to the warranty card included in your packaging or visit the official Kyota website. Contact details for customer service can also be found in the Quick Start Guide.

