

[Manuals.plus](#) /

› [Little Partners](#) /

› Little Partners Foldable Toddler Tower, Learning Tower Explore 'N Store Montessori Standing Kitchen Tower with Folding Step Stool Platform for Cooking and Learning, Ages 2+ (Charcoal) Charcoal W/ Natural

Little Partners Explore 'N Store

Little Partners Foldable Toddler Tower

Model: Explore 'N Store

User Instruction Manual

INTRODUCTION

The Little Partners Foldable Toddler Tower, Explore 'N Store model, is designed to safely elevate your child to counter height, fostering independence and engagement in household activities such as cooking, baking, and crafting. Inspired by the Montessori learning method, this sturdy and adjustable tower provides a secure platform for children aged 2 to 6 years, supporting up to 150 lbs. Its thoughtful design includes a convenient folding step for easy storage and multiple height adjustments to grow with your child.





Figure 1: The Little Partners Foldable Toddler Tower, showcasing its charcoal and natural wood finish. This image provides an overall view of the product's design and structure.

SAFETY INFORMATION

Your child's safety is paramount. Please read and adhere to all safety guidelines before assembly and use.

- **Age and Weight Limit:** Suitable for children aged 2 to 6 years, with a maximum weight capacity of 150 lbs.
- **Adult Supervision:** Always ensure an adult is present and supervising the child while using the tower.
- **Stable Placement:** Place the tower on a flat, stable, and dry surface. Ensure all feet are firmly on the ground.
- **Secure Position:** Ensure the child is positioned centrally within the tower's platform.
- **Folding Step:** Always ensure the folding step is fully extended and locked into place when in use, or fully folded and secured when not in use.
- **Environmental Certifications:** This product is Greenguard Gold Certified, contributing to healthier indoor air quality for your child. It is also Forestry Stewardship Council Certified, indicating that the wood used comes from sustainably managed forests.



Figure 2: An adult supervising a child using the toddler tower at a kitchen counter. This image highlights the safe and interactive use of the tower, emphasizing the Greenguard Gold certification for healthier indoor air.

SOLID WOOD CONSTRUCTION



Figure 3: A visual representation of the tower's key safety features, including the full-surround safety bar, anti-tip and anti-slip feet, and the fold-away step. This diagram illustrates the design elements that ensure stability and child security.

PARTS LIST

Before beginning assembly, ensure all parts are present and undamaged. Tools for assembly are included.

- Main Side Panels (2)
- Adjustable Standing Platform (1)
- Folding Step Assembly (1)
- Top Support Bar (1)
- Hardware Pack (screws, bolts, washers, Allen wrench)
- Instruction Manual (this document)

ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Toddler Tower. It is recommended to have a second person assist during certain steps for ease and safety.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts listed above are present.
2. **Attach Top Support Bar:** Secure the Top Support Bar between the two Main Side Panels using the provided hardware. Ensure the Little Partners logo faces forward.
3. **Install Adjustable Standing Platform:** Slide the Adjustable Standing Platform into the desired height slots on the Main Side Panels. Secure it in place with the designated fasteners. Refer to the 'Operating Instructions' section for height adjustment details.
4. **Assemble Folding Step:** Attach the Folding Step Assembly to the lower section of the Main Side Panels according to the diagrams in the included assembly guide. Ensure it pivots smoothly and locks securely.
5. **Tighten All Fasteners:** Once fully assembled, go back and ensure all screws and bolts are securely tightened. Do not overtighten.
6. **Final Check:** Before first use, gently shake the assembled tower to confirm stability.

OPERATING INSTRUCTIONS

Adjusting Platform Height

The Toddler Tower features four adjustable platform heights to accommodate your child's growth and different counter heights.

1. **Unlock Platform:** Locate the locking mechanisms on both sides of the standing platform. Rotate them to the unlocked position.
2. **Adjust Height:** Carefully lift or lower the platform to the desired height slot. Ensure both sides are aligned.
3. **Lock Platform:** Once at the desired height, rotate the locking mechanisms back to the locked position to secure the platform firmly.

The available platform heights (from floor to top of platform) are approximately: 12.36", 14.33", 16.3", and 18.27".

Grows with your child



Adjustable Platform Heights:
(from floor to top of platform)

- | | | |
|--------|-----------|----|
| 18.27" | • • • • • | 1. |
| 16.30" | • • • • • | 2. |
| 14.33" | • • • • • | 3. |
| 12.36" | • • • • • | 4. |



Figure 4: This image illustrates the four adjustable height settings of the standing platform, allowing the tower to adapt as your child grows from 2 to 6 years old. The overall dimensions of the tower are also shown.

Folding the Step for Storage

The bottom step can be folded up to reduce the tower's footprint for easier storage.

1. **Clear the Step:** Ensure no objects are on the folding step.
2. **Release Latch:** Locate the release latch or mechanism for the folding step (if applicable, refer to your specific model's assembly guide for details).
3. **Fold Up:** Gently lift the step upwards until it clicks into its folded, upright position.



Figure 5: This image demonstrates how the bottom step of the toddler tower folds up, allowing the unit to slide easily under counters for convenient and space-saving storage.

Typical Use Cases

- **Kitchen Activities:** Allows children to safely participate in cooking, baking, and food preparation at counter height.
- **Bathroom Use:** Can be used at the bathroom sink for brushing teeth or washing hands.
- **Crafts and Learning:** Provides a stable platform for art projects, science experiments, or other learning activities at a table or counter.



Figure 6: A child standing on the toddler tower, reaching the kitchen sink to wash hands. This illustrates the practical application of the tower in daily household routines, promoting independence.



Figure 7: An adult and child engaged in baking activities at a kitchen island, with the child safely positioned on the toddler tower. This image highlights the tower's role in fostering interaction and learning, and notes the use of sustainably sourced solid wood.

MAINTENANCE AND CARE

Proper care will ensure the longevity and safety of your Toddler Tower.

- **Cleaning:** Wipe surfaces clean with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals that could damage the wood finish. Dry immediately after cleaning.
- **Regular Checks:** Periodically inspect all fasteners to ensure they remain tight. Re-tighten if necessary. Check for any signs of wear, damage, or loose components.
- **Storage:** Store the tower in a dry environment, away from extreme temperatures or humidity, which can affect wood integrity. Utilize the folding step feature for compact storage.




Figure 8: A close-up view of a child's feet on a silicone mat placed on the tower's platform. Please note that the silicone mat is sold separately and is not included with the toddler tower. It can aid in easy cleanup and provide a non-slip surface.

TROUBLESHOOTING

If you encounter any issues with your Toddler Tower, refer to the following common solutions:

Problem	Possible Cause	Solution
Tower feels wobbly after assembly.	Fasteners are not fully tightened.	Ensure all screws and bolts are securely tightened using the provided Allen wrench. Do not overtighten.

Problem	Possible Cause	Solution
Standing platform is difficult to adjust.	Locking mechanisms are not fully disengaged or platform is misaligned.	Ensure both locking mechanisms are fully rotated to the unlocked position. Gently wiggle the platform to align it with the slots before adjusting.
Folding step does not fold smoothly.	Obstruction or misaligned hinges.	Check for any debris or objects obstructing the folding mechanism. Ensure hinges are properly aligned and free of damage.
Scratches or marks on the wood.	Normal wear and tear or improper cleaning.	Use a wood-safe cleaner or polish for minor marks. For deeper scratches, consult a wood repair specialist. Always use soft cloths for cleaning.

SPECIFICATIONS

- **Product Dimensions:** 22.28"D x 19.58"W x 33.5"H
- **Material:** Wood (LVL wood, sustainably sourced)
- **Color:** Charcoal W/ Natural
- **Weight Limit:** 150 Pounds
- **Item Weight:** 18.36 pounds
- **Adjustable Heights (from floor to top of platform):** 12.36", 14.33", 16.3", 18.27"
- **Assembly Required:** Yes
- **Special Features:** Adjustable, Durability, Foldable Step, Anti-tip/Anti-slip feet
- **Certifications:** Greenguard Gold Certified, Forestry Stewardship Council Certified

WARRANTY AND SUPPORT

The Little Partners Foldable Toddler Tower comes with a**Limited Lifetime Warranty**. This warranty covers defects in materials and workmanship under normal use. For specific details regarding warranty coverage, claims, or product support, please contact Little Partners customer service directly.

Contact Information: Please refer to the Little Partners official website or product packaging for the most current customer service contact details.

IMPORTANT NOTE ON VIDEOS

While this product may have associated instructional videos, specific video URLs with relevant metadata (such as 'creator_type' or 'm3u8' format) were not provided in the input data. Therefore, no videos could be embedded in this

manual. For visual demonstrations, please visit the official Little Partners website or product page on Amazon.

© 2025 Little Partners. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09S1B2CNL>

More documents and user manuals: <https://manuals.plus/>