

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [vidaXL](#) /

› [vidaXL Mint Green Steel Storage Cabinet Model 336167 Instruction Manual](#)

vidaXL 336167

vidaXL Mint Green Steel Storage Cabinet Model 336167 Instruction Manual

Brand: vidaXL | Model: 336167

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your vidaXL Mint Green Steel Storage Cabinet, Model 336167. Please read all instructions carefully before assembly and use to ensure safe and correct operation of the product. Keep this manual for future reference.



Image 1.1: Front view of the vidaXL Mint Green Steel Storage Cabinet.

2. SAFETY INFORMATION

- **Read all instructions:** Ensure you understand all assembly steps and safety warnings before proceeding.
- **Keep children and pets away:** Small parts can be a choking hazard. Keep them away from the assembly area.
- **Use appropriate tools:** Ensure you have the necessary tools for assembly. Do not use power tools unless specifically instructed, as they may overtighten fasteners and damage the product.
- **Assemble on a soft, clean surface:** This prevents scratching the product during assembly.

- **Two-person assembly recommended:** For safety and ease of assembly, it is advisable to have two adults for certain steps.
- **Secure to wall:** To prevent tipping, especially in households with children, it is highly recommended to secure the cabinet to a wall using appropriate hardware (not always included). Refer to Image 2.1 for potential wall mounting points.
- **Do not overload:** Adhere to the maximum weight capacity per shelf and for the entire cabinet. The maximum weight limit for this cabinet is 30 kilograms.
- **Check stability:** After assembly, ensure the cabinet is stable and level. Adjust levelling feet as needed.



Image 2.1: Back view of the cabinet, indicating potential wall mounting points for anti-tip safety.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Top Panel (1)
- Bottom Panel (1)
- Side Panels (2)
- Back Panels (2)
- Doors (2)
- Adjustable Shelves (2)
- Legs (4)
- Handles (2)
- Levelling Feet (4)
- Assembly Hardware (screws, bolts, shelf pins, etc.)

Note: The exact quantity and type of hardware may vary slightly. Refer to the included hardware bag for specific counts.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow these general steps. For detailed diagrams, refer to the separate assembly sheet included in your package.

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the cabinet parts and your floor.
2. **Attach Legs and Levelling Feet:** Secure the four legs to the bottom panel of the cabinet. Insert the levelling feet into the bottom of each leg. Do not fully tighten the levelling feet yet.



Image 4.1: Detail of a cabinet leg with an installed levelling foot.

3. **Assemble the Frame:** Attach the side panels to the bottom panel, then connect the back panels. Finally, secure the top panel to complete the main frame. Ensure all connections are snug but do not overtighten.



Image 4.2: Example of a cabinet corner joint, illustrating proper alignment.

4. **Install Shelves:** Insert the shelf pins into the desired holes on the side panels. Place the adjustable shelves onto these pins. Ensure shelves are level and securely seated.



Image 4.3: Interior view showing adjustable shelves in place.

5. **Attach Doors and Handles:** Mount the doors to the cabinet frame using the provided hinges. Attach the handles to the front of each door. Adjust hinges if necessary to ensure doors close properly and are aligned.



Image 4.4: Detail of the cabinet handles.

6. **Final Adjustments:** Place the cabinet in its desired location. Adjust the levelling feet by turning them clockwise or counter-clockwise until the cabinet is stable and does not wobble.
7. **Wall Anchoring (Recommended):** For added safety, especially in homes with children, secure the cabinet to a wall using anti-tip hardware (not always included). Follow the instructions provided with your anti-tip kit.

5. OPERATING INSTRUCTIONS

- **Opening and Closing Doors:** Use the handles to gently open and close the cabinet doors. Avoid forcing the doors.
- **Adjusting Shelves:** To adjust the height of the shelves, remove all items from the shelf. Carefully lift the shelf and remove the shelf pins. Reinsert the pins into the desired holes at the new height, ensuring they are level, then place the shelf back onto the pins.
- **Loading the Cabinet:** Distribute weight evenly across the shelves. Do not exceed the maximum weight limit of 30 kilograms for the entire cabinet. Place heavier items on lower shelves for better stability.

6. MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish. Dry immediately with a clean cloth.
- **Regular Inspection:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Levelling Feet:** Occasionally check and adjust the levelling feet to ensure the cabinet remains stable on uneven surfaces.
- **Avoid Moisture:** Do not expose the cabinet to excessive moisture or direct sunlight, which can cause damage or fading.

7. TROUBLESHOOTING

- **Cabinet is Wobbly:**

Solution: Ensure all assembly screws are tightened. Adjust the levelling feet on the bottom of the legs until the cabinet is stable and level on the floor.

- **Doors Do Not Close Properly or Are Misaligned:**

Solution: Check the hinge attachments on both the doors and the cabinet frame. Loosen hinge screws slightly, adjust the door position, and then re-tighten. Ensure the cabinet itself is level.

- **Shelves Do Not Fit or Are Uneven:**

Solution: Verify that the shelf pins are inserted into corresponding holes on both side panels at the same height. Ensure no obstructions are preventing the shelf from seating correctly.

- **Missing Parts or Damaged Components:**

Solution: Do not proceed with assembly. Contact vidaXL customer support with your model number and a description of the issue for assistance.

8. SPECIFICATIONS

Model Number	336167
Material	Alloy Steel
Color	Mint Green
Overall Dimensions (W x D x H)	31.5" x 13.8" x 40" (80 cm x 35 cm x 101.5 cm)
Item Weight	45.3 lbs (20.6 kg)
Number of Shelves	2 (Adjustable)
Maximum Weight Limit	30 kg (66 lbs)
Assembly Required	Yes
Special Features	Adjustable Shelves, Sturdy Construction, Levelling Feet



Image 8.1: Dimensional diagram of the storage cabinet.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to report missing/damaged parts, please refer to the warranty card included with your purchase or contact vidaXL customer service directly. Please have your model number (336167) and proof of purchase ready when contacting support.

You can typically find contact information on the vidaXL official website or through your retailer.