

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [tectake](#) /

› [TecTake 801046 Faux Leather Office Chair User Manual](#)

tectake 404390

TecTake 801046 Faux Leather Office Chair User Manual

Model: 404390

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your TecTake 801046 Faux Leather Office Chair. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

The TecTake 801046 office chair is designed for comfort and durability, featuring extra thick padding, an ergonomic design, and adjustable height for an optimal seating experience.

2. SAFETY INFORMATION

Important Safety Instructions:

- Always assemble the chair according to the instructions provided.
- Do not exceed the maximum weight recommendation of 120 kg (approximately 264 lbs).
- Exercise caution when adjusting the chair's height to prevent injury.
- Ensure all screws and bolts are securely tightened before use and periodically check for looseness.
- Keep children away from the chair during assembly.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- 1 x Office Chair (includes seat, backrest, armrests, base, wheels, gas lift)
- Assembly Hardware (screws, washers, Allen key)
- Instruction Manual



Image: An illustration or photograph showing the various components of the TecTake 801046 Faux Leather Office Chair laid out, including the seat, backrest, armrests, five-star base, wheels, and gas lift cylinder.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your office chair. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

1. **Attach Wheels to Base:** Insert the five wheels into the holes at the end of each leg of the five-star base until they click securely into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the central hole of the five-star base. Ensure it is seated firmly.
3. **Attach Armrests to Seat:** Secure the armrests to the underside of the seat cushion using the provided screws. Do not overtighten initially.
4. **Attach Backrest to Seat:** Connect the backrest to the seat assembly, typically by aligning the metal plate on the backrest with the mechanism on the seat and securing with screws.
5. **Attach Seat Mechanism:** Fasten the seat mechanism (which includes the height adjustment lever and tilt control) to the underside of the seat cushion. Ensure the front of the mechanism faces the front of the seat.
6. **Connect Seat to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring the central hole of the seat mechanism aligns with the top of the gas lift. Apply gentle downward pressure to secure.
7. **Final Tightening:** Once all components are in place, securely tighten all screws.

5. OPERATION

Your TecTake 801046 office chair offers several adjustable features for personalized comfort.

- **Height Adjustment:** To raise the seat, lift the lever located under the right side of the seat while taking your weight off the chair. To lower the seat, lift the lever while seated. Release the lever at the desired height.
- **Tilt Function:** The chair features a tilt mechanism. Pull the lever outwards to enable tilting, and push it inwards to lock the chair in an upright position.
- **Swivel:** The chair is designed to swivel 360 degrees for ease of movement.
- **Mobility:** The five-star base with wheels allows for easy movement across various floor surfaces.

6. MAINTENANCE

Proper care will extend the life and appearance of your office chair.

- **Cleaning:** The faux leather material should be dry cleaned. For minor spills, gently wipe with a damp cloth and mild soap, then dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary.
- **Moving the Chair:** When moving the chair, lift it rather than dragging it to prevent damage to the base or floor.

7. TROUBLESHOOTING

If you encounter issues with your chair, refer to these common solutions:

- **Chair Sinks or Does Not Adjust Height:** Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift may need replacement. Contact customer support.
- **Chair Wobbles:** Check that all assembly screws are securely tightened, especially those connecting the armrests and mechanism to the seat. Ensure the gas lift is properly seated in the base.
- **Wheels Not Rolling Smoothly:** Check for debris (hair, dust) caught in the wheels. Clean them if necessary. Ensure the chair is on an appropriate surface (carpet or hard floor).

- **Squeaking Noises:** Apply a small amount of silicone lubricant to moving parts, such as the tilt mechanism or wheel axles, if squeaking occurs.

8. SPECIFICATIONS

Feature	Detail
Brand	tectake
Model Number	404390
Material	Faux Leather (Upholstery), Foam (Fill)
Color	White
Seat Height	42 - 50 cm (16.5 - 19.7 inches)
Seat Dimensions (W x D)	52 x 49 cm (20.5 x 19.3 inches)
Backrest Dimensions (W x H)	52 x 75 cm (20.5 x 29.5 inches)
Maximum Weight Recommendation	120 kg (264 lbs)
Product Dimensions	20.47 x 19.29 x 19.69 inches (L x W x H)
Item Weight	16 kg (35.2 lbs)
Special Features	Arm Rest, Ergonomic, Headrest, With wheels, Tilting
Product Care Instructions	Dry Clean

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the purchase documentation or contact TecTake customer service directly. Keep your proof of purchase for any warranty claims.

For further assistance, visit the official TecTake website or contact their support channels.