

[Manuals.plus](#) /

› [KUTCHINA](#) /

› Kutchina Pluto 2B Cooktop Gas Stove 2 Burners Instruction Manual

KUTCHINA Pluto 2B

KUTCHINA Pluto 2B Cooktop Gas Stove User Manual

Model: Pluto 2B

INTRODUCTION

Thank you for choosing the KUTCHINA Pluto 2B Cooktop Gas Stove. This manual provides essential information for the safe and efficient use, installation, and maintenance of your new appliance. Please read these instructions carefully before operating the gas stove and retain them for future reference.

SAFETY INSTRUCTIONS

WARNING: Failure to follow these instructions could result in fire, explosion, or carbon monoxide poisoning, which could cause property damage, personal injury, or death.

- Ensure proper ventilation in the kitchen area when using the gas stove.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Keep children and pets away from the appliance during operation.
- Never leave cooking unattended.
- Ensure all gas connections are secure and checked for leaks before first use and periodically thereafter.
- Do not modify the appliance. Any modifications can be dangerous and will void the warranty.
- Use only appropriate cookware for gas stoves.
- In case of a gas leak, immediately turn off the gas supply, open windows and doors, and do not operate any electrical switches or appliances. Contact a qualified technician.

PRODUCT OVERVIEW

The KUTCHINA Pluto 2B Cooktop Gas Stove is designed for efficient and convenient cooking. It features a sleek tempered glass top and two high-efficiency cast iron burners.

PLUTO 2B COOKTOP

SEAMLESS COMBINATION OF
DURABILITY & AESTHETICS



Image: Kutchina Pluto 2B Cooktop Gas Stove, showing the overall design with two burners and glass top.

Key Components:

- **Tempered Glass Top:** A 6mm thick, easy-to-clean glass surface.
- **Cast Iron Burners:** Two high-efficiency burners, one 79mm and one 69mm, for varied cooking needs.
- **Premium Knobs:** For precise control over flame intensity.
- **Euro Coated Pan Supports:** Sturdy supports for various cookware, ensuring stability and even heat distribution.
- **Scratch-Proof Drip Tray:** Collects spills and splatters for easy cleaning.
- **Anti-Skid Legs:** Provides stability and prevents movement during use.
- **Gas Inlet:** Connection point for the gas supply hose.



Image: Left: Detailed view of the cast iron burners. Right: Close-up of the control knobs.



Image: Left: Euro coated pan support. Right: Anti-skid legs for stability.

SETUP

1. **Unpacking:** Carefully remove the gas stove from its packaging. Inspect for any damage. Keep packaging materials away from children.
2. **Placement:** Place the gas stove on a stable, level, and non-combustible surface. Ensure there is adequate clearance from walls and overhead cabinets as per local safety regulations. Avoid placing it near flammable materials.
3. **Gas Connection:** Connect the gas stove to your gas supply using an ISI-certified rubber hose and regulator. It is highly recommended that a qualified technician performs this installation to ensure safety and compliance with local standards. Ensure the gas inlet is securely connected.
4. **Leak Check:** After connecting, apply a soap solution to all gas connections. If bubbles appear, there is a leak. Immediately turn off the gas supply and tighten the connections. Repeat the check until no bubbles are observed. Never use an open flame to check for gas leaks.



Image: Close-up of the gas inlet connection point.

OPERATING INSTRUCTIONS

1. **Before Lighting:** Ensure the gas cylinder valve is open.
2. **Lighting a Burner:**
 - Place your cookware on the pan support over the desired burner.
 - Push down and turn the corresponding control knob counter-clockwise to the 'ON' position.

- Immediately bring a lit matchstick or gas lighter near the burner to ignite the flame.
 - Once lit, release the knob.
3. **Adjusting Flame:** Turn the control knob to adjust the flame intensity. Turn towards the '+' for a higher flame and towards the '-' for a lower flame.
4. **Turning Off:** Turn the control knob clockwise to the 'OFF' position until you hear a click and the flame extinguishes. For prolonged periods of non-use, also close the gas cylinder valve.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and efficient performance of your gas stove.

- **Daily Cleaning:** After each use, allow the stove to cool completely. Wipe the tempered glass top with a soft cloth and mild detergent. Avoid abrasive cleaners or scouring pads that can scratch the glass.
- **Burners and Pan Supports:** Remove the pan supports and burners. Clean them with warm soapy water. For stubborn stains, a non-abrasive scrub brush can be used. Ensure all parts are completely dry before reassembling.
- **Drip Tray:** Empty and clean the drip tray regularly to prevent accumulation of food particles and spills.
- **Gas Inlet:** Periodically check the gas hose and connections for any signs of wear, cracks, or damage. Replace if necessary.
- Do not immerse the entire gas stove in water.



Image: The tempered glass top, highlighting its smooth surface for easy cleaning.

TROUBLESHOOTING

If you encounter any issues, refer to the following table before contacting customer service.

Problem	Possible Cause	Solution
Burner does not light	Gas supply off; clogged burner holes; faulty lighter.	Check gas cylinder valve; clean burner holes; use an external lighter.
Uneven flame	Clogged burner holes; burner cap not seated correctly.	Clean burner holes; ensure burner cap is properly aligned.

Problem	Possible Cause	Solution
Gas smell	Gas leak from connections or hose.	Immediately turn off gas supply, ventilate area, and check for leaks with soap solution. Contact a qualified technician if leak persists.
Knob is stiff	Food debris or grease accumulation.	Clean around the knob area. Do not force the knob.

If the problem persists after attempting these solutions, please contact KUTCHINA customer support.

SPECIFICATIONS

Feature	Detail
Model Number	Pluto 2B
Brand	KUTCHINA
Number of Burners	2 (1x 79mm, 1x 69mm)
Ignition Type	Manual Ignition
Top Material	6mm Tempered Glass
Burner Material	Cast Iron
Pan Support	Euro Coated
Special Features	ISI Certified, Drip Tray, Anti-Skid Legs
Color	BLACK
Material Type	Alloy Steel
Item Dimensions (D x W x H)	38D x 60W x 13H Centimeters
Item Weight	5.8 Kilograms

KUTCHINA
THE KITCHEN EXPERTS

SIMPLIFY
YOUR
COOKING



Image: Diagram showing the approximate dimensions of the Kutchina Pluto 2B gas stove.

WARRANTY AND SUPPORT

Warranty Information:

The KUTCHINA Pluto 2B Cooktop Gas Stove comes with a **1-year warranty on the product**. This warranty is applicable only on functionality. Please note that the warranty does not cover burner discoloration, deformation, denting, chipping, or peeling of the enameled black coating.

Customer Support:

For any queries, service requests, or technical assistance, please contact KUTCHINA customer support. You can find contact details on the warranty card included with your product or visit the official KUTCHINA website.

Manufacturer Contact Information:

KUTCHINA HOME MAKERS PVT. LTD.

20, CHINAR PARK, RAJARHUT, GOPALPUR, KOLKATA - 700157

