

Nerf F3776

Nerf Roblox MM2 Dartbringer Instruction Manual

MODEL: F3776

1. Introduction

Welcome to the official instruction manual for your Nerf Roblox MM2 Dartbringer blaster. This manual provides essential information on how to set up, operate, and maintain your blaster for optimal performance and safety. Please read all instructions carefully before use.

The Nerf Roblox MM2 Dartbringer blaster is inspired by the popular Roblox game MM2, bringing the excitement of the game into real-world play. It features an internal clip and comes with Nerf Elite darts, along with a special code to redeem a virtual item in the Roblox game.

2. Product Overview

Your Nerf Roblox MM2 Dartbringer blaster package includes:

- 1 x Nerf Roblox MM2 Dartbringer Blaster
- 3 x Official Nerf Elite Darts
- 1 x Code for an exclusive virtual item in Roblox MM2



Figure 2.1: Nerf Roblox MM2 Dartbringer Blaster

The blaster features a distinctive design inspired by the MM2 game, with red wing-like accents and a blue and white body. It is designed for quick and easy dart loading and firing.



Figure 2.2: Blaster and contents as packaged

3. Setup

3.1 Loading Darts

1. Ensure the blaster is not primed.
2. Locate the dart loading slot on the top of the blaster.
3. Insert one official Nerf Elite dart into the loading slot until it clicks into place. The blaster has an internal clip that holds up to 3 darts.
4. Repeat for additional darts, up to a maximum of 3.



Figure 3.1: Loading darts into the blaster

3.2 Priming the Blaster

1. Once darts are loaded, grasp the priming slide located on the top rear of the blaster.
2. Pull the priming slide all the way back until it locks into place. You will hear a click.
3. Return the priming slide to its forward position. The blaster is now primed and ready to fire.




Figure 3.2: Priming slide location (indicated on box diagram)

4. Operating

4.1 Firing the Blaster

1. After loading darts and priming the blaster, aim at your target.
2. Pull the trigger to fire a dart.
3. To fire another dart, re-prime the blaster by pulling the priming slide back and releasing it, then pull the trigger again.



Figure 4.1: Operating the blaster

5. Maintenance

5.1 Cleaning

To clean your blaster, wipe it with a dry or slightly damp cloth. Do not submerge the blaster in water or use harsh chemicals, as this may damage the internal mechanisms or exterior finish.

5.2 Storage

Store the blaster and darts in a cool, dry place away from direct sunlight and extreme temperatures. Ensure darts are not bent or crushed during storage, as this can affect their performance.

6. Troubleshooting

6.1 Dart Jamming

If darts frequently jam:

- **Check Darts:** Ensure you are using official Nerf Elite darts. Worn, bent, or damaged darts can cause jamming. Replace any damaged darts.
 - **Proper Loading:** Make sure darts are fully inserted into the internal clip.
 - **Full Priming:** Ensure the priming slide is pulled all the way back until it clicks and then fully returned forward before attempting to fire. Incomplete priming is a common cause of jams.
 - **Clear Obstructions:** Visually inspect the dart path for any foreign objects or broken dart pieces. Do not use fingers or other objects to clear jams; gently shake the blaster or use a soft, blunt tool if necessary.
-

7. Specifications

Feature	Detail
Model Number	F3776
Manufacturer	Hasbro
Product Dimensions	12 x 2.5 x 8 inches
Item Weight	15.8 ounces
Recommended Age	Ages 8 and Up
Dart Capacity	3 Darts (Internal Clip)

8. Safety Information

WARNING: Do not aim at eyes or face. To avoid injury, use only official NERF darts. Other darts may not meet safety standards. Do not modify darts or blaster.



- Always wear eye protection when using this product (not included).
- Keep away from small children. This product contains small parts and is not suitable for children under 3 years due to choking hazards.
- Adult supervision is recommended during play.





9. Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the contact information provided on the product packaging or visit the official Hasbro/Nerf website. Keep your purchase receipt as proof of purchase.

Manufacturer: Hasbro

Related Documents - F3776

	<p>Nerf Roblox MM2 Shark Seeker Blaster Instructions</p> <p>Step-by-step instructions for loading, firing, and storing the Nerf Roblox MM2 Shark Seeker blaster. Includes safety warnings and product information.</p>
	<p>Nerf Roblox Arsenal Pulse Laser Blaster Instructions</p> <p>Comprehensive guide on how to operate, load, fire, and clear jams for the Nerf Roblox Arsenal Pulse Laser motorized dart blaster. Includes safety warnings and battery information.</p>

	<p>Nerf Hyper MACH-100 Blaster: Operating and Safety Instructions</p> <p>Comprehensive guide for the Nerf Hyper MACH-100 blaster, detailing how to load, fire, clear jams, store the blaster, and important safety precautions. Includes battery information and product compatibility.</p>
	<p>Nerf Pro Stryfe X Dart Blaster: User Manual and Safety Instructions</p> <p>Comprehensive guide to operating the Nerf Pro Stryfe X Dart Blaster, including charging, loading, firing, safety warnings, and storage. Features detailed instructions for safe play and regulatory information.</p>
	<p>Nerf N-Strike Elite Strongarm Blaster: User Guide</p> <p>Official instructions for the Nerf N-Strike Elite Strongarm toy blaster. Learn how to load darts, fire single shots, and use the slam-fire feature for rapid firing. Includes safety warnings and product details.</p>
	<p>NERF Modulus ECS-10 Blaster: Instructions and Safety Guide</p> <p>Official instructions and safety information for the NERF Modulus ECS-10 blaster by Hasbro. Learn how to load, fire, maintain, and safely use your NERF blaster.</p>