

[Manuals.plus](#) /

› [TecTake](#) /

› tectake® Wicker Garden Lounge Set Instruction Manual

TecTake 800808

tectake® Wicker Garden Lounge Set Instruction Manual

Model: 800808

INTRODUCTION

Thank you for choosing the tectake® Wicker Garden Lounge Set. This 5-piece set, including a table, two armchairs, and two stools, is designed to provide comfort and style for your outdoor living space. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure long-lasting enjoyment of your product.

SETUP AND ASSEMBLY

Your tectake® garden lounge set is delivered as a construction kit and requires assembly. Please follow these steps carefully to ensure proper setup and stability.

- 1. Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the packing list are present and undamaged. Lay out all parts on a clean, soft surface to prevent scratches.
- 2. Identify Hardware:** Separate and identify all screws, bolts, and tools provided. Note that some screws may vary slightly in length; ensure you use the correct ones for each step as indicated in the assembly diagrams (if provided with the physical product).
- 3. Assemble Chairs:** Begin by assembling the frames of the armchairs. Attach the backrests and armrests to the seat base using the appropriate screws. Do not fully tighten screws until all parts are loosely connected.
- 4. Assemble Stools:** Connect the frame components of the stools.
- 5. Assemble Table:** Construct the table frame. Ensure the supports for the glass top are correctly positioned.
- 6. Final Tightening:** Once all components are loosely assembled, place the furniture on a flat, level surface. Systematically tighten all screws and bolts. Avoid over-tightening.
- 7. Place Cushions and Glass Top:** Insert the soft cushions into the armchairs and place them on the stools. Carefully place the safety glass top onto the table.



Image: The fully assembled tectake® Wicker Garden Lounge Set, showcasing its compact design.

AFMETINGEN

Totale afmetingen van de stoel
52 x 56 x 92,5 cm

Zitkussen
48 x 42 x 5 cm

Zithoogte (met kussen)
44 cm

Totale afmetingen kruk
40,5 x 40,5 x 39,5 cm

Kussen
40 x 40 x 5 cm

Totale afmetingen van de tafel
130,5 x 65,5 x 73 cm

Afmetingen glasplaat
126,2 x 61,2 x 0,5 cm

TECHNISCHE DETAILS

Gewicht stoel ca. 8,5 kg
Gewicht hocker ca. 3,5 kg
Gewicht tafel ca. 19,5 kg
Draagvermogen stoel 120 kg
Draagvermogen hocker 80 kg
Draagvermogen tafel 45 kg
Materiaal gepoedercoat staal, polyethyleen, 100% polyester, glas

INHOUD

2 stoelen met kussens
 2 hockers met kussens
 Tafel met glazen blad
 Bevestigingsmateriaal
 Montage-instructies




Image: Detailed product information and dimensions for each component of the lounge set.

OPERATING INSTRUCTIONS

The tectake® Wicker Garden Lounge Set is designed for versatile outdoor use, offering comfort and practical features.

- **Seating Arrangement:** The set includes two armchairs and two stools, providing flexible seating for up to four people. The stools can also serve as footrests for added comfort.
- **Compact Storage:** For space-saving storage, the armchairs and stools are designed to fit neatly under the table. Simply slide the stools under the table, and then slide the armchairs over the stools and under the table. This compact design helps free up space when the set is not in use.
- **Integrated Bottle Opener:** The table features a convenient integrated bottle opener on its side. This allows for easy opening of beverages while enjoying your outdoor space.
- **Removable Glass Top:** The safety glass top on the table is removable, making it easy to clean and providing access to the space underneath for storage or other uses.

SLIM Design




Compact
opslag

tectake
garden

Op deze comfortabele rotan zithoek kun je heerlijk ontspannen in de zomerzon en genieten van koele cocktails. Uiterst praktisch: na gebruik kunnen de zitkussens, stoelen en krukken eenvoudig onder de tafel worden geschoven en uiterst ruimtebesparend worden opgeborgen.

Image: Illustration of the smart design allowing for compact storage of the chairs and stools under the table.



Dankzij de **flesopener aan de zijkant** vd tafel kunt u in een mum van tijd genieten van uw favoriete drankjes.



De **verwijderbare veiligheidsglasplaat** scoort met zijn hoge slag- en stootvastheid.



Dankzij het **slimme inschuifstelsel** kan de gehele set zeer ruimtebesparend worden opgeborgen.



De **hoezen** zijn waterafstotend en dankzij de ritsen verwijderbaar & wasbaar.

Image: Details showcasing the side-mounted bottle opener, the durable safety glass top, the smart compact system, and the water-repellent cushion covers.

MAINTENANCE AND CARE


Proper maintenance will extend the life and preserve the appearance of your tectake® garden lounge set.

- **Cushion Care:** The cushion covers are made from water-repellent polyester and are washable. For cleaning, remove the covers and wash them according to the care label instructions, typically a gentle cycle with mild detergent. Allow them to air dry completely before reattaching.
- **Wicker Cleaning:** The poly rattan wicker can be cleaned with a soft cloth, mild soap, and water. Avoid abrasive cleaners or brushes that could damage the material. Rinse thoroughly with clean water and allow to air dry.
- **Frame Maintenance:** The robust steel frame is lacquered to protect against corrosion. Periodically wipe the frame with a damp cloth to remove dirt and dust. Inspect screws and connections regularly and tighten if necessary.
- **Glass Top Cleaning:** Clean the safety glass top with a glass cleaner and a soft, lint-free cloth.
- **Weather Protection:** While the set is designed to be weather-resistant, for prolonged outdoor use and to protect against


material fatigue and discoloration, it is highly recommended to use a protective cover when the furniture is not in use, especially during harsh weather conditions or off-season storage.

WIND- &
weerbestendig





Waterafstotend





Poedergecoate
stalen frameconstructie



100 % roestvrijstalen
schroeven




Image: Demonstrates the wind and weather resistance of the set, highlighting water-repellent properties, powder-coated steel frame construction, and 100% stainless steel screws.

TROUBLESHOOTING

This section addresses common issues you might encounter with your garden lounge set.

Problem	Possible Cause	Solution
Furniture feels wobbly after assembly.	Screws not fully tightened or uneven surface.	Ensure all screws are securely tightened. Place the furniture on a flat, level surface. If still wobbly, loosen all screws slightly, gently rock the furniture to settle, then re-tighten.
Cushions appear stained or dirty.	Accumulation of dirt, dust, or spills.	Remove cushion covers and wash them according to care instructions. For minor spots, spot clean with a damp cloth and mild soap.

Problem	Possible Cause	Solution
Wicker material looks dull or dirty.	Exposure to elements, dust, or grime.	Clean the wicker with a soft cloth, mild soap, and water. Rinse thoroughly and allow to air dry. Consider using a protective cover when not in use.
Glass top is scratched or damaged.	Impact or abrasive cleaning.	Avoid placing sharp or heavy objects directly on the glass. Use soft cloths for cleaning. If severely damaged, contact customer support for replacement options.

SPECIFICATIONS

Feature	Detail
Model Number	800808 (Palermo)
Brand	TecTake
Material	Poly rattan (Plastic), Steel (powder-coated), Glass, Polyester (cushions)
Color	Black
Overall Product Dimensions (L x W x H)	Approximately 391.5 x 196.5 x 73 cm (when fully extended/arranged)
Chair Dimensions (L x W x H)	52 x 56 x 92.5 cm
Stool Dimensions (L x W x H)	40.5 x 40.5 x 39.5 cm
Table Dimensions (L x W x H)	130.5 x 65.5 x 73 cm
Glass Plate Dimensions	126.2 x 61.2 x 0.5 cm
Total Product Weight	Approximately 43 kg
Assembly Required	Yes
Max. Load Capacity (Chair)	120 kg
Max. Load Capacity (Stool)	80 kg
Max. Load Capacity (Table)	45 kg

WARRANTY AND SUPPORT

For any questions, concerns, or issues not covered in this manual, please contact tectake customer support. Please have your model number (800808) and purchase information ready when contacting support.

Information regarding spare parts availability is not provided in the product specifications. For specific part inquiries, please contact tectake customer service directly.

Note: This product is manufactured by tectake.

OFFICIAL PRODUCT VIDEOS

No official product videos from the seller are available for this product at this time.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09S6SZWKY>

More documents and user manuals: <https://manuals.plus/>