Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ATOTO AC-44F8

ATOTO AC-44F8 Wireless Remote Control User Manual

Model: AC-44F8

Brand: ATOTO

1. Product Overview

The ATOTO AC-44F8 is a wireless remote control designed to enhance driving safety and convenience by providing easy access to car stereo functions without diverting attention from the road. It is particularly beneficial for vehicles that lack original steering wheel control (SWC) capabilities.



Image: The ATOTO AC-44F8 Wireless Remote Control, featuring a circular design with illuminated buttons for various functions and

a strap for attachment.

Compatibility

The AC-44F8 is compatible with ATOTO A5, A6, F7, and S8 series car stereos, as well as most third-party car stereos. Please note that it is not compatible with ATOTO P5, P8, P9, and P10 series.

2. Setup and Installation

Proper installation of the AC-44F8 involves connecting the receiver to your car stereo and positioning the remote control for optimal accessibility.

Wiring Connection

Connect the receiver unit to your car stereo's steering wheel control input. Typically, this involves connecting the SWC key cables and accessory power. Refer to the wiring diagram below for detailed connections.




Image: A diagram illustrating the wiring connections from the car stereo to the AC-44F8 receiver and the wireless remote control (transmitter). It shows connections for chassis ground, accessory/ignition, and steering wheel key inputs. A warning indicates that placing the SWC receiver behind the marked red dotted area on the car stereo may block the signal.

Important Note on Signal Blocking: Avoid placing the SWC receiver behind areas on the car stereo marked with red dotted lines, as this may block the signal and impair functionality.

Physical Attachment

The AC-44F8 can be attached to your steering wheel using the provided watchband-style strap or affixed to a convenient location using the adhesive pad.

1. **Strap Attachment:** Secure the AC-44F8 to your steering wheel using the adjustable strap. Ensure it is positioned where it can be easily reached without obstructing driving.
2. **Adhesive Attachment:** For alternative placement, remove the strap and attach the adhesive pad to the back of the remote. Clean the desired surface thoroughly before applying the remote.



Image: A visual guide demonstrating how to attach the AC-44F8. It shows detaching the remote from the strap, attaching an adhesive pad, buckling the strap, and examples of the remote attached to a steering wheel and a dashboard.

Key Mapping

After connecting the receiver, perform key mapping through your car stereo's settings. This process assigns specific functions (e.g., volume up, next track) to the buttons on the AC-44F8 remote. Consult your car stereo's manual for detailed key mapping instructions.

3. Operating Instructions

The AC-44F8 features 5 buttons and 1 rotary knob, providing 6 distinct functions to control your car stereo.

Available Functions

- **Voice Command:** Activate voice assistant.
- **Volume Adjustment:** Increase or decrease audio volume using the rotary knob.
- **Track Navigation:** Skip to the previous or next track.
- **Call Management:** Answer or hang up phone calls.



Image: An illustration detailing the main functions of the AC-44F8 remote. Icons represent Voice Search, Answer Call, Hang Up Call, Previous Track, Next Track, Volume Up, and Volume Down. Below, a driver is shown using the remote on a steering wheel while music notes emanate from the car stereo display.

Luminous Buttons

All buttons on the AC-44F8 are made with luminous material, ensuring clear visibility during night driving or in low-light conditions.



Image: A night-time view from inside a car, showing the ATOTO AC-44F8 remote attached to the steering wheel with its buttons glowing green, highlighting its accessibility in low-light environments.

4. Maintenance

To ensure the longevity and optimal performance of your ATOTO AC-44F8, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote control. Avoid using abrasive cleaners or solvents, as they may damage the finish or electronic components.
- **Battery Replacement:** The device uses a non-rechargeable battery. When the remote's responsiveness decreases, replace the battery. Refer to the specifications for battery type.

- **Storage:** If not in use for an extended period, store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Impact:** Protect the device from drops or strong impacts, which can damage internal components.

5. Troubleshooting

If you encounter issues with your ATOTO AC-44F8, consider the following common troubleshooting steps:

- **Remote Not Responding:**
  - Check the battery: Ensure the battery is correctly inserted and has sufficient charge. Replace if necessary.
  - Verify receiver connection: Confirm that the receiver is securely connected to the car stereo's SWC input.
  - Check for signal blocking: Ensure the receiver is not placed in an area that obstructs the wireless signal (refer to the wiring diagram).
  - Re-perform key mapping: Sometimes, re-mapping the keys in your car stereo's settings can resolve connectivity issues.
- **Inaccurate or Intermittent Control:**
  - Interference: Move the remote slightly to a different position to avoid potential wireless interference.
  - Battery level: A low battery can cause inconsistent performance. Replace the battery.
- **Luminous Buttons Not Glowing:**
  - Exposure to light: The luminous material requires exposure to light to glow in the dark. Ensure the remote is exposed to ambient light during the day.

If the issue persists after attempting these steps, please contact ATOTO customer support for further assistance.

6. Specifications

Feature	Detail
Brand	ATOTO
Model	AC-44F8
Number of Buttons	6 (5 buttons + 1 rotary knob)
Controller Type	Android (compatible with ATOTO Android car stereos)
Maximum Range	5 meters
Special Features	Voice Search, Luminous Buttons
Battery Used	No (implies non-rechargeable, user-replaceable battery, or power from receiver)

Package Size	7.2 x 7 x 4.4 cm
Weight	80 g

7. Warranty and Support

Warranty Information

ATOTO products typically come with a 12-month warranty, with an additional 6 months available upon product registration or specific conditions. Please refer to the official ATOTO website or your purchase documentation for the most accurate and up-to-date warranty terms and conditions.

Customer Support

For any questions, technical assistance, or support inquiries regarding your ATOTO AC-44F8, please contact ATOTO customer support through their official channels. You can typically find support options by visiting the ATOTO brand store or official website.

Online Platform: ATOTO provides an online platform for customer support. You can access their storefront on Amazon or visit their official website to submit questions or find contact information.

Product Operation Status Tracking: ATOTO offers 12+6 months of product operation status tracking, which may include support and updates.

© 2025 ATOTO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09S8BZR2S

More documents and user manuals: **https://manuals.plus/**