

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VOUNOT](#) /

> [VOUNOT 10x10ft Pop Up Gazebo Tent Instruction Manual \(Model 6680612241431\)](#)

VOUNOT 6680612241431

# VOUNOT 10x10ft Pop Up Gazebo Tent Instruction Manual

Model: 6680612241431

## 1. PRODUCT OVERVIEW

The VOUNOT 10x10ft Pop Up Gazebo Tent is designed for various outdoor activities, offering a shaded area and flexible enclosure options. It features a robust steel frame and a PA-coated polyester roof for sun protection.

### Key Features:

- **Solid Construction:** The upgraded frame is made of high-quality powder-coated steel for rust resistance and enhanced durability. The 160g/ PA-coated polyester roof provides effective sun protection.
- **4 Detachable Side Panels:** Includes two side panels with windows and two side panels with zippers for entrance. These panels can be removed individually or entirely to adapt to weather conditions or usage needs.
- **Versatile Use:** Provides a 10x10ft shaded area, suitable for family gatherings, picnics, parties, outdoor events, camping, and commercial applications.
- **Easy to Install:** Features a pop-up design for quick setup without tools. The gazebo is compact and easy to store when folded.
- **Package Contents:** 1 folding pavilion frame, 4 side panels, 4 sandbags, 4 pegs, 4 ropes, 1 carrying bag, and 1 set of assembly instructions.

**Important Note: This Pop Up Gazebo is not intended for use unattended or in inclement weather conditions.**

## 2. SETUP INSTRUCTIONS

Follow these steps for proper assembly of your VOUNOT Pop Up Gazebo Tent. It is recommended that two people perform the setup for ease and safety.

### 2.1 Unpacking and Initial Frame Setup

1. Remove all components from the carrying bag.
2. Place the folded frame in the desired location.
3. With two people, grasp opposite corners of the frame and slowly pull outwards, partially extending the frame.
4. Place the canopy fabric over the partially extended frame. Ensure the canopy is correctly oriented with the VOUNOT logo facing the front.
5. Continue to pull the frame outwards until it is fully extended. The frame will click into place.
6. Secure the canopy to the frame using the attached Velcro straps or ties.

**Visual Aid:**


vounot
STRUCTURE ACIER PLIABLE  
FOLDING STEEL FRAME / KLAPPBARER STAHLRAHMEN



### ATTENTION LORS DE L'INSTALLATION !

ATTENTION DURING THE INSTALLATION ! / ACHTUNG BEI DER INSTALLATION !


<p style="text-align: center; font-weight: bold;">DÉPLIAGE – UNE PERSONNE</p> <p style="text-align: center; font-weight: bold;">UNFOLDING – ONE PERSON / ENFALTUNG – EINE PERSON</p>  <p style="text-align: center; font-weight: bold;">FORTE PRESSION + NIVEAU PIED DIFFÉRENT = CONNECTEUR CASSÉ</p> <p style="text-align: center; font-size: 0.8em;">STRONG PRESSURE + DIFFERENT LEVEL = CONNECTOR BROKEN STARKER DRUCK + UNTERSCHIEDLICHES NIVEAU = STECKER GEBROCHEN</p>	<p style="text-align: center; font-weight: bold;">DÉPLIAGE – DEUX PERSONNES</p> <p style="text-align: center; font-weight: bold;">UNFOLDING – TWO PERSONS / ENFALTUNG – ZWEI PERSONEN</p>  <p style="text-align: center; font-weight: bold;">PRESSION HOMOGENÈ + MÊME NIVEAU PIED = OK</p> <p style="text-align: center; font-size: 0.8em;">EQUAL PRESSION + SAME LEVEL = OK GLEICHE PRESSE + GLEICHER PEGEL = OK</p>
---	---

Figure 2.1: Proper two-person frame extension for stability and to prevent damage.



Figure 2.2: Details of roof attachment, frame connection, and weight bag placement.

## 2.2 Attaching Side Panels

1. Identify the window panels and zipper entrance panels.
2. Attach the side panels to the gazebo frame using the integrated Velcro fasteners. Ensure a snug fit.
3. The zipper panels can be rolled up and secured with ties for an open entrance.

### Visual Aid:

OUVERTURE DE LA FERMETURE À GLISSIÈRE  
ZIPPER OPENING / REIBVERSCHLUSSÖFFNUNG



PAROIS LATÉRALES IMPERMÉABLES  
WATERPROOF SIDE WALLS / WASSERDICHTE SEITENWÄNDE

TOIT EN PVC REVÊTU  
PVC COATED ROOF / PVC-BESCHICHTETES DACH



COUVERTURE RENFORCÉE  
REINFORCED COVER / VERSTÄRKT ABDECKUNG



Figure 2.3: Details of side panel features including zippers and waterproof material.

## 2.3 Securing the Gazebo

To ensure stability, especially in light wind conditions, use the provided sandbags, pegs, and ropes.

1. Fill the sandbags with sand or other heavy material and attach them to the gazebo legs.
2. Use the pegs to anchor the gazebo legs to the ground.
3. Attach the ropes to the gazebo frame and secure them to the ground with additional pegs, pulling taut to provide extra stability.

**Visual Aid:**



Figure 2.4: Gazebo fully set up with accessories.

#### Setup Video:

Your browser does not support the video tag.

Video 2.1: Demonstrates the quick setup process of the VOUNOT Pop Up Gazebo Tent.

## 3. OPERATING INSTRUCTIONS

The VOUNOT Pop Up Gazebo Tent offers flexibility for various outdoor needs.

### 3.1 Adjusting Side Panels

- To create an open space, detach all side panels.
- To block wind or sun, attach the desired number of side panels. The window panels allow light while providing shelter.
- Use the zippered panels as entrances, rolling them up and securing them with ties when open.

#### Visual Aid:




Figure 3.1: Different configurations of the gazebo for various uses.

## 3.2 UV Protection

The gazebo's PA-coated polyester roof provides ultraviolet light protection, offering a shaded retreat from direct sunlight.

### Visual Aid:



Figure 3.2: The gazebo roof provides protection from UV rays.

## 4. MAINTENANCE

---

Proper maintenance will extend the lifespan of your gazebo.

### 4.1 Cleaning

- Clean the canopy and side panels with a mild soap solution and water. Do not use harsh chemicals or abrasive cleaners.
- Rinse thoroughly and allow all fabric components to air dry completely before storage to prevent mildew.
- Wipe down the steel frame with a damp cloth.

### 4.2 Storage

- Ensure all parts are clean and dry before disassembling.
- Carefully fold the canopy and side panels.
- Collapse the frame according to the reverse of the setup instructions.
- Store all components in the provided carrying bag in a dry, cool place away from direct sunlight.

## 5. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your gazebo.

## 5.1 Stability Issues

- **Gazebo feels wobbly:** Ensure all frame joints are fully extended and locked into place. Verify that sandbags are filled and properly attached to each leg. Use all provided pegs and ropes to anchor the gazebo securely to the ground.
- **Gazebo is unstable in wind:** The gazebo is not designed for use in strong winds. Always disassemble and store the gazebo during inclement weather. If light winds are present, ensure all anchoring methods (sandbags, pegs, ropes) are fully utilized.

## 5.2 Water Leakage

- **Water dripping through canopy:** While the roof is PA-coated for sun protection, the product specifications state it is "Not Water Resistant." It is designed for sun shade and light drizzle, not heavy rain. For prolonged rain, it is recommended to take down the gazebo.

## 5.3 Assembly Difficulties

- **Frame not extending smoothly:** Ensure two people are involved in the setup, pulling opposite corners evenly. Uneven pressure can cause the frame to bind. Refer to Figure 2.1 for correct technique.
- **Side panels not fitting:** Check that the gazebo frame is fully extended and the canopy is properly seated. Ensure you are attaching the correct panels to the corresponding sides.

## 6. SPECIFICATIONS

Attribute	Detail
Brand	VOUNOT
Model Number	6680612241431
ASIN	B09S9SW1X2
Material	Metal, Polyester
Style	Modern
Product Dimensions	118"L x 118"W x 102"H (295cm L x 295cm W x 260cm H)
Item Weight	32.4 Pounds
Frame Material	Metal
Water Resistance Level	Not Water Resistant
Shape	Square
Ultraviolet Light Protection	Yes
Assembly Required	Yes
Color	Blue
Manufacturer	VOUNOT

Attribute	Detail
Floor Area	9 Square Meters

**Visual Aid:**



Figure 6.1: Gazebo dimensions.