

AGARO 33632

AGARO Breeze Cool Mist Ultrasonic Humidifier User Manual

Model: 33632

1. INTRODUCTION

Thank you for choosing the AGARO Breeze Cool Mist Ultrasonic Humidifier. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new humidifier. Please read it thoroughly before use and retain it for future reference.

This humidifier utilizes ultrasonic technology to produce a fine cool mist, helping to maintain optimal humidity levels in your environment. It also functions as an aroma diffuser, allowing you to add essential oils for a pleasant fragrance.



AGARO
Humidifier
Model: Breeze

Covers up to 25 Sq meters area

2.5 Litres Tank Capacity

Adjustable Mist Control

The image shows a woman in a grey t-shirt and white pants lying on a bed, stretching her arms. In the foreground, a white and light blue AGARO humidifier sits on a small round wooden table, emitting a fine mist. The background is a softly lit bedroom with a white bed and a window with sheer curtains.

Image 1.1: The AGARO Breeze Humidifier in a home setting, showcasing its design and key features like 2.5 Litres tank capacity and adjustable mist control.

2. SAFETY INSTRUCTIONS

- Always place the humidifier on a firm, flat, waterproof surface at least 12 inches (30 cm) away from walls and appliances.
- Do not immerse the base unit in water or other liquids.
- Unplug the humidifier from the power outlet before filling, cleaning, or moving it.
- Do not operate the humidifier with a damaged cord or plug. If the cord or plug is damaged, contact customer support.
- Keep the humidifier out of reach of children and pets.
- Use only clean, cool tap water. Distilled or demineralized water is recommended to prevent mineral buildup.
- Do not add water directly into the mist outlet.
- Do not add essential oils directly into the water tank. Use the designated aroma tray if available, or add directly to the water as per instructions for this model.
- Do not block the air inlet or mist outlet.
- Do not attempt to repair or disassemble the humidifier yourself. Refer all servicing to qualified personnel.

3. PRODUCT OVERVIEW

The AGARO Breeze Humidifier is designed for ease of use and effective humidification. Key features include:

- **2.5 Litre Capacity:** Provides up to 12 hours of continuous mist.
- **Top-Fill Design:** Simplifies water refilling and cleaning.
- **Adjustable Mist Output:** Dial control for customized humidity levels.
- **Aroma Diffuser:** Supports essential oils for a fragrant environment.
- **360° Rotating Nozzle:** Directs mist in any desired direction.
- **Auto Shut-Off:** Automatically turns off when water level is low or tank is removed.
- **Quiet Operation:** Operates at less than 32 dB for undisturbed use.

Adjustable mist output

Adjust the mist output to Ideal level from LOW-HIGH as per requirement



Image 3.1: Front view of the AGARO Breeze Cool Mist Ultrasonic Humidifier.

4. SETUP

Follow these steps to set up your humidifier for first use:

1. **Unpack:** Carefully remove all packaging materials and place the humidifier on a flat, stable, and waterproof surface.
2. **Fill Water Tank:**
 - Remove the lid of the water tank.
 - Pour clean, cool tap water directly into the tank from the top opening. Do not exceed the maximum fill line indicated on the tank.
3. **Add Essential Oil (Optional):** If desired, add a few drops of essential oil directly into the water tank.
4. **Replace Lid:** Securely place the lid back onto the water tank.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet.

How to use



Image 4.1: Step-by-step guide on how to prepare and start the humidifier, including removing the lid, adding water, adding essential oil, and turning the control knob.

5. OPERATING INSTRUCTIONS

1. **Power On:** Turn the control knob clockwise from the 'OFF' position. The humidifier will start producing mist.
2. **Adjust Mist Output:** Continue rotating the control knob clockwise to increase the mist output, or counter-clockwise to decrease it. Adjust to your desired humidity level.
3. **Direct Mist:** Rotate the 360° mist nozzle on top of the unit to direct the mist in any direction.
4. **Auto Shut-Off:** The humidifier will automatically turn off when the water level is too low. Refill the tank to resume operation.
5. **Power Off:** Turn the control knob counter-clockwise until it clicks into the 'OFF' position. Unplug the unit when not in use.

Covers up to
25 Sq. meters area/
269 sq. feet room area



Image 5.1: Visual representation of adjustable mist output from low to high using the control knob.

360° rotating nozzle

Helps to distribute mist output evenly



Image 5.2: Detail of the 360° rotating nozzle, illustrating its function to distribute mist evenly.

6. MAINTENANCE

Regular cleaning is essential for optimal performance and hygiene. It is recommended to clean the humidifier once a week.

1. **Unplug:** Always unplug the humidifier from the power outlet before cleaning.
2. **Empty Water:** Remove the lid and empty any remaining water from the tank and base unit.
3. **Clean Water Tank:** Wipe the inside of the water tank with a soft, damp cloth. For mineral buildup, use a solution of white vinegar and water (1:1 ratio) and let it soak for 15-20 minutes, then rinse thoroughly.
4. **Clean Base Unit:** Gently wipe the surface of the base unit and the ultrasonic transducer (the small disc inside the base) with a soft, damp cloth. Do not scrub the transducer or use abrasive cleaners.
5. **Rinse:** Rinse all parts thoroughly with clean water to remove any cleaning solution residue.
6. **Dry:** Allow all parts to air dry completely before reassembling or storing the humidifier.

Note:

- Do not use harsh chemicals, abrasive cleaners, or scouring pads.

- Do not immerse the base unit in water.

7. TROUBLESHOOTING

If you encounter issues with your humidifier, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No mist or very little mist	Low water level Power not connected Mineral buildup on transducer	Refill water tank Ensure plug is securely in outlet Clean the ultrasonic transducer as per maintenance instructions
Unusual noise	Humidifier not on a flat surface Foreign object in water tank/base Water level too low	Place on a flat, stable surface Check and remove any foreign objects Refill water tank
Water leaking	Water tank lid not properly secured Overfilled water tank Humidifier placed on an uneven surface	Ensure lid is tightly closed Do not fill past the MAX line Place on a flat, stable surface
No power	Power cord unplugged Power outlet not working	Plug in the power cord securely Test the outlet with another appliance

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Model Name	Breeze
Model Number	33632
Capacity	2.5 Litres
Runtime	Up to 12 hours
Coverage Area	Up to 25 sq meters / 269 sq ft
Max Mist Output	200 ml/hr
Noise Level	Less than 32 dB
Dimensions (D x W x H)	16D x 16W x 28H Centimeters
Power Source	Corded Electric
Control Method	Dial Knob

Material	PP Plastic
Item Weight	904 Grams



Image 8.1: Product dimensions of the AGARO Breeze Humidifier.

9. WARRANTY AND SUPPORT

The AGARO Breeze Cool Mist Ultrasonic Humidifier comes with a **1-Year Warranty** from the date of purchase.

This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accident, alteration, neglect, unauthorized repair, or commercial use.

For warranty claims, technical support, or any inquiries, please contact AGARO customer service. Please have your model number (33632) and proof of purchase ready when contacting support.

