

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Segway-Ninebot](#) /
- › [Segway-Ninebot D38E Electric Scooter User Manual](#)

Segway-Ninebot D38E

Segway-Ninebot D38E Electric Scooter User Manual

1. INTRODUCTION

Welcome to the user manual for your new Segway-Ninebot D38E Electric Scooter. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your scooter. Please read this manual thoroughly before your first ride to ensure optimal performance and safety.

The Segway-Ninebot D38E is designed for adults, offering a maximum speed of 25 km/h and a range of up to 38 km. It features a 350W motor, 10-inch pneumatic tires, and a dual braking system for a reliable and comfortable riding experience.

2. SAFETY GUIDELINES

Your safety is paramount. Always adhere to the following guidelines:

- Always wear a helmet and other protective gear (knee pads, elbow pads) when riding.
- Familiarize yourself with and obey all local laws and regulations regarding electric scooter use.
- Perform a pre-ride inspection before each use: check tire pressure, brake function, and ensure all parts are secure.
- Do not ride in heavy rain, on slippery surfaces, or through puddles deeper than 2 cm.
- Avoid riding at night or in low visibility conditions. If unavoidable, ensure all lights are functional and wear reflective clothing.
- Maintain a safe distance from other vehicles and pedestrians.
- Do not perform stunts, sudden turns, or rapid acceleration/deceleration.
- The maximum weight capacity for this scooter is 120 kg. Do not exceed this limit.
- Do not allow children under the age of 16 to ride the scooter.

3. PACKAGE CONTENTS

Upon opening the package, please verify that all items are present and in good condition:

- Segway-Ninebot D38E Electric Scooter
- Power Adapter/Charger
- User Manual (this document)
- Necessary assembly tools (if applicable)

If any items are missing or damaged, please contact your retailer or Segway-Ninebot customer support.

4. SETUP AND INITIAL ASSEMBLY

Follow these steps to prepare your scooter for its first ride:

1. **Unfolding the Scooter:** Carefully lift the stem until it locks into place. Ensure the folding mechanism is securely latched.

2. **Attaching the Handlebar:** Connect the handlebar to the stem. Ensure all cables are properly routed and not pinched. Secure the handlebar using the provided screws and tools.
3. **Initial Charge:** Before first use, fully charge the scooter's battery. Connect the power adapter to the charging port and then to a power outlet. The charging indicator on the scooter or charger will change when fully charged (up to 6.5 hours).
4. **Tire Pressure Check:** Verify that both 10-inch pneumatic tires are inflated to the recommended pressure. Refer to the tire sidewall for specific pressure recommendations.



Figure 4.1: Segway-Ninebot D38E Electric Scooter, front-left view, illustrating its overall design.



Figure 4.2: Segway-Ninebot D38E Electric Scooter, side view, showcasing its profile.

5. OPERATING INSTRUCTIONS

Understanding how to operate your scooter safely and efficiently is crucial.

5.1 Powering On/Off

- **To Power On:** Press and hold the power button on the display for a few seconds.
- **To Power Off:** Press and hold the power button until the display turns off.

5.2 Display Functions

The integrated display on the handlebar provides real-time information:

- **Speed Indicator:** Shows current speed in km/h.
- **Battery Level:** Indicates remaining battery charge.

- **Riding Modes:** Displays the active riding mode (ECO, D, S).
- **Light Indicator:** Shows if the headlights are on.



Figure 5.1: Close-up of the Segway-Ninebot D38E handlebar display, showing speed, battery level, and riding modes.

5.3 Riding Modes

The D38E offers three riding modes:

- **ECO Mode:** Energy-saving mode for extended range, with a lower maximum speed.
- **D Mode (Standard):** Balanced mode for everyday use, offering a good mix of speed and range.
- **S Mode (Sport):** Maximum performance mode for higher speeds and quicker acceleration.

Switch between modes by pressing the power button briefly while the scooter is on.

5.4 Acceleration and Braking

- **Acceleration:** Push off with your foot to gain initial momentum, then gently press the throttle lever to accelerate.
- **Braking:** The scooter features an electronic front brake and a drum rear brake. Use the brake levers on the handlebar to slow down or stop. Apply both brakes smoothly for effective and safe stopping.



Figure 5.2: An adult rider operating the Segway-Ninebot D38E Electric Scooter on a paved path, demonstrating typical riding posture.

5.5 Folding and Transporting

The D38E can be folded for easy storage and transport:

1. Ensure the scooter is powered off.
2. Locate the folding latch mechanism on the stem.
3. Follow the instructions on the latch to release the stem and fold it down towards the rear wheel.
4. Secure the folded stem to the rear fender hook.



Figure 5.3: The Segway-Ninebot D38E Electric Scooter in its folded position, suitable for compact storage.



Figure 5.4: An adult transporting the folded Segway-Ninebot D38E Electric Scooter onto public transport, highlighting its portability.

6. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your scooter.

- **Battery Care:** Charge the battery regularly, even if the scooter is not in use for extended periods (at least once every 30 days). Avoid fully discharging the battery. Store the scooter in a cool, dry place.
- **Tire Pressure:** Check tire pressure weekly. Proper inflation is crucial for ride quality, range, and tire lifespan.
- **Brake Inspection:** Regularly check the functionality of both electronic and drum brakes. Ensure brake levers operate smoothly and braking is effective. Adjust or replace components as needed by a qualified technician.
- **Cleaning:** Wipe down the scooter with a damp cloth. Do not use high-pressure water jets or corrosive cleaners. Ensure the charging port cover is securely closed before cleaning.
- **General Inspection:** Periodically check all screws, bolts, and connections for tightness. Ensure no parts are loose or damaged.



Figure 6.1: Close-up of the 10-inch pneumatic front tire and fender of the Segway-Ninebot D38E Electric Scooter, important for regular pressure checks.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your Segway-Ninebot D38E Electric Scooter.

Problem	Possible Cause	Solution
Scooter does not power on	Low or depleted battery; loose battery connection; power button malfunction.	Charge the battery fully. Check battery connections. If problem persists, contact support.
Reduced range or power	Low tire pressure; riding in Sport mode constantly; heavy load; cold weather; battery degradation.	Check and inflate tires to recommended pressure. Use ECO or D mode. Reduce load. Battery performance can be affected by temperature.
Brakes feel weak or unresponsive	Brake cable adjustment needed; worn brake pads (drum brake); electronic brake issue.	Inspect brake cables and adjust tension. Have brake pads checked and replaced by a professional if worn. Contact support for electronic brake issues.

Problem	Possible Cause	Solution
Unusual noises during operation	Loose components; debris in wheels; motor issue.	Inspect all visible parts for looseness. Check wheels for obstructions. If noise persists, seek professional inspection.

For issues not listed here or if solutions do not resolve the problem, please contact Segway-Ninebot customer support.

8. SPECIFICATIONS

Detailed technical specifications for the Segway-Ninebot D38E Electric Scooter:

Feature	Specification
Model Name	D38E
Brand	Segway-Ninebot
Maximum Speed	Up to 25 km/h
Maximum Range	Up to 38 km
Motor Power	350W
Tire Type	10-inch Pneumatic with Inner Tube
Braking System	Electronic (front), Drum (rear)
Lights	2.1W LED Front Light, Integrated Brake and Rear Lights
Reflectors	E-MARK Front, Side, and Rear
Charging Time	Up to 6.5 hours
Frame Material	Aluminum
Maximum Weight Capacity	120 kg
Product Dimensions (L x W x H)	114.3 x 48 x 50 cm
Product Weight	16.3 kg
Battery Type	1 Lithium-polymer (included)
Age Range (Description)	Adult

9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official Segway-Ninebot website. Keep your proof of purchase for warranty claims.

If you require technical assistance, have questions about your scooter, or need to report a defect, please contact Segway-Ninebot customer support through their official channels. Contact details can typically be found on the manufacturer's website or in the product packaging.

Related Documents - D38E

	<p>Ninebot KickScooter F30E by Segway: Product Guideline & Features Discover the Ninebot KickScooter F30E by Segway. This product guideline details its features, specifications, and benefits, including its 25 km/h speed, 30 km range, dual braking system, and smart battery management.</p>
	<p>Ninebot KickScooter F2 Series User Manual and Specifications Comprehensive user manual and technical specifications for the Ninebot KickScooter F2, F2 Plus, and F2 Pro electric scooters, including diagrams, dashboard controls, specifications, maintenance schedules, and certifications.</p>
	<p>Ninebot KickScooter MAX G30L/G30LP User Manual Segway Comprehensive user manual for the Ninebot KickScooter MAX G30L and G30LP electric kick scooters. Includes detailed safety guidelines, assembly instructions, operation, maintenance, specifications, and contact information from Segway.</p>
	<p>Ninebot KickScooter D18U/D28U/D38U Product Manual Official product manual for the Segway-Ninebot KickScooter models D18U, D28U, and D38U, detailing specifications, features, and component identification.</p>
	<p>Ninebot KickScooter F Series User Manual Segway-Ninebot Comprehensive user manual for the Segway-Ninebot KickScooter F Series (models F20D, F25E, F30E, F30D, F40E, F40D), covering assembly, activation, riding, charging, safety, folding, and maintenance.</p>
	<p>Ninebot KickScooter Max: User Manual and Specifications Official user manual for the Ninebot KickScooter Max (G30E II, G30D II) by Segway-Ninebot. Provides detailed information on features, operation, safety, and specifications.</p>

Documents - Segway-Ninebot – D38E


[\[pdf\]](#) User Manual Installation Guide Instructions



User Manual Segway Ninebot Kickscooter D38E Download Voltes Electric Mobility v 17129039372805620817 voltes eu cdn shop files |||

EN The manufacturer reserves the right to make changes to the product, release firmware updates, and ... Handbuch IT Manuale del prodotto ES Manual del producto PL Instrukcja produktu D18E / D28E / D28D / **D38E** / D38D EN 1 Diagram Handlebar Bell Brake Lever Headlight Quick-release Lever Folding Mechanis...

lang:it score:51 filesize: 3.28 M page_count: 23 document date: 2023-05-23



[\[pdf\]](#) User Manual Installation Guide Instructions Specifications Diagram

SEGWAY D18E Ninebot Kick Scooter Instruction Manual D38E Electric 350 W Motor 38 km Range Rhyde rhyde cod18e ninebot kick scooter manualcdn shopify s files 1 0556 1997 7395 d18e manual |||

Manuals -- User Manuals Simplified. SEGWAY D18E Ninebot Kick Scooter Instruction Manual Home Segwa ... ed of the scooter, as well as error codes. Walk Mode: Max. speed is 5 km/h 3.1 mph . D18E / D28E / **D38E**: The headlight and rear light keep flashing and can t be turned off. D28D / D38D: The headlight...

lang:en score:51 filesize: 336.24 K page_count: 8 document date: 2023-05-21



[Ninebot KickScooter D Series User Manual](#)

User manual for the Ninebot KickScooter D Series, covering models D18E, D28D, D28E, D38D, and D38E. Includes product diagrams, specifications, features, and safety certifications.

lang:it score:45 filesize: 3.22 M page_count: 23 document date: 2022-01-14

[\[pdf\]](#) User Manual Installation Guide Instructions

User Manual Segway Ninebot Kickscooter D28E Download Voltes Electric Mobility v 3313682782136148894 voltes eu cdn shop files |||

EN The manufacturer reserves the right to make changes to the product, release firmware updates, and ... Handbuch IT Manuale del prodotto ES Manual del producto PL Instrukcja produktu D18E / D28E / D28D / **D38E** / D38D EN 1 Diagram Handlebar Bell Brake Lever Headlight Quick-release Lever Folding Mechanis...


lang:it score:44 filesize: 3.28 M page_count: 23 document date: 2023-05-23

[\[pdf\]](#) User Manual Installation Guide Instructions Datasheet

CE 00 0063 38 B D28D 2021 01 11Ninebot D38E Technical data sheet error codes and resolutionCE 11 2shop happytec it 2025 04 2 KickScooterNinebot resolutionVisita segway o revisa la app para descargar los materiales de usuario más recientes Stelo Leva di sgancio rapido Forcella anteriore ParafangoCE 2CE 11shop srsLtd AfmBOoqmw1hXtZp9qtHcfSg11ap6aHLSbsALw pKRHxcDHhLYxgb0GU 11CE pKRHxcDHhLYxgb0GUshop AfmBOoo 3GFPaGZYtSz2QDoZP5wf6Kf3CqicE72STusgPLaWVxhdFmsy ||| ||| EN The manufacturer reserves the right to make changes to the product, release firmware updates, and update this manual at any time. Visit www.segway.com or check the Segway-Ninebot app to download the latest user materials. You must instal ||| EN The manufacturer reserves the right to make changes to the product, release firmware updates, and update this manual at any time. Visit www.segway.com or check the Segway-Ninebot app to download the latest user materials. You must instal

EN The manufacturer reserves the right to make changes to the product, release firmware updates, and ... Handbuch IT Manuale del prodotto ES Manual del producto PL Instrukcja produktu D18E / D28E / D28D / **D38E** / D38D EN 1 Diagram Handlebar Bell Brake Lever Headlight Quick-release Lever Folding Mechanism...

lang:it score:39 filesize: 848.93 K page_count: 12 document date: 2025-04-17



[\[pdf\]](#) User Manual Installation Guide Instructions

CE 00 0063 38 B D28D 2021 01 11 r9izlv503rt0foeob2mf7riftqyam3lsegwave ru upload iblock 798
r9izlv503rt0foeob2mf7riftqyam3l D series 3 22 МБЭлектросамокат Ninebot KickScooter D38 купить в Москве по цене
самокат Ninebotv32at9l20m10ljm543i7ztxw5oue006esegwave 8ab v32at9l20m10ljm543i7ztxw5oue006esegwave МБD
NinebotЭлектросамокат D18 Ninebotv32at9l20m10ljm543i7ztxw5oue006eg8gxt5e5uy82fhsmlqgzutjijtk1tgsegwave 84f
g8gxt5e5uy82fhsmlqgzutjijtk1tgsegwave D18W D28
Ninebotv32at9l20m10ljm543i7ztxw5oue006eg8gxt5e5uy82fhsmlqgzutjijtk1tgct3r4ap8lectd4yl5yyenx8e1kzrhds37segwave
80a t3r4ap8lectd4yl5yyenx8e1kzrhds37segwave ||| ||| EN The manufacturer reserves the right to make changes to the
product, release firmware updates, and update this manual at any time. Visit www.segway.com or check the Segway-
Ninebot app to download the latest user materials. You must instal ||| EN The manufacturer reserves the right to make
changes to the product, release firmware updates, and update this manual at any time. Visit www.segway.com or check the
Segway-Ninebot app to download the latest user materials. You must instal ||| EN The manufacturer reserves the right to
make changes to the product, release firmware updates, and update this manual at any time. Visit www.segway.com or
check the Segway-Ninebot app to download the latest user materials. You must instal
EN The manufacturer reserves the right to make changes to the product, release firmware updates,
and ... Handbuch IT Manuale del prodotto ES Manual del producto PL Instrukcja produktu D18E /
D28E / D28D / **D38E** / D38D EN 1 Diagram Handlebar Bell Brake Lever Headlight Quick-release
Lever Folding Mechanis...
lang:it score:38 filesize: 3.22 M page_count: 23 document date: 2022-01-14



[\[pdf\]](#) User Manual Installation Guide Instructions

CE 04 00 0218 11 A D28U 2022 07 02 DNSsegway or check the Segway Ninebot app to D18E D28E D38E Le phare
avant et le feu Segway Inc Ninebot ninebot kickscooter d28u instrukcia 185258 28032025drv dns shop ru drivers
Manuals N ninebot 28032025 |||
EN The manufacturer reserves the right to make changes to the product, release rmware updates,
an ... bl mes sont d tect s. Mode marche : La vitesse maximale est de 5 km/h 3.1 mph . D18E /
D28E / **D38E** : Le phare avant et le feu arri re clignotent et ne peuvent pas tre teints. D28D / D38D:
...
lang:es score:38 filesize: 2.95 M page_count: 18 document date: 2022-08-23



[\[pdf\]](#) User Manual Installation Guide Instructions

CE 00 0060 91 B D18E 2021 11 04 Download Segway Ninebot Australia 24032818133241439 segwaytest oss cn
beijing aliyuncs data upload 202403 KickScooter D28E D38E The headlight and rear light keep flashing can t be turned off
* How to enable it in the app Tap sidebar menu KickScooterD18E menu segwaytest 24032818133241439segwaytest |||
EN The manufacturer reserves the right to make changes to the product, release firmware updates,
and ... rodukt-Handbuch IT Manuale del prodotto ES Manual del producto PL Instrukcja produktu
D18E / D28E / **D38E** EN 1 Diagram Handlebar Bell Brake Lever Headlight Quick-release Lever
Folding Mechanism Safet...
lang:it score:35 filesize: 2.73 M page_count: 22 document date: 2024-02-27



[\[pdf\]](#) Declaration of Conformity

CE 00 0067 92 A EU DoC GT 2022 01 21 Bekijk de markering Segway Ninebot D18E Elektrische Step 25km u E scooter
bol original media s qLyW6XoNXI6y |||
EU DECLARATION OF CONFORMITY We, Ninebot Changzhou Tech Co., Ltd. Address: 16F-17F,
Block A, Buil ... enomination: Electrical Kick Scooter Product name: Ninebot KickScooter Type or
model: D18E / D28E / **D38E** / D28D / D38D Series No.: N8GP / N8GF / N8GJ / N8GE / N8GM X
YYYY X YYYY, X=any letter from A-Z...
lang:en score:34 filesize: 311.49 K page_count: 3 document date: 2022-07-08



[Ninebot KickScooter D28U Product Manual - Specifications, Features, and Certifications](#)

Comprehensive product manual for the Ninebot KickScooter D28U, detailing specifications,
components, dashboard controls, speed modes, safety certifications, and compliance information.
lang:es score:31 filesize: 2.95 M page_count: 18 document date: 2022-08-23



[\[pdf\]](#) Declaration of Conformity

CE 00 0063 28 C EU DoC D28D 240909 Type or model D18E D28E D38E D38D Series No N8GP N8GF ou modèle de série N8GF DOC assets segway cdn DoC Multi language |||



EC DECLARATION OF CONFORMITY We, Ninebot Changzhou Tech Co., Ltd. Address: 16F-17F, Block A, Bui ... omination: Electrical Kick Scooter Product name: Ninebot KickScooter Type or model: D18E / D28E / **D38E** / D28D / D38D Series No.: N8GP / N8GF / N8GJ / N8GE / N8GM X YYYY X YYYY, X=any letter from A-...

lang:en score:31 filesize: 940.96 K page_count: 3 document date: 2025-01-09



[\[pdf\]](#) Instructions

KickScooters D series D18E D28D D28E D38D D38E User Instructions SK Jakub Segway store cz segway user documents upload Manuály |||

2 Bezpecnos pri jazde 1. KickScooter je rekreacn dopravn prostriedok. Pre bezpecn ovdanie je potrebna jazda. Spolocnos Ninebot Inc. alej len Ninebot Beijing Tech Co., Ltd. a jej dcrske spolocnosti a dovozcovia ani spolocnos Segway Inc. nenes zodpovednos za akkovek zranenia alebo skody s...

lang:hr score:31 filesize: 3.63 M page_count: 7 document date: 2022-05-02

[\[pdf\]](#) Declaration of Conformity

CE 00 0067 92 A EU DoC GT 2022 01 21 DoC Ninebot KickScooter D18E D28E D38E D28D D38D mtime 20220401050525 focal none assets segway cdn Multi language |||



EU DECLARATION OF CONFORMITY We, Ninebot Changzhou Tech Co., Ltd. Address: 16F-17F, Block A, Buil ... enomination: Electrical Kick Scooter Product name: Ninebot KickScooter Type or model: D18E / D28E / **D38E** / D28D / D38D Series No.: N8GP / N8GF / N8GJ / N8GE / N8GM X YYYY X YYYY, X=any letter from A-Z...

lang:en score:31 filesize: 932.16 K page_count: 3 document date: 2022-02-12


[\[pdf\]](#)



Windows User Segway Ninebot D un F sērija LV rdveikals lv reader p 493291 lang |||

LV Partdie attli ir paredzti tikai ilustratviem nolkiem. Faktiskais produkta vai lietotnes interfeis ... eisung IT Manuale d uso ES Instrucciones de uso PL Instrukcja obsługi CE.00.0053.72-A D18E/ D28E /**D38E** / F25E II/ F40I/ F65I Laipni Idzam/ Bienvenue / Herzlich willkommen / Benvenuto / Bienvenidos...

lang:es score:31 filesize: 1.69 M page_count: 11 document date: 2023-05-19



[pdf]

Télécharger la fiche produit SEGWAY D38E PC portables et tablettes Villatech 1000122550 fp villatech fr media ||| Trottinette Ninebot **D38E** Powered by Segway Fiche Produit Trottinette lectrique Ninebot **D38E** Powered by Segway Cliquez ici pour les photos lifestyle Cliquez ici pour les photos produit Cliquez ici pour le lien Youtube Cliquez ici pour la video produit 25 km/h 38 km 16.3 kg Nouveau design, meilleu...

lang:fr score:29 filesize: 171.12 K page_count: 2 document date: 2022-06-10




[pdf] Declaration of Conformity Diagram

CE 00 0063 38 B D28D 2021 01 11 KickScooters D series D18E D28E D38D D38E CZ 2 Návod k použití 12 69 MB Elektrická koloběžka Ninebot by Segway KASA cz doc 5000917 kasa document 7 1 9 |||

CZ Vrobce si vyhrazuje prvo kdykoli provdt zmny produktu , vydvat aktualizace firmwaru a aktualizova ... nny. Ninebot KickScooter CZ Uzivatelsk nvod www.segway.com CE.00.0063.38-B D18E / D28E / D28D / **D38E** / D38D CENZ 1 Diagram dtka Zvonecek Brzdov pcka Pedn svtlo Pcka skldacho mechanismu Skldac me...

lang:hr score:28 filesize: 12.69 M page_count: 5 document date: 2022-01-14



[pdf] User Manual

Mette Jakobsen Witt A S Ninebot KickScooterNinebot är ett registrerat varumärke som tillhör Tianjin Technology IPX5 Lading Ca 3 5 timer Batteri Normal spenning 42 V Maks ladespenning90710100 manual nowitt no Files Images ECOM Downloads 90710100 |||

Ninebot KickScooter NO Bruksanvisning D18E D28D D28E **D38E** 2 Innhold Kjresikkerhet

..... 4 Vedlikehold
.....10 Symbolforklaring ...

lang:no score:28 filesize: 1.96 M page_count: 44 document date: 2022-03-15



[pdf] Diagram

CE 00 0063 38 B D28D 2021 01 11 KickScooter D18E D28E D38E CZ Podpora Segway store cz KickScooters D series D38D segway user documents upload Manuály |||

CZ Vrobce si vyhrazuje prvo kdykoli provdt zmny produktu , vydvat aktualizace firmwaru a aktualizova ... nny. Ninebot KickScooter CZ Uzivatelsk nvod www.segway.com CE.00.0063.38-B D18E / D28E / D28D / **D38E** / D38D CENZ 1 Diagram dtka Zvonecek Brzdov pcka Pedn svtlo Pcka skldacho mechanismu Skldac me...

lang:hr score:27 filesize: 5.55 M page_count: 7 document date: 2022-01-14




[pdf]

Ninebot D18E D28E D38E PM HU KickScooterSéta üzemmód A maximális sebesség 5 km h 3 1 mph Az első és hátsó lámpák villognak ebben az üzemmódban nem lehet őket lekapcsolni séta üzemmódot expert hu egyeb letoltes pag.aspx ID 251 |||

Ninebot KickScooter Kezelsi tmutat D18E / D28E / **D38E** ekints Kormny Cseng Fkkar Els Impa Rgztkar szsecsuk mechanika Biztonsgi zr Prizma Els villa Els srvd Agymotor Gyorstkar Mszerfal Horog Kormnyrd Lbart Dobfk Akaszt Hts srvd Hts Impa prizma Tblatart Prizma Akkumulor csomag Kitmaszt Tltsatl...

lang:no score:27 filesize: 173.82 K page_count: 8 document date: 2023-04-12



[pdf] User Manual

Mette Jakobsen Witt A S Ninebot KickScooter 90710102 manual fi witt Files Images ECOM Downloads |||
Ninebot KickScooter FI Kyttohje D18E D28D D28E **D38E** 2 Sislyluettelo Ajoturvallisuus
.....4 Kunnossapito
.....10 Merkkien selityks...

lang:fi score:27 filesize: 2.03 M page_count: 44 document date: 2022-03-15



[pdf]

CE 00 0053 79 A F25E 6 2021 05 Ninebot KickScooter D38E elektromos roller HasznÁlleti ÁtmutatÁ³ D28E mstore hu online webÁjruhÁjz d30489ff06c2c0637e537e0a283cb94b ninebot kick scooter d18e 28e 38e hasznalati utasitas custom image data srtatched |||

A gyrt fenntartja magnak a jogot, hogy a termket elzetes rtests nlkl megvltoztassa, firmware frissts ... k illusztrcik, az n kszlke ezektl eltr lehet. www.segway.com CE.00.0063.38-B D18E / D28E / D28D / **D38E** / D38D HU 1 bra Markolat Cseng Fkkar Els vilgts Gyorszr Csukl mechanizmus Biztonsgi zr Fnyvis...

lang:no score:27 filesize: 3.92 M page_count: 9 document date: 2022-05-12



[pdf]

SEGWAY ELEKTRIKLI SCOOTER D18E D28E D28D D38E D38D indd Ürün Kullanım Kılavuzu Ninebot KickScooter NINEBOT D Serisi1709805337 195 87 71 7 bilkom backend api files kilavuz |||
SEGWAY ELEKTRKL SCOOTER - D18E / D28E / D28D / **D38E** / D38D SEGWAY ELEKTRKL SCOOTER - D18E / D28E / D28D / **D38E** / D38D rn Kullanim Kilavuzu Ninebot KickScooter rn Kullanim Kilavuzu Ninebot KickScooter retici, herhangi bir zamanda rnde deiiklik yapma, retici yazilimi gncellemeleri yayrineltaicmi...

lang:id score:25 filesize: 799.93 K page_count: 19 document date: 2023-04-19



[pdf] User Manual Installation Guide Instructions

CE 00 0063 38 B D28D 2021 01 11 ninebot d18e trovaprezzi it manuali |||
Questo manuale d istruzione fornito da trovaprezzi.it. Scopri tutte le offerte per Ninebot D18E o c ...
Handbuch IT Manuale del prodotto ES Manual del producto PL Instrukcja produktu D18E / D28E / D28D / **D38E** / D38D EN 1 Diagram Handlebar Bell Brake Lever Headlight Quick-release Lever Folding Mechanis...

lang:it score:24 filesize: 3.22 M page_count: 23 document date: 2022-01-14

[\[pdf\]](#) Diagram

CE 00 0063 38 B D28D 2021 01 11 ai Náhled * souboru s návodem k obsluze NÁVOD K OBSLUZE Elektrická koloběžka Ninebot by Segway D18E Databáze návodu v češtině elektricka kolobezka ninebot segway d18e 96946 locked navod cz preview 97 |||



CZ Vrobce si vyhrazuje prvo kdykoli provdt zmny produktu , vydvat aktualizace firmwaru a aktualizova ... yny. Ninebot KickScooter CZ Uzivatel'sk nvod www.segway.com CE.00.0063.38-B D18E / D28E / D28D / **D38E** / D38D CENZ 1 Diagram dtka Zvonecek Brzdov pcka Pedn svtlo Pcka skldacho mechanismu Skldac me...

lang:hr score:23 filesize: 8.29 M page_count: 4 document date: 2022-11-10

[\[pdf\]](#) Diagram

CE 00 0063 38 B D28D 2021 01 11 ai Náhled * souboru s návodem k obsluze NÁVOD K OBSLUZE Elektrická koloběžka Ninebot by Segway D28E Databáze návodu v češtině elektricka kolobezka ninebot segway d28e 96947 locked navod cz preview 97 |||



CZ Vrobce si vyhrazuje prvo kdykoli provdt zmny produktu , vydvat aktualizace firmwaru a aktualizova ... yny. Ninebot KickScooter CZ Uzivatel'sk nvod www.segway.com CE.00.0063.38-B D18E / D28E / D28D / **D38E** / D38D CENZ 1 Diagram dtka Zvonecek Brzdov pcka Pedn svtlo Pcka skldacho mechanismu Skldac me...

lang:hr score:23 filesize: 8.29 M page_count: 4 document date: 2022-11-10

[Ninebot Indicators for Electric KickScooters: User Manual and Installation Guide](#)

Comprehensive guide to Ninebot Indicators for Electric KickScooters, covering installation, usage, specifications, and troubleshooting. Includes information for E, D, F, and G series models.

lang:en score:20 filesize: 17.63 M page_count: 23 document date: 2022-07-25



[\[pdf\]](#) Diagram

Ninebot Indikatoren für Elektrische KickScooter B1c3xisQDsL ref dp product quick view m media amazon images I ||| Machine Translated by Google Ninebot-Indikatoren fr Elektrische KickScooter IN Benutzerhandbuch ES ... G30D II/G30LE/ G30LE II/G30LD; F-Serie: F20D/F25E/F30D/F30E/F40D/F40E; D-Serie: D18E/D28D/D28E/D38D/**D38E**; E-Serie: E22D/E22E/E25D/E25E/E45D/E45E/ ES1LD/ES1//ES2/ES2L/ES4. Aufladekabel Funktion Stan...

lang:de score:19 filesize: 2.06 M page_count: 15 document date: 2023-10-16



[\[pdf\]](#)

Untitled Bekijk de CE marking Segway Ninebot Kickscooter D38E Elektrische Step bol original media s q6BrM5kj6Vkp ||| ...

lang:de score:18 filesize: 165.12 K page_count: 1 document date: 2022-05-19



KICSELEZTÜK A ROSSZ ÁRAKAT!
WWW.BESTBYTE.HU

BEST BYTE

SAMSUNG
4K UHD
QUANTUM HDR, ANGLE
QLED

SAMSUNG
SMART LED TV
25" (63,5 CM)
159 999 Ft 5% THM
36 x 5 137 Ft 2

4GB / 128GB HÁTTÉRÉR
18,1 M OXIDÁSTÓLÁS

REALME
REALME 8330T
OKOSTELEFON
4,7" (11,9 CM) ÉRŐS
1,9 MM VÉDELLEL ÉS 32 MP MP
CAMERA A HÁTULON ÉS
16 MP MP
CAMERA ELŐLŐL

69 999 Ft 0% THM
10 x 7 000 Ft 1

AEG
8 KG KAPACSIÁS
INVERTER MOTOR

400 KONFINZÁCIÓS
STARTSTOP

149 899 Ft 5% THM
36 x 6 811 Ft 2

0% THM 10 HÓNAPRA ÉS 9,9% THM 36 HÓNAPRA,
MINDEN AZ AKCIÓBAN RÉSZTVEVŐ TERMÉKEIREL!

[pdf] Flyer

BB flyer november vb v5 BestByte HD SMART LED TV 32 UE32T5302CKXXH PURCOLOR 353668 55

UE65AU7022KXXH ENERGIAOSZTÁLY G 165cm REALME WATCH 2 PRO OKOSÓRA bestbyte hu il y a 1 jour — |||

AFELTNTETETTRAKRVNYESEK: 2022.NOVEMBER21-DECEMBER04. WWW.BESTBYTE.HU

345313 SAMSUNG SMARTQLEDTV 43 ... 9 Ft MAX. 25 KM/H SEBESSG AKR 38 KM

HATTVOLSG 359499 SEGWAY NINEBOT ELEKTROMOS ROLLER KICKSCOOTER **D38E**, 10200

MAH AKKUMLTOR, 3 HALADSI MD ECO, DRIVE, SPORT 189 999 Ft 0 THM 10 HNAPRA S 9,9

THM ...

lang:i-klngon score:13 filesize: 20.2 M page_count: 14 document date: 2022-11-21