

TOPCHARGEUR VM 790

TOP CHARGEUR 9V Power Adapter User Manual

Model: **VM 790** | Brand: **TOPCHARGEUR**

1. INTRODUCTION AND PRODUCT OVERVIEW

This manual provides essential information for the safe and efficient use of your TOP CHARGEUR 9V AC-DC power adapter, specifically designed for the Domyos VM 790 exercise equipment. Please read these instructions carefully before use and retain them for future reference.

The power adapter converts standard AC wall power to the required 9V DC power for your device. It is built with multiple safety features to ensure reliable operation.



Image 1: The TOP CHARGEUR 9V Power Adapter. This image shows the compact design of the adapter with its attached power

Key Features:

- **Input:** 100-240V AC, 50-60Hz (Universal compatibility)
- **Output:** 9V DC
- **Polarity:** Center Positive (+)
- **Cable Length:** Approximately 120 cm
- **Certifications:** CE & RoHS compliant
- **Safety Protections:** Over-voltage, over-heating, short-circuit, and over-charge protection for enhanced safety.

2. SETUP INSTRUCTIONS

Follow these steps to correctly set up your power adapter:

1. **Unpack:** Carefully remove the power adapter from its packaging. Inspect it for any visible damage. Do not use if damaged.
2. **Connect to Device:** Locate the power input port on your Domyos VM 790. Insert the barrel connector of the TOP CHARGEUR adapter firmly into this port. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the AC power cord of the adapter into a standard 100-240V AC wall outlet. Ensure the outlet is easily accessible and not overloaded.
4. **Verify Connection:** Once connected, your Domyos VM 790 should receive power. Refer to your device's manual for specific power indicator lights.

Important: Always ensure the power adapter's specifications (voltage, polarity) match your device's requirements to prevent damage.

3. OPERATING INSTRUCTIONS

The TOP CHARGEUR power adapter is designed for continuous operation when connected to a compatible device and power source. No specific operational controls are present on the adapter itself.

- Once connected as per the setup instructions, the adapter will supply power to your Domyos VM 790.
- To power off your device, use the power switch on the Domyos VM 790 itself, or disconnect the adapter from the wall outlet.
- Always disconnect the adapter from the wall outlet when not in use for extended periods or during electrical storms.

Safety Precautions:

- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or modify the adapter. This will void the warranty and may cause safety hazards.
- Ensure adequate ventilation around the adapter during use to prevent overheating.

4. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your power adapter.

- **Cleaning:** Disconnect the adapter from both the wall outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or abrasive materials.
- **Cable Care:** Regularly inspect the power cable for any signs of fraying, cuts, or damage. Do not bend the cable sharply or place heavy objects on it. If the cable is damaged, discontinue use immediately and replace the adapter.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid wrapping the cable too tightly around the adapter.

5. TROUBLESHOOTING

If you encounter issues with your power adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on.	Adapter not properly connected. No power from outlet. Faulty adapter.	Ensure adapter is firmly plugged into both the device and the wall outlet. Test the wall outlet with another device. If still no power, the adapter may be faulty.
Adapter feels excessively hot.	Poor ventilation. Overload.	Ensure the adapter is in a well-ventilated area. Disconnect and allow to cool. If overheating persists, discontinue use.
Device powers on but functions intermittently.	Loose connection. Damaged cable.	Check all connections for tightness. Inspect the cable for damage. If damage is found, replace the adapter.

If these steps do not resolve the issue, please contact customer support.

6. TECHNICAL SPECIFICATIONS

- **Brand:** TOPCHARGEUR
- **Model Compatibility:** Domyos VM 790
- **Input Voltage:** 100-240V AC
- **Input Frequency:** 50-60Hz
- **Output Voltage:** 9V DC
- **Polarity:** Center Positive (+)
- **Cable Length:** 120 cm
- **Certifications:** CE, RoHS
- **Safety Features:** Over-voltage protection, Over-heating protection, Short-circuit protection, Over-charge protection
- **Manufacturer:** TOP CHARGEUR
- **Country of Origin:** China

7. WARRANTY INFORMATION

Specific warranty details for this TOP CHARGEUR product may vary depending on your region and point of

purchase. Please refer to the warranty information provided at the time of purchase or contact your retailer for details regarding warranty coverage and terms.

Typically, power adapters come with a limited warranty covering manufacturing defects. Damage resulting from misuse, accidents, unauthorized modifications, or improper installation is generally not covered.

8. CUSTOMER SUPPORT

If you require further assistance, have questions not covered in this manual, or need to report a problem, please contact the seller or manufacturer directly.

When contacting support, please be prepared to provide the following information:

- Product Name: TOP CHARGEUR 9V Power Adapter
- Model: VM 790
- Date of Purchase
- A detailed description of the issue

© 2023 TOP CHARGEUR. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

