

[manuals.plus](#) /

› [hansgrohe](#) /

› [hansgrohe Finoris Modern 1-Handle 1-Hole Bathroom Sink Faucet \(Matte Black\) - Model 76010671 User Manual](#)

hansgrohe 76010671

hansgrohe Finoris Modern 1-Handle 1-Hole Bathroom Sink Faucet User Manual

Model: 76010671

1. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in property damage or personal injury. Retain this manual for future reference.

- Always turn off the main water supply before beginning any installation or maintenance.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- Ensure all connections are secure and leak-free before restoring water supply.
- Do not use abrasive cleaners or harsh chemicals on the faucet finish, as this may cause damage.

2. PRODUCT OVERVIEW

The hansgrohe Finoris Modern 1-Handle 1-Hole Bathroom Sink Faucet (Model 76010671) is designed for a contemporary bathroom aesthetic. It features a single handle for water flow and temperature control, a durable matte black finish, and water-saving EcoRight technology.



Figure 2.1: hansgrohe Finoris Faucet installed in a modern bathroom setting, with a person washing hands.

Key Features:

- **Modern Design:** Slim shape and precise geometric design.
- **Durable Construction:** Equipped with a high-quality, smooth-running ceramic mixing system.
- **Water Efficiency:** Flow rate reduced to a maximum of 1.2 GPM (EcoRight technology).
- **Integrated Drain:** Includes a push-open drain fitting for a sleek appearance without a pull rod.
- **Easy Installation:** Connects to water supply via flexible 3/8-inch connection hoses.
- **Matte Black Finish:** Provides an expressive contrast suitable for modern architecture.
- **ComfortZone 100:** Optimized spout height and reach for comfortable use.

3. WHAT'S INCLUDED

The package contains the following components:

- hansgrohe Finoris Bathroom Faucet (Matte Black)
- Flexible Connection Hoses (3/8-inch)
- Push-Open Drain Fitting
- Installation Instructions

- Mounting Hardware

4. INSTALLATION GUIDE

This section provides general steps for installing your hansgrohe Finoris faucet. Refer to the detailed installation instructions included in your package for specific diagrams and safety warnings.

4.1. Preparation

1. Turn off the main water supply to your bathroom.
2. Clear the area around the sink and ensure you have all necessary tools.
3. Remove your old faucet and clean the sink surface.

4.2. Faucet Installation

1. Insert the flexible connection hoses through the single hole in your sink or countertop.
2. Position the faucet body over the hole.
3. From underneath the sink, secure the faucet using the provided mounting hardware. Ensure it is tightened firmly but do not overtighten.
4. Connect the flexible hoses to your hot and cold water supply lines (3/8-inch connections). Ensure a watertight seal.



Figure 4.1: A close-up view of the faucet's aerator and handle mechanism, highlighting the design and functionality.

4.3. Drain Installation

1. Install the push-open drain fitting into the sink drain hole according to the included instructions.
2. Ensure all seals are properly seated to prevent leaks.
3. Connect the drain fitting to your P-trap assembly.

5. OPERATING INSTRUCTIONS

The hansgrohe Finoris faucet features a single lever handle for easy control of water flow and temperature.

- Turning On/Off:** Lift the handle upwards to turn on the water. Push the handle downwards to turn off the water.
- Adjusting Temperature:** Move the handle to the left for hot water and to the right for cold water.
- Adjusting Flow:** The further you lift the handle, the greater the water flow.

6. MAINTENANCE AND CARE

Proper care will help maintain the finish and functionality of your hansgrohe faucet.

- Cleaning:** Clean the faucet regularly with a soft cloth and a mild soap solution. Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.
- Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, ammonia-based cleaners, or any products containing bleach, acids, or alcohol, as these can damage the matte black finish.
- Aerator Maintenance:** If water flow decreases, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris, and reattach.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Low water flow	Clogged aerator; partially closed shut-off valves; low water pressure.	Clean or replace aerator; ensure shut-off valves are fully open; check household water pressure.
Leaking from spout	Worn O-rings or cartridge.	Contact hansgrohe customer support for replacement parts or professional assistance.
Water temperature issues	Incorrect hot/cold supply connections; water heater settings.	Verify hot and cold supply lines are correctly connected; adjust water heater temperature.

8. SPECIFICATIONS

- Brand:** hansgrohe
- Model Name:** Finoris Single-Hole Faucet 100 with Pop-Up Drain
- Model Number:** 76010671
- Color:** Matte Black
- Material:** Brass
- Number of Handles:** 1
- Hole Count:** 1
- Mounting Type:** Deck Mount
- Flow Rate:** 1.2 GPM (Gallons Per Minute)
- Spout Height:** 5 Inches
- Spout Reach:** 4 Inches
- Item Weight:** 4.1 Pounds

- **Product Dimensions:** 15.75"D x 4.1"W x 2.96"H
- **Included Components:** Bathroom Faucet, Connection Hoses, Installation Instructions, Push-Open Drain

9. WARRANTY INFORMATION

This hansgrohe product comes with a **limited warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty documentation included with your purchase or visit the official hansgrohe website.

10. CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to order replacement parts, please contact hansgrohe customer support. Contact information can typically be found on the hansgrohe website or in the documentation provided with your product.

Online Resources: www.hansgrohe-usa.com