Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- X-PRO /
- > X-PRO Milan 50 50cc Moped User Manual

X-PRO Milan 50

X-PRO Milan 50 50cc Moped User Manual

Model: Milan 50 (MC-P001)

1. Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and care of your X-PRO Milan 50 50cc Moped. Please read this manual thoroughly before operating the moped to ensure proper usage and to prevent damage or injury.

The X-PRO Milan 50 is equipped with a GY6 49.6cc, air-cooled, 4-stroke engine, designed for reliable performance and fuel efficiency. It features both electric starting and a back-up kick starter for convenience.

2. SETUP AND INITIAL ASSEMBLY

Your X-PRO Milan 50 Moped is shipped in a factory package, which requires some assembly upon arrival. This section outlines the general steps for preparing your moped for first use.



Image: The X-PRO Milan 50 Moped as it appears inside its metal shipping crate, indicating the initial packaging condition.



Image: A visual comparison illustrating the components included in a 'Factory Package' (unassembled) versus a fully assembled X-PRO Moped.

2.1 Uncrating and Inspection

- 1. Carefully remove the outer packaging and metal crate. Ensure all components are present and undamaged.
- 2. Refer to the packing list to verify all parts are accounted for.

2.2 Assembly Steps

- 1. **Handlebar Installation:** Attach the handlebars securely, ensuring all cables and wires are routed correctly and not pinched.
- 2. Mirror Attachment: Install the rearview mirrors onto the handlebars. Adjust them for optimal visibility.
- 3. **Front Wheel Installation:** Securely attach the front wheel, ensuring the brake system is correctly aligned and functional.
- 4. Battery Connection: Connect the battery terminals, ensuring correct polarity.
- 5. Fluid Checks: Verify engine oil levels and brake fluid levels. Add fuel to the tank.

It is recommended to have a qualified technician perform the final inspection and adjustments before the first ride.

3. OPERATING INSTRUCTIONS

Familiarize yourself with the controls and features of your Milan 50 moped before riding.



Image: A full side view of the X-PRO Milan 50 50cc Moped, showcasing its design and components.

3.1 Starting the Engine

- 1. Ensure the moped is on its center stand.
- 2. Insert the key into the ignition and turn it to the 'ON' position.
- 3. **Electric Start:** Squeeze the left brake lever and press the electric start button.
- 4. **Kick Start:** If the electric start does not engage, use the kick starter lever located on the right side of the engine.

3.2 Seat Operation

The seat of the X-PRO Milan 50 has a specific mechanism for opening and closing. Refer to the video below for detailed instructions.

Your browser does not support the video tag.

Video: This video demonstrates the correct procedure for opening and closing the seat of the X-PRO Milan 50 Scooter, including how to manage the two-layer seat design and ensure the lock latch is properly engaged.

3.3 Riding the Moped

- 1. Always wear appropriate safety gear, including a helmet.
- 2. Familiarize yourself with the throttle, brakes (front and rear), and turn signals.
- 3. Maintain a safe speed and distance from other vehicles.

4. MAINTENANCE

Regular maintenance is crucial for the longevity and safe operation of your X-PRO Milan 50 Moped.

4.1 Routine Checks

- Engine Oil: Check engine oil level regularly and change according to the maintenance schedule.
- Tire Pressure: Ensure tires are inflated to the recommended pressure for optimal handling and safety.
- Brakes: Inspect brake levers and pads for wear and proper function.
- Lights and Signals: Verify all lights, including headlights, taillights, and turn signals, are working correctly.
- Air Filter: Clean or replace the air filter as needed to maintain engine performance.

4.2 Air Cooling System

The moped features an air cooling system that helps maintain optimal engine temperatures. Ensure the cooling fins are kept clean and free from obstructions to allow for efficient heat dissipation.

5. TROUBLESHOOTING

This section provides solutions to common issues you might encounter with your X-PRO Milan 50 Moped.

5.1 Engine Not Starting

- Check Fuel Level: Ensure there is sufficient fuel in the tank.
- Ignition Key: Verify the ignition key is in the 'ON' position.
- Battery: Check battery connections and charge level. A weak battery can prevent electric starting.
- Spark Plug: Inspect the spark plug for fouling or damage. Clean or replace if necessary.
- Kill Switch: Ensure the engine kill switch is in the 'RUN' position.

5.2 Loss of Power

- Air Filter: A clogged air filter can restrict airflow and reduce engine power. Clean or replace.
- Fuel System: Check for fuel line obstructions or a dirty carburetor.
- Tire Pressure: Underinflated tires can increase drag and reduce perceived power.

For complex issues, it is recommended to consult a certified mechanic.

6. SPECIFICATIONS

Detailed technical specifications for the X-PRO Milan 50 Moped.



Image: The X-PRO Milan 50 Moped displaying its overall length, width, and height dimensions.

Feature	Specification
Brand	X-PRO
Model Name	Milan 50
Engine Type	GY6 49.6cc, Air-cooled, 4-stroke
Starting System	Electric with back-up Kick Starter
Product Dimensions	68.9"L x 26.8"W x 42.5"H
Item Weight	192 Pounds
Number of Wheels	2
Wheel Size	10 Inches
Wheel Material	Rubber

Feature	Specification
Frame Material	Alloy Steel
Suspension Type	Rear Suspension
Brake Style	Front Braking, Rear Braking
Special Features	Lights, Seat
Manufacturer Part Number	MC-P001

7. WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the official warranty documentation provided with your purchase or contact X-PRO customer support directly. Warranty terms and conditions may vary. For technical assistance, parts, or service inquiries, please contact the manufacturer or an authorized service center.

© 2023 X-PRO. All rights reserved.

Related Documents - Milan 50



X-PRO 50cc 2-Stroke Dirt Bike Owner's Manual

Comprehensive owner's manual for the X-PRO 50cc 2-Stroke Dirt Bike, covering safety, assembly, operation, maintenance, troubleshooting, and warranty information. Designed for competition use only.



X-PRO Motorcycle Quick Start Guide and Tips

Essential quick start guide and tips for X-PRO motorcycles, including assembly advice, maintenance recommendations, and warranty information.



X-PRO ATV Speed Limiter Adjustment and Operation Tips

A quick guide from X-PRO on how to adjust the speed limiter on your ATV (model HS110A-A/ATV-D02), along with essential operating tips for safe and proper use. Includes support contact information.



X-PRO ATV Speed Limiter Adjustment and Operation Tips

Learn how to adjust the speed limiter on your X-PRO ATV (CT110-2/ATV-P012) and find essential operating tips for safe and optimal performance. Includes guidance on oil changes, battery, and more.



Smart EV/Moped
User Manual
(Model: F26 PRO / F28 PRO)

FAFREES Smart EV/Moped User Manual - F26 PRO & F28 PRO

Comprehensive user manual for FAFREES F26 PRO and F28 PRO Smart EV/Moped models, covering installation, operation, safety, and maintenance.