



Manuals.plus /

› Naviforce /

› Naviforce 9167 BYD.BN Men's Analog-Digital Watch Instruction Manual

Naviforce 9167 BYD.BN

Naviforce 9167 BYD.BN Men's Analog-Digital Watch Instruction Manual

Model: 9167 BYD.BN

INTRODUCTION

Thank you for choosing the Naviforce 9167 BYD.BN Analog-Digital Watch. This manual provides detailed instructions for the proper setup, operation, and maintenance of your timepiece. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.

PRODUCT OVERVIEW

Key Features

- Analog and Digital Time Display
- Full Calendar Display (Day and Date)
- Chronograph (Stopwatch) Function
- Water Resistance up to 3 ATM (30 meters)
- Quartz Movement for accurate timekeeping
- Durable Stainless Steel Case with Crystal Dial Window
- Comfortable Leather Strap

Watch Components

The Naviforce 9167 BYD.BN watch features a robust design with several key components:

- **Crown:** Used for setting analog time.
- **Pushers (A, B):** Used for operating digital functions such as mode selection and chronograph control.
- **Analog Dial:** Displays hours, minutes, and seconds with traditional hands.
- **Digital Display:** Shows time, date, day, and other digital functions.
- **Sub-dials:** Provide additional information, typically for day, date, or 24-hour format.

- **Leather Strap:** Secures the watch to your wrist with a deployment clasp.



Figure 1: Naviforce 9167 BYD.BN watch. This image shows the watch's transparent dial, brown leather strap, and the arrangement of its analog and digital displays, along with the crown and pushers on the side.

SETUP

Initial Setup

1. **Remove Protective Film:** Carefully remove any protective films from the watch face, case back, and strap.
2. **Set Analog Time:**
 - Pull the crown out to the first click position.
 - Rotate the crown to set the hour and minute hands to the correct time.
 - Push the crown back in to its normal position to start the analog movement.
3. **Set Digital Time and Date:**
 - Press the 'Mode' pusher (usually bottom-left or 'B') repeatedly to cycle through digital display modes (Time, Date, Alarm, Chronograph).
 - When in Time mode, press and hold the 'Adjust' pusher (usually top-left or 'A') until the digits

start flashing.

- Use the 'Reset' pusher (usually top-right or 'A' again, or a third pusher if available) to change the flashing digit.
- Use the 'Mode' pusher to move to the next setting (hours, minutes, 12/24-hour format, year, month, day).
- Once all settings are correct, press the 'Adjust' pusher again to exit setting mode.

Strap Adjustment

The watch comes with a leather strap and a deployment clasp. To adjust the strap for a comfortable fit, locate the pins on the clasp or the strap itself. You may need a small tool to push out the pins and adjust the strap length. Ensure the clasp closes securely after adjustment.

OPERATING INSTRUCTIONS

Analog Time Display

The main analog hands continuously display the current time. Ensure the analog time is synchronized with the digital time for consistency.

Digital Time and Date Display

Press the 'Mode' pusher (typically on the left side) to cycle through the various digital display modes:

- **Time Display:** Shows hours, minutes, and seconds digitally.
- **Date Display:** Shows the current month, day, and year.
- **Day Display:** Shows the current day of the week.
- **Chronograph (Stopwatch):** For measuring elapsed time.

Chronograph Function

To use the chronograph (stopwatch) function:

1. Press the 'Mode' pusher until the digital display shows the chronograph mode (usually indicated by '00:00:00').
2. Press the 'Start/Stop' pusher (typically top-right or 'A') to begin timing.
3. Press the 'Start/Stop' pusher again to pause the timing.
4. Press the 'Reset' pusher (typically bottom-right or 'B') to reset the chronograph to zero.

Water Resistance (3 ATM / 30 Meters)

Your Naviforce 9167 BYD.BN watch is water-resistant up to 3 ATM (30 meters). This means it is suitable for daily use, such as accidental splashes, rain, or hand washing. It is **not** suitable for showering, bathing, swimming, diving, or any water sports. Avoid pressing any pushers or operating the crown when the watch is wet or submerged in water, as this can compromise the water resistance.

MAINTENANCE

Cleaning

To maintain the appearance of your watch:

- Wipe the watch case and crystal with a soft, dry cloth.
- For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals. Clean with a damp cloth and mild soap if necessary, then dry thoroughly.
- Do not use chemical cleaners or abrasive materials, as these can damage the watch's finish.

Battery Replacement

The watch is powered by a Lithium Ion battery. When the watch stops or the digital display fades, it indicates that the battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

Water Resistance Care

To preserve the water resistance of your watch:

- Ensure the crown is always pushed in completely.
- Avoid exposing the watch to extreme temperature changes, which can cause seals to expand and contract.
- Have the water resistance seals checked periodically by a professional, especially after battery replacement.

TROUBLESHOOTING

If you encounter any issues with your watch, please refer to the table below for common problems and their solutions.

Problem	Solution
Analog hands not moving	Check if the crown is pushed in completely. If it is, the battery may need replacement.
Digital display is blank or dim	The battery may be low or depleted. Replace the battery.
Incorrect digital time or date	Refer to the "Set Digital Time and Date" section under Setup to reset the time and date.
Watch fogging up internally	This indicates a loss of water resistance. Avoid further water exposure and have the watch inspected by a professional immediately.

SPECIFICATIONS

Feature	Detail
Model Number	9167 BYD.BN
Movement	Quartz
Display Type	Analog-Digital
Case Material	Stainless Steel
Case Diameter	42 mm
Case Thickness	9 mm
Dial Window Material Type	Crystal
Band Material Type	Leather
Band Width	22 mm
Band Length	22 mm
Band Color	Brown
Clasp Type	Deployment Clasp
Water Resistance Depth	30 meters (3 ATM)
Power Source	Battery Powered (1 Lithium Ion battery included)
Item Weight	30 grams

WARRANTY AND SUPPORT

Manufacturer's Warranty

This Naviforce product is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For warranty claims, service, or technical assistance, please contact the manufacturer or your authorized dealer. Keep your proof of purchase for warranty validation.